

A290

ALPINE





## Welcome to your new electric vehicle

**This user manual** contains the information required:

- for you to familiarise yourself with your vehicle, to use it to its best advantage and to fully benefit from all the functions and the technical developments it incorporates.
- to ensure that it always gives the best performance by following the simple, but comprehensive advice concerning regular maintenance.
- to enable you to deal quickly with minor faults not requiring specialist attention.

It is well worth taking a few minutes to read this manual to familiarise yourself with the information and guidelines it contains about the vehicle and its functions and new features. If certain points are still unclear, our Network technicians will be only too pleased to provide you with any additional information.

For guidance, please see the following symbols:

 and  visible in the vehicle – indicate that you should consult the manual for detailed information and/or limits on operations with respect to your vehicle's equipment.

→ anywhere in the manual indicates a transfer to a page.



**anywhere in the manual indicates a hazard, danger or a safety recommendation.**

The description of the models given in this manual is based on the technical specifications at the time of writing. **The manual covers all items of equipment (both standard and optional) available for these models, but whether or not these are fitted to the vehicle depends on the version, the options selected and the country where the vehicle is sold.**

**This document may also contain information about items of equipment to be introduced later in the model year.**

**The diagrams in the user manual are provided as examples.**

Enjoy driving your new vehicle.

Translated from French. Copying or translation, in part or in full, is forbidden unless prior written permission has been obtained from the car manufacturer.

# CONTENTS


<b>Welcome to your new electric vehicle</b> .....	<b>4</b>	Starting, stopping the engine .....	153
Exterior .....	4	Standing start procedure .....	156
Passenger compartment .....	6	"Overtake" function .....	158
Driver's position .....	8	Gear control .....	160
Driving aids .....	10	Regenerative braking system .....	162
Safety on board .....	12	Parking brake.....	164
Identifying a vehicle - Labels .....	14	Environment.....	170
The engine compartment (routine maintenance).....	16	Driving advice, eco-driving .....	171
Breakdown recovery .....	18	Vehicle range: advice .....	173
<b>Getting to know your vehicle</b> .....	<b>20</b>	Tyre pressure monitoring system .....	175
Electric vehicle.....	20	Driver correction devices and aids .....	180
Card .....	51	Additional driving aid functions .....	184
Digital key .....	59	Speed limiter.....	238
Doors and opening elements.....	62	Stop and Go adaptive cruise control .....	242
Front seats .....	70	Parking aids .....	258
Rear seats .....	73	Emergency call .....	278
Seat belts.....	75	<b>Your comfort</b> .....	<b>281</b>
Additional safety devices .....	80	DRIVE MODE .....	281
Child safety .....	89	Air vents, heating and air conditioning.....	283
Child seats .....	95	Multimedia equipment .....	295
Child safety: deactivating, activating the front passenger airbag.....	109	Passenger compartment equipment.....	297
Driving position .....	113	Passenger compartment storage, fittings .....	301
Trip computer .....	118	Transporting objects .....	304
Warning lights .....	131	<b>Maintenance</b> .....	<b>307</b>
Steering .....	135	Accessing the engine, levels .....	307
Rear view.....	137	Battery .....	312
Lighting and signals .....	139	Cleaning.....	314
Audible and visual signals .....	146	<b>Practical advice</b> .....	<b>318</b>
Wiper .....	147	Tyres .....	318
<b>Driving</b> .....	<b>153</b>	Breakdown recovery .....	326

# CONTENTS

Headlights, lights: replacing bulbs .....	328
Wiper blades: replacement .....	331
Fuses .....	333
Installation and use of accessories.....	338
Operating faults .....	340
<b>Technical specifications .....</b>	<b>345</b>
Information about the vehicle .....	345
Replacement parts and repairs .....	353
Service sheets .....	354
Anticorrosion check .....	360

# EXTERIOR

1




# EXTERIOR

1. Lights: operation → 139  
Lights: replacement → 328
2. Screen wiper, washer → 147  
Demisting → 287
3. Rear view mirrors → 137
4. Bodywork maintenance → 314
5. Tyres → 318
6. → 51 → 59 card  
Locking, unlocking the doors → 64
7. Electric windows → 297
8. Load → 30

# PASSENGER COMPARTMENT

1




# PASSENGER COMPARTMENT

1. Adjusting your driving position → **75**
2. Passenger compartment storage/fit-tings → **301**
3. Rear headrests → **73**  
Rear bench seat → **74**
4. Transporting objects → **304**
5. Child safety → **89**
6. Front headrests → **70**  
Front seats → **70**

# DRIVER'S POSITION

1



# DRIVER'S POSITION

1. Instrument panel → 131
2. Trip computer controls → 118
3. Overtake (OV) control → 156 → 158
4. Window wiper(s)/washer(s) control → 147
5. Engine start/stop button → 153
6. Multimedia screen → 295
6. Heated seats → 70/Heated steering wheel → 135
7. Heating system/air conditioning → 287
8. USB-C ports in the centre console → 300
9. Centre console storage compartment/induction charging zone → 301
10. Gear control → 160
11. Electronic parking brake → 164
12. DRIVE MODE control → 281
13. Steering wheel adjustment → 135
14. Regenerative braking control → 162
15. Speed limiter → 238  
Stop and Go adaptive cruise control → 242
16. Bonnet release → 307
17. Exterior lighting → 139

# DRIVING AIDS

1

62354




## DRIVING AIDS

- Driver correction devices and aids  
➔ **180**
- My Safety ➔ **184**
- Lane departure prevention ➔ **185**
- Emergency lane departure prevention ➔ **192**
- Active emergency braking ➔ **208**
- Active emergency braking in reverse gear ➔ **235**
- Blind spot warning ➔ **199**
- Parking exit warning ➔ **272**
- Tyre pressure monitoring system  
➔ **175**
- Safe distance warning ➔ **204**
- Driver vigilance warning ➔ **215**
- Speed limiter ➔ **238**
- Stop and Go adaptive cruise control  
➔ **242**
- Road sign detection ➔ **217**
- Park Assist ➔ **258**
- Reversing camera ➔ **264**
- Hands-free parking ➔ **267**
- Safe vehicle exit ➔ **275**
- Parking exit warning ➔ **272**

# SAFETY ON BOARD

1




66307

# SAFETY ON BOARD

1. Airbags Front → 81  
Frontal passenger airbag inhibition  
→ 89
2. Airbags Curtain → 86
3. Seat belts → 75
4. Airbags side → 85

# IDENTIFYING A VEHICLE - LABELS

1




# IDENTIFYING A VEHICLE - LABELS

1. Technical information for the emergency services → **346**
2. Vehicle identification number reminder → **345**
3. Tyre pressure labels → **320**
4. Engine identification → **347**
5. Vehicle identification plate → **345**

# THE ENGINE COMPARTMENT (ROUTINE MAINTENANCE)

1




# THE ENGINE COMPARTMENT (ROUTINE MAINTENANCE)

1. Battery and engine coolant → 309
2. Brake fluid → 310
3. 12 volt battery → 312
4. Screen washer fluid → 311
5. Opening the bonnet → 307
6. “400 volt” electrical circuit → 20
7. Passenger compartment coolant → 309

# BREAKDOWN RECOVERY

1



## BREAKDOWN RECOVERY

1. Replacing windscreen wiper blade(s) → **331**
2. Puncture → **321**  
Tools → **325**
3. Fuses → **333**
4. Replacing rear light bulbs → **328**
5. Replacing the rear screen wiper blade → **331**
6. Front towing point → **326**
7. Replacing headlight bulbs → **328**

# ELECTRIC VEHICLE

## Introduction

2

Electric vehicles have special features, but operate in a similar manner to conventional vehicles.

The main difference in electric vehicles is the exclusive use of electric energy instead of fuel, as used in convention vehicles.


We therefore recommend that you read these instructions describing your electric vehicle carefully.



# ELECTRIC VEHICLE

## Electric vehicle schematic diagram

2



# ELECTRIC VEHICLE

- 1** 400 V traction battery
- 2** Electric charging connection
- 3** Electric motor
- 4** Orange electrical power cables
- 5** Secondary 12 V battery

# ELECTRIC VEHICLE

## Connected services

2

### Introduction

Your electric vehicle has connected services that provide information and/or control:

- your vehicle's charging status with low battery warning;
- the traction battery charging programming, based on certain choices on offer;
- remaining vehicle range;
- ...

You can access these services using:

- external digital devices (mobile phone, tablet, etc.);
- the vehicle multimedia screen .

For more information, refer to the multimedia equipment instructions or contact an Approved Dealer.



You can subscribe to a connected service or extend it at any time by consulting an authorised dealer

### Batteries

The electric vehicle has two types of battery:

- a "400 V" traction battery;
- a secondary 12 V battery.

#### "400 V" traction battery

This battery stores the energy necessary to operate the motor in your electric vehicle properly. As with any battery, it discharges after use, and must be regularly recharged.

You do not have to wait until the traction battery hits the reserve level in order to recharge it.

Charging times vary depending on the type of specific wall unit socket or public terminal you connect to.

Your vehicle range will depend on the traction battery charge level and also on your driving style → 173.


The vehicle's air conditioning system is used to cool the traction battery.

To preserve the lifetime of your traction battery, have your air conditioning system checked by a qualified professional. Especially if you notice a reduction in air conditioning performance.

#### Secondary 12 V battery

The second battery on your vehicle is a secondary 12 V battery: this supplies the energy required to operate vehicle equipment (lights, windshield wipers, braking assistance, etc.).

(A)



The  symbol identifies the electrical components in your vehicle which may present safety risks.

# ELECTRIC VEHICLE

## "400 V" electrical circuit



The "400 V" electrical circuit can be recognised by the orange wiring **6** and components bearing the ⚡ symbol.



The vehicle drive system in an electric vehicle uses a direct voltage of approximately 400 volts.

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle. All operations on or modifications to the 400 V electrical system (components, cables, connectors, traction battery) are strictly prohibited due to the risks they present to your safety. Call an approved dealer.

**The risk of serious burns or electric shocks can lead to death.**

## Driving

As with a car with an automatic gear-box, you will have to get used to not using your left foot, and not using this foot to brake.

When driving, if you lift your foot off the accelerator pedal or press the brake pedal, the motor generates electrical current during deceleration and this energy is used to recharge the battery → 171.

Bad weather, flooded roads:



Do not drive through floods if the depth of water is above the lower edge of the wheel rims.



The engine brake should under no circumstances be used as a substitute for the brake pedal.



## Driver obstruction

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another.

**There is a risk of wedging the pedals**

## Noise

Electric vehicles are particularly quiet. You will not yet necessarily be used to it, and neither will other road users. It is difficult for them to hear the vehicle when it is moving.

## ELECTRIC VEHICLE

As the motor is silent, you will hear noises that you are not used to hearing (aerodynamic noises, tyre noise, etc.)

Each time the ignition is switched off, the ventilation will be switched off after about ten seconds.

### Pedestrian horn

The pedestrian horn enables you to warn others of your presence – especially pedestrians and cyclists.

When the engine is started, the pedestrian horn is activated automatically.

The sound is emitted when the vehicle speed is between approximately 1 and 19 mph (1 and 30 km/h).

For further information on the pedestrian horn, refer to the multimedia instructions.

In the event of a fault with the pedestrian

horn, the warning light  is displayed on the instrument panel, accompanied by the "Failure Outside sound" message.

Consult an approved dealer.



Your electric vehicle is silent. Before leaving it, with your foot on the brake, stop the engine.

**RISK OF SERIOUS INJURY**

## Important recommendations



Please read these instructions carefully. Failure to follow these instructions may lead to **a risk of fire, serious injury or electric shocks which could result in death.**

### **In the event of an accident or impact**

In the event of an accident or an impact to the underside of the vehicle (e.g. striking a post, raised kerb or other street furniture) the electric circuit or the traction battery may be damaged.

Have the vehicle checked by an authorised dealer.

Never touch the "400 V" components or orange cables which are exposed and visible inside or outside the vehicle.

In the event of serious damage to the traction battery, leaks may occur:

- never touch liquids (fluids, etc.), coming from the traction battery;
- in the event of contact with the body, wash the affected area with plenty of water and consult a doctor as soon as possible.

In the event of an impact, even slight, against the charging flap and/or valve, have them checked by an authorised dealer as soon as possible.

### **In the event of fire**

In the event of fire, make everyone evacuate the vehicle immediately and contact the emergency services, informing them that this is an electric vehicle.

Only use extinguishing agents ABC or BC that are permitted for use with electrical fires. Do not use water or other extinguishing agents.

In the event of damage to the electrical circuit, please call an authorised dealer.

**All towing operations → 326.**

### **Washing the vehicle**

Never wash the engine compartment, the charging connection or the traction battery with a high-pressure jet.

**This risks damaging the electric circuit.**

Never wash the vehicle while it is charging. Never wash the charging cable while the vehicle is charging. Never wash the charging cable and the charging cable plug while the cable is not connected, in order to prevent corrosion of the charging pins.

## ELECTRIC VEHICLE

**Risk of electric shock and a risk to life.**

2




# ELECTRIC VEHICLE

## Charging

2

### Schematic diagram

# ELECTRIC VEHICLE



2

# ELECTRIC VEHICLE

- 1 Specific wall socket or recharging terminal
- 2 Charging cable
- 3 Electric charging connection

2



If you have any questions regarding the equipment needed for charging, please ask an authorised dealer.



## Important recommendations for charging your vehicle

Please read these instructions carefully. Failure to follow these instructions may lead to **a risk of fire, serious injury or electric shocks which could result in death.**

### Charging

Do not do anything to the vehicle during charging (washing, working in the engine compartment, etc.).

In the event of the presence of water, signs of corrosion or foreign bodies in the charging cord connector or in the vehicle charging socket, do not charge the vehicle. Fire hazard.

Do not attempt to touch the cord contacts, the domestic socket or the vehicle charging socket, or introduce objects into them.

Never plug the charging cord into an adapter, multiple socket or extension lead.

The use of generators is prohibited.

Do not remove or change the vehicle charging socket or the charging cord. Fire hazard.

Do not modify or perform any action on the installation during charging.

In the event of an impact, even slight, against the charging flap or valve, have them checked by an authorised dealer as soon as possible.

Take care of the lead: do not tread on it, immerse it in water, pull on it or let anything knock against it.

Check regularly that the charging lead is in good condition.

In the event of damage to the charging lead (corrosion, browning, cuts, etc.), to the unit or to the vehicle's electrical charging socket, do not use them. Please see an authorised dealer to replace them.

In the event of non-activation of the charging flap locking mechanism and/or unlocking of the vehicle's electric charging socket, please contact an approved dealer.

# ELECTRIC VEHICLE


## Charging lead A

47303



This lead is specific to your vehicle and designed for connecting to wall sockets or public terminals to enable standard charging of the traction battery.

## Charging lead B




This lead can be used for:

- in normal use, on a socket used only for the vehicle (14 A/16 A charging);
- occasional charge using a domestic socket, (8 A charge) when you are not at home, for example.

In all cases, sockets must be fitted as stated in the instructions provided with the charging lead **B**.

35906



34577

In all cases, read the charging lead **B** user instructions **carefully**.

**i** Never leave the socket hanging by the cord. Use the hooks **C** to hang it.

**i** If a malfunction occurs during the charging process (red warning light appears on the unit **D**), stop charging immediately. Please refer to cord instructions.

2

## ELECTRIC VEHICLE

2



We recommend that you use a charging cord that enables a standard charge to charge the traction battery.



Before cleaning the charging lead, make sure the lead is disconnected.

Clean the cable using a cloth slightly dampened with water. When cleaning, make sure that the cloth does not come into contact with the ends of the cable (connectors, charging pins) to avoid any risk of corrosion.



Each charging lead is stored in the luggage compartment of the vehicle

→ 67.

## Important recommendations



### **Important recommendations for charging your vehicle**

Please read these instructions carefully. Failure to follow these instructions may lead to **a risk of fire, serious injury or electric shocks which could result in death.**

#### **Choice of charging cord**

The standard charging cords supplied with the vehicle have been designed specifically for this vehicle. It is designed to protect you against the risks of electric shock that can lead to death or fire.

Do not use with the charging leads of previous vehicles as they are not adapted.

For safety reasons, the use of a charging cord not recommended by the manufacturer is strictly forbidden. Failure to follow this instruction can lead to risks of fire or electric shock that can prove fatal. For information on a charging cord suited to your vehicle, please consult an authorised dealer.

#### **Using the charging lead *B***

Please read the instructions that come with the charging lead carefully to learn about the precautions you must take when using the product and the technical specifications required for fitting the socket.

#### **Installation**

##### **Wall socket**

Have a special wall socket installed by a qualified professional.

##### **In the case of domestic charging**

Have a qualified professional check that each socket to which you will connect the charging cable complies with the standards and regulations in force in your country and that it complies with the specifications described in the information on "Power supply systems".

##### **Power supply systems**

Only use charging terminals which conform to the IEC 61851-1 standard and connecting points protected by:


- a Type A 30 mA residual current device specific to the socket used;
- an overcurrent protection device;
- protection against overvoltage relating to lightning in exposed areas (IEC 62305-4);
- an earth connection that complies with the standards in the relevant country.

# ELECTRIC VEHICLE



Charging types that conform to European standards

2

Alternating current (AC)



62364



If the information is displayed on the vehicle charging flap, follow the instructions below.

Before plugging in a charging lead, check that:

- the colour and one of the letters of the input socket **1** correspond to the colour and one of the letters on the end **4** of the lead;
- the colour and one of the letters of the input socket **3** correspond to the colour and one of the letters on the end **5** of the lead.

# ELECTRIC VEHICLE

## Labels

<b>Charging type</b>	<b>Alternating current (AC)</b>			
<b>Connection</b>	<b>Charging terminal 1 /Charging cable 4</b>		<b>Vehicle 3 /Charging cable 5</b>	
<b>Charging types that conform to European standards</b> (for all other cases, please consult an approved dealer).				



2

# ELECTRIC VEHICLE

## Direct current (DC)

2

62378



If the information is displayed on the vehicle charging flap, follow the instructions below.

Before plugging in a charging lead, make sure that the colour and one of the letters on the inlet socket **3** correspond to the colour and one of the letters on the end **5** of the charging lead.

# ELECTRIC VEHICLE


## Labels

<b>Charging type</b>	<b>Direct current (DC)</b>				
<b>Connection</b>	<b>Vehicle 3 /Charging cable 5</b>				
<b>Charging types that conform to European standards</b> (for all other cases, please consult an approved dealer).					

2

# ELECTRIC VEHICLE

## Electric charging socket 3



**Note:** if in a snowy environment, remove snow from the area around the vehicle charging socket before plugging in or disconnecting.

Snow in the socket may block the insertion of the charging cord plug.

The vehicle is equipped with two charging connections located at the front of the vehicle:

- socket **E** for charging up to 11 kW;
- socket **F**, depending on the vehicle, in addition to socket **E**, for fast charging.

There are also two buttons located inside the charging flap:

– the button **6**  unlocks the charging cable;

– the button **7**  launches immediate charging of the vehicle.

### Precautions

For daily use, it is recommended that you charge your vehicle to 80% to improve the battery service life.

Avoid charging and parking your vehicle in extreme temperatures (hot or cold).

Under extreme conditions, charging may take several minutes before starting (time required for the traction battery to cool down or warm up).

When the vehicle is parked for more than seven days in temperatures below approximately  $-25^{\circ}\text{C}$ , charging the traction battery can become impossible.

When the vehicle is parked for more than three months with near zero charge, charging the battery can become impossible.

The energy level available depends on the battery temperature. It may therefore vary between stopping and restarting the vehicle if the battery is cold or warm.

To preserve the service life of your traction battery, avoid parking the vehi-

cle for more than one month with high charge, especially when the weather is very hot.

Favour charging the traction battery after driving and/or in mild temperatures. Otherwise, charging may take a longer period of time or even become impossible.

It is preferable to recharge the vehicle after driving if the charge level is low ( $< 25\%$ ) and in negative temperatures.

### Advice

- In high temperatures, try to park and recharge the vehicle in a shaded/sheltered location;
- charging can be performed in the rain or snow;
- activating the air-conditioning increases the charging time required.


## Recharging the traction battery

### Vehicle stationary, ignition off:

- take the charging cable **2** located in the storage compartment in your vehicle's luggage compartment;
- press the charging flap **8** to unlock it. The warning light **9** illuminates in white;

## ELECTRIC VEHICLE

**i** Depending on the vehicle, when the charging flap is open or not properly closed, the "Charging flap opened" message appears on the instrument panel.



- plug in the end of the lead to the power supply;
- grab the handle **10**;
- plug in the vehicle cord. The indicator light **9** flashes in yellow;

**i** Do not use the charging flap **8** to hang the charging cable **2** while recharging the vehicle.

**i** If you have just accepted a system update via the multimedia system, the traction battery charging will be delayed or cancelled. Wait for the update to be completed before connecting the charging lead to the vehicle. For more information on system updates, please refer to the multimedia instructions.

- after you hear a locking click, check that the charging cord is properly plugged in. To check the locking, pull gently on the handle **10**;
- if you have programmed a deferred charge and you wish to start charging immediately, press the button **7** to start charging → **291**.

The charging cord is automatically locked with the vehicle. This will make it impossible to unplug the cord from your vehicle.

**i** Make sure you fully uncoil the charging cord to limit its heating.



Do not use an extension lead, multiple socket or adapter.  
**Fire hazard.**

During charging, the indicator light **9** flashes in blue.



When charging starts, the following information is displayed on the instrument panel:

## ELECTRIC VEHICLE

2

- the energy level on the battery indicator light **12**;
- the battery charge level;
- an estimate of the remaining charging time (this is not displayed after the battery is charged to approximately 95%);
- the indicator light **11** indicates that the vehicle is connected to a power supply;
- your vehicle range will vary according to the charge level.

The display on the instrument panel disappears after a few seconds. It reappears on the instrument panel when a door is opened.

One charging is complete, the indicator light **9** is displayed in green.

You do not need to wait until the charge is at reserve levels to recharge your vehicle.

 The traction battery charging time depends on the amount of energy remaining and the power delivered by the charging terminal. The information is displayed on the instrument panel during charging → **125**.


**Note:** under certain conditions, the actual charging time may be longer than the charging time displayed on the instrument panel. This depends on:

- the quality of the electrical network;
- the initial charge level;
- the exterior temperature is too cold;
- ...

In the event of a problem with the charging cable, we recommend that you replace it with a cable that is identical to the original. Consult an approved Dealer.

### Operating faults

If the warning light **9** is illuminated continuously in red, please contact an approved dealer.



### Precautions to take when removing from the socket

- Press the button **6** or **press and hold** the door unlocking button on the card in order to unlock the vehicle charging cable;
- grab the handle **10**;

 It is imperative to follow the unplugging steps in order.

- disconnect the charging cable **2** from the vehicle;
- you must close the charging flap **8** and press on it to lock it;
- disconnect the cable **2** from the power supply **1**;

## ELECTRIC VEHICLE



– store the cable **2** in the storage compartment of your luggage compartment.

**Note:** immediately after a long period of charging the traction battery, the lead may be hot. Please use the handles.



After pressing the charging cable release button, you will have around 30 seconds to unplug it before it is locked once again.

### Label 13



The label **13** located on the charging flap **8** details the charging operation according to the status of the indicator light **9**:

- when it flashes in white this indicates that the lead is plugged into the vehicle and the system is carrying out its checks;
- when it lights up continuously in blue this indicates that charging programming is activated;
- when it flashes in blue this indicates that charging is in progress;
- when it lights up continuously in green this indicates that the vehicle is fully charged;
- flashes in green: when Vehicle to Grid (V2G) → **44** or Vehicle to Load (V2L) → **45** is enabled;

– when it flashes in red this indicates an operating fault.

The label **13** located on the right-hand side reminds you of the following instructions:

- do not wash the charging flap using a high-pressure water jet;
- with the vehicle stationary, the valve and the charging flap can be opened;
- when the vehicle is being driven, the valve and the charging flap must be closed;
- open the flap to connect the charging lead;
- close the flap again once disconnected;
- connect to a domestic socket, an alternating current charging terminal or a quick charging terminal;
- for any information on charging, please consult your vehicle user manual.

# ELECTRIC VEHICLE

## Charging programming

### Operation

2



With the vehicle stationary and the engine running, from the "Vehicle" world **3** on the multimedia screen **1**, press the "Electric" menu **2** then the "Charge & Climate" tab to set up charging for your vehicle.

You can choose from several charging modes:

- « Instant charge » ;
- "Scheduled charging";
- "V2G charging".

Please refer to the multimedia instructions for further information.



For safety reasons, carry out these operations when the vehicle is stationary.

When the programming is confirmed,

the indicator light  lights up on the instrument panel.

**Note:** charging will start if the engine is switched off, the vehicle is connected to a power supply and access is authorised.



If you have just accepted a system update via the multimedia system, the traction battery charging will be delayed or cancelled.

Wait for the update to be completed before connecting the charging lead to the vehicle.

For more information on system updates, please refer to the multimedia instructions.

### Vehicle to Grid (V2G) charging

With your vehicle stationary and connected using your vehicle's charging cable, the Vehicle to Grid (V2G) charging allows you to redistribute the energy stored in your vehicle's battery to your home and to the power grid.

You must have a compatible two-way AC charging terminal and have subscribed to the V2G charging service. Please refer to the multimedia instructions for further information.

# ELECTRIC VEHICLE



Disconnect your vehicle before carrying out any work or modification on the electrical installation.



To set up V2G charging, refer to the multimedia user manual.

## Vehicle to Load (V2L) function

With the vehicle stationary and the parking brake applied, the "Vehicle to Load" (V2L) function allows you to connect electrical devices directly to the vehicle.

The system provides AC power (up to 16 A/3.7 kW) using electrical energy stored in your vehicle's traction battery  
➔ 20.

The V2L connector enables you to connect and operate various electrical devices using the charging socket at the front of your vehicle.

## Important recommendations

2



Please read these instructions carefully. Failure to follow these instructions may lead to **a risk of fire, serious injury or electric shocks which could result in death.**

### **Precautions to be taken when using the V2L function.**

Do not attempt to power your home as this can lead to damage and electric shocks.

Do not wash the vehicle or work in the engine compartment while using the V2L function.

Do not use the V2L function:

- if there is water in the V2L connector or in the vehicle's charging socket;
- if the vehicle's V2L connector or charging input socket is damaged (broken, signs of corrosion, discolouring, etc.), contact an approved dealer to organise a replacement;
- outdoors, if the weather conditions are unsuitable (rain, risk of lightning, etc.).

Do not place metal objects on the V2L connector.

Do not modify or interfere with the V2L connector while using the V2L function.

Never connect an adapter to the V2L connector.

### **Precautions to be taken when handling and using the V2L connector.**

Use only the V2L connector supplied with the vehicle. The V2L connector has been designed specifically for this vehicle.

For your safety, the use of a V2L connector not recommended by the manufacturer is strictly prohibited. For more information on which V2L connector is right for your vehicle, consult an approved dealer.

Do not rest any objects against the V2L connector and do not hang devices by their power cable from the AC output socket of the V2L connector. **Risk of damage.**

Take care of the V2L connector. Do not disassemble it, immerse it in water or pull on it while it is connected and do not let anything knock against it. Regularly check the condition of the connector before use.

### **Precautions to be taken when using electrical/electronic devices.**

Before plugging in and using a device (extension cable, multi-plugs, etc.), check the precautions for use by referring to its user manual.

Do not plug in:


- devices that require a direct current, such as medical equipment. The power supply may be interrupted depending on the vehicle operating conditions;

## ELECTRIC VEHICLE

- devices that consume more than 16 A;
- devices that do not comply with national regulations and standards;
- damaged devices (units, cables, etc.);
- devices whose initial recommendations for use are not adapted to the environment in which they will be used (risks related to contact with dust and water);
- more than one multi-plug. When in use, do not connect products that consume more than 8 A;
- an extension lead more than 20 m long. If used, be sure to unwind it completely.

# ELECTRIC VEHICLE

## Vehicle to Load (V2L) connector A



- 1 Charging socket;
- 2 Operation warning light;
- 3 On/Off switch;
- 4 Protective cover;
- 5 AC output socket.

The V2L connector is stored in the toolkit located underneath the luggage compartment carpet.

 Before carrying out maintenance on the V2L connector, make sure the connector is disconnected.

Clean the connector using a cloth slightly dampened with water. When cleaning, make sure that the cloth does not come into contact with the ends of the connector (connectors, charging pins) to avoid any risk of corrosion.

### Operation




Ensure that the parking brake is always applied when the V2L function is in use.

 You must observe the order in which the V2L connector is connected/disconnected.


 Before connecting or disconnecting a device, make sure that the V2L connector indicator light 2 is off.

### To connect the V2L connector

With the vehicle stationary, the opening elements unlocked and the ignition off:




# ELECTRIC VEHICLE



- press the charging flap **9** to unlock it;
- hold the handle of the connector **8** and connect the end piece **1** of the connector to the vehicle charging socket **7**;
- check that the V2L connector is correctly connected by pulling lightly on the handle **8**. Before the discharge begins, the socket lock is activated. The V2L connector is automatically locked to the vehicle. This makes it impossible to disconnect the connector from the vehicle;
- connect the electrical device to the V2L connector AC output socket **5**;
- press the V2L connector switch **3** for at least three seconds until the indicator light **2** appears in green. The V2L

function is activated, the indicator light on the charging socket **10** flashes in green and the electrical device is supplied with power.

**Note:** do not pull the handle **8** while the V2L connector is being locked to the vehicle.



When in use, the following information is displayed on the instrument panel:


- the indicator light **11** to indicate that the vehicle is connected to the V2L connector;
- the estimated time **12** remaining before the minimum battery charging threshold is reached;
- the battery energy level **13**.

**Note:** the power supply automatically shuts off when:

- the V2L function is not used for about an hour (no electrical devices connected to the AC socket **5** of the V2L connector or no power consumption);
- an electrical device exceeding the maximum power capacity is connected;
- the opening elements have been previously locked, the driver's door is unlocked;
- the minimum charging threshold of the traction battery set from the multimedia display is reached.

When the power supply is cut off, a message will appear on the instrument panel to inform you.

## To disconnect the V2L connector



## ELECTRIC VEHICLE

With the card on you or the vehicle opening elements unlocked:

- press the button **6**  located next to the charging socket to stop the discharging. The indicator light **2** goes out, the indicator light on the charging socket **10** goes out and the V2L function is deactivated;
- the V2L connector is automatically unlocked with the vehicle. This enables the connector to be disconnected from your vehicle;
- disconnect your electrical device and hold the handle **8** of the V2L connector to disconnect it from the vehicle **within approximately 15 seconds**. Otherwise, the charging socket **7** will be locked again automatically;
- close the charging flap **9** and press on it to lock it;
- place the V2L connector in its storage area.



Do not drive the vehicle while the charging flap **9** is open. Once the V2L connector is disconnected from the vehicle, make sure that the charging flap **9** is properly closed.

### Settings



You can set the minimum charge threshold level of the traction battery from the multimedia screen **12**.

Please refer to the multimedia instructions for further information.

### Operating faults

In the event of an operating malfunction, the indicator light **2** on the V2L connector will go out and the V2L (discharge) power supply will switch off automatically. A message is displayed on the instrument panel to inform you.

**In the event of an internal failure of the V2L function**, the "V2L discharge impossible V2L to check" message will

be displayed on the instrument panel: disconnect the electrical device and disconnect the V2L connector. Consult an approved dealer.


**In the event of a failure of the V2L function from the device connected to the AC socket of the V2L connector**, the "V2L discharge impossible Connected device fault" message is displayed on the instrument panel:

- disconnect the electrical device and the V2L connector;
- check that the device and V2L connector are not damaged and that the power supply plug is not broken or corroded;
- make sure that the electrical device does not exceed the maximum capacity of power that the vehicle can provide.

If there is still a problem, contact an approved dealer.

# CARD

## General information



1. Unlocking the doors and luggage compartment.
2. Locks all the opening elements.
3. Unlocking/locking the boot.
4. Switching on the lighting remotely.

### The card is used for:

- locking/unlocking the opening elements (doors, luggage compartment door);
- unlocking the charging flap → 20;
- switching on the vehicle lighting remotely;
- automatic remote opening/closing of the electric windows → 64.

 Depending on the vehicle, you may have a digital key that offers all the functions of the card. However, if a card has been left inside the vehicle and the doors have been locked with a digital key, all of the card's functions will be inhibited. For further information, please see the "Digital key" section → 59.

## Range

Make sure that the correct battery type is being used, and that the battery is in good condition and inserted correctly. Its service life is approximately two years: it should be replaced when the "Keycard Battery Low" message appears on the instrument panel → 51.

## card operating range

This varies according to the surroundings: take care not to accidentally lock or unlock the vehicle by inadvertently pressing the buttons on the card.

**Note:** if a door or the luggage compartment door is open or not properly shut, the vehicle will not be locked. A beep sounds and the hazard warning lights and side repeaters do not flash.

 If the battery is flat, you can still lock/unlock and start your vehicle → 153 → 64 → 51.

## "Remote lighting" function



Press button 4 to switch on the dipped beam headlights and the exterior lighting for approximately 20 seconds. This can be used, for example, to identify the vehicle from a distance when parked in a car park. Press and hold button 4 for approximately two seconds to switch on the exterior lighting and emit a sound.

## CARD

**Note:** press button **4** again to switch off the lighting.



### Recommendations

Avoid leaving the card in hot, cold or humid areas.

Do not keep the card in a place where it could be bent or damaged accidentally, such as in a back pocket of a garment where it might be sat on.



### Replacement: need for an additional card

If you lose your card or require another, you can obtain one from an approved dealer.

If a card is replaced, it will be necessary to take the vehicle **and all its cards** to an approved Dealer to initialise the system.

You may use up to four cards per vehicle.

### Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the remote control)

may affect the operation of the remote control.



### Driver's responsibility when parking or stopping the vehicle


Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.


Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

### Fitting a strap 7



Slide the rear casing **5** downwards while pressing on area **A**.



## CARD

Insert the strap into the component **8** and pass the end of the hand strap through the buckle.

Position the strap at the opening **6** and close the casing.

**Note:** check that the diameter of the strap cord **7** fits the opening **6**.

### "Hands-free" card

#### Use

There are two ways to unlock/lock the vehicle:

- in "hands-free" mode, when approaching and moving away from the vehicle;
- using the card in remote control mode.



Do not store the card anywhere it may come into contact with other electronic equipment (computer, phone etc.) as this could hinder its operation.

#### Deactivating/activating the "hands-free" mode

Depending on the vehicle, you can deactivate/activate unlocking when ap-

proaching and locking when moving away from the vehicle.

You can also deactivate/activate the sound signal that is emitted upon locking when moving away from the vehicle → **128**.



Never leave your vehicle with the card inside.



#### Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

### "Hands-free" unlocking when approaching the vehicle



If you are holding the card and in the access zone **1** the vehicle will be unlocked.

To indicate that the doors have unlocked, **the hazard warning lights and indicator lights flash once** and, depending on the vehicle, the door mirrors fold out automatically.

## CARD

"Hands-free" locking when moving away from the vehicle


2



67199

With the card on you and the doors and luggage compartment door closed, move away from the vehicle: it will be locked automatically as soon as you leave the access zone **1**. To indicate that the doors have locked, **the hazard warning lights flash once then stay on** for about four seconds, a beep sounds and, on some vehicles, the door mirrors fold in automatically.

**Note:** the distance at which the vehicle locks depends on the surroundings.



62017

If the card has been within the detection zone **1** for approximately 15 minutes, remote locking is deactivated. To lock the vehicle, press the button **3** on the card.

The vehicle cannot be remotely locked if the card is within the zone **2**.

"Hands-free" unlocking by opening the luggage compartment



66317

With the card in the zone **1** and the vehicle locked, press button **4** once to unlock the entire vehicle.

Unlocking is indicated by **one flash** of the hazard warning lights and the indicator lights.

### Special features of the unlocking system

Under certain circumstances, unlocking when approaching the vehicle is deactivated:

- if the vehicle has not been used for eight days;

## CARD

- if the card remains close to vehicle zone **1** during approximately five minutes **after the vehicle has been locked**;
- after several passes in the vicinity of zone **1** **without the doors having been unlocked**.


Press the luggage compartment door opening button **4** or use the card as a remote control to unlock the vehicle and reactivate "hands-free" mode.

### Special features relating to "hands-free" locking

After locking in "hands-free" mode, you have to wait approximately three seconds to be able to unlock the vehicle again. During these three seconds, the door handles can be tried to make sure that the vehicle is locked properly.

**Note:** if a door or the luggage compartment door is open or not properly shut, the vehicle will not be locked. A beep sounds but the hazard warning lights and side repeaters do not flash.

### Using the card as a remote control



### Unlocking with the card

Press the button **5**.

Unlocking is indicated by **one flash** of the hazard warning lights and the indicator lights.



The card buttons are deactivated when the engine is running.

### Locking using the card

With the doors and luggage compartment door closed, press button **3**: the vehicle will be locked.

The hazard warning lights **flash twice** to indicate that the vehicle is locked and, depending on the vehicle, the door mirrors automatically fold in.

Depending on the vehicle, press button **3** twice to lock the vehicle. Press and hold button **3** to close the front and rear windows.

### Note:

- the maximum distance at which the vehicle locks depends on the surroundings;
- if a door or the boot is open or not properly shut, locking is not carried out. A beep sounds but the hazard warning lights and side repeaters do not flash.




## CARD

**While the engine is running**, if the card is no longer in zone **2** after a door is opened and closed, the "Keycard Not Detected" message indicates that the card is no longer inside the vehicle. This will, for example, prevent you from driving away after dropping off a passenger who has kept the card on them.

The warning disappears when the card is detected again.

### Locking/unlocking the boot only



Press button **6** to lock/unlock the luggage compartment only.



### Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

### Unlocking the charging cable

Press button **5** to unlock the vehicle charging cable.

### Deadlocking


#### Use

If the vehicle is equipped with a deadlocking function, this allows you to lock the opening elements and to prevent the doors from being unlocked using

the interior handles (for example, by breaking the window and then trying to open the door from the inside).



Never use deadlocking if someone is still inside the vehicle.



### To activate deadlocking

Press button **2** twice in quick succession.

Locking is confirmed by **two slow flashes and three quick flashes** of the hazard warning lights and side repeaters.

## CARD

Depending on the vehicle, the door mirrors may fold in automatically when the vehicle is locked ➔ 137.


### To deactivate deadlocking

Press the button **1** once.

The hazard warning lights **flash once** to indicate that the doors have been unlocked.

### "Hands-free" card: battery

#### Replacing the battery



When the "Keycard Battery Low" message appears on the instrument panel, replace the card battery:

- slide the rear casing **1** downwards while pressing on area **A**;
- remove the battery cover **2**;
- remove the battery by pressing on one side and lifting the other;
- replace it according to the direction and template indicated inside the cover.



To refit, proceed in the reverse order then press one of the buttons on the card four times while you are near the vehicle: the next time the vehicle is started, the message will disappear.

Check that the cover is clipped shut.

**Note:** when replacing the battery, do not touch the electronic circuit or contacts on the card.



The batteries are available from approved Dealers, and their service life approximately two years. Check that there is no dye on the battery: risk of an incorrect electrical contact.



If they need to be replaced, be sure to use the same or equivalent type of battery (consult an Approved Dealer).



When replacing:  
– make sure that the batteries are correctly inserted.

#### **Risk of explosion.**

– if the flap does not close correctly, do not use the card and keep out of reach of children.

## CARD

### Operating faults

If the battery is too weak to ensure correct operation, you will still be able to start and lock/unlock the vehicle → 64.



61496



Do not throw away your used batteries as rubbish. Take them to an approved Dealer or consult your local authority for information on appropriate recycling facilities.



#### **Precautions relating to batteries:**

- keep batteries (new or used) out of reach of children;
- do not swallow batteries;

#### **Risk of chemical burns which may lead to death**

- if ingested or inserted into any part of the body, consult a doctor as soon as possible.

# DIGITAL KEY

## General information

Depending on the country and subscription, you can install a digital key for your vehicle on your smartphone.

The digital key contains the rights required to lock/unlock and start your vehicle using a smartphone. Thus, your smartphone replaces your card.

The installation, administration and transmission of the digital keys are carried out using the manufacturer's app.

Once the manufacturer's application is installed on your smartphone and the subscription is activated, the digital key must be activated from the manufacturer's application.

 If you need to entrust your vehicle to somebody else, make sure you have the vehicle card with you to guarantee access to the vehicle (e.g. in the context of an intervention on the vehicle, an appointment with an approved dealer or a qualified professional, etc.).

### **Secure access to the digital key on the smartphone**

It is the responsibility of the owner of the digital key and the designated users to protect and secure access to the digital key on the smartphone.

Make sure that you install the necessary security and protection tools on your smartphone (such as securing the screen with a password).

## Operating conditions

Activate Bluetooth® on your smartphone then open the manufacturer's application to access the various digital key functions.

**Note:** the smartphone must be sufficiently charged in order to use a digital key. In the event of a low charge level, the "Low phone battery" message appears on the instrument panel.

 The digital key's operational reach will depend on your smartphone's Bluetooth® connection.

## Lending a digital key

From the manufacturer's app, access the "Share Virtual Key " menu and fill in the information for the occasional user. After validation, a confirmation email will be sent to the user.

 In the event of vehicle lending, the owner of the digital key is responsible for designating a trusted person as another user of the vehicle.

To avoid any error in the transmission of a digital key to an occasional user (for example: lack of WIFI or mobile network, etc.), be sure to anticipate the lending procedure.

To do this, make sure that:

- the manufacturer's application has previously been downloaded and installed by the occasional user;
- your smartphone and the occasional user's smartphone are connected to

## DIGITAL KEY

the internet throughout the procedure (via WIFI or mobile networks);

– the occasional user's digital key is activated once the procedure is completed.

### Revoking a digital key

The user can individually revoke a digital key. Once a digital key has been revoked, the user can activate a new key.

For more information, please see the manufacturer's application.

### Activation/deactivation from the multimedia screen

It is possible to deactivate and reactivate the "Digital key" function so that the vehicle does not communicate with any digital key. Refer to the multimedia instructions.

**Note:** deactivating the function will not delete existing digital keys. It only deactivates the vehicle's capacity to communicate with them.

### Locking/unlocking the doors and luggage compartment, deadlocking, remote lighting

The first time the vehicle is unlocked or started using a new digital key or a new smartphone, it will take several

seconds for the vehicle to identify the digital key installed on your smartphone.

From your smartphone, with Bluetooth® activated, open the manufacturer's application and discover the various functions available for your digital key. They are identical to those of your card.

### Special features related to unlocking the opening elements

Under certain circumstances (e.g. after eight days of the vehicle not being used), it is not possible to unlock the vehicle using a digital key: press the luggage compartment opening button then unlock your vehicle using your digital key.

These functions are:

- locking/unlocking all the opening elements: please see "Hands-free card: use" → 53;
- locking/unlocking the luggage compartment (depending on the vehicle): please see "Hands-free card: use" → 53;
- deadlocking (depending on the vehicle): please see "Hands-free card: deadlocking" → 56;
- remote lighting: please see the information on the "Remote lighting" function → 51;
- remote sounding of the horn (allows you to identify the vehicle from afar or

when parked in a crowded car park, for example);

– starting/stopping the engine: please see "Starting, stopping the engine" → 153.

### Starting, stopping the engine



Upon first use and each time a new smartphone is used, it is necessary to calibrate your digital key with your vehicle.

To do this, activate Bluetooth® on your smartphone then follow the procedure from the manufacturer's application.

When calibrating, the smartphone must be placed in the placement area 1.

## DIGITAL KEY

To start/stop the engine, the system checks that the smartphone is present in the placement area **1** before allowing the engine to be started.

For more information, please refer to the information on "Starting, stopping the engine" ➔ **153**.

The smartphone must remain in the vehicle throughout the journey.

**Note:** if a digital key is being lent, you can delete it by carrying out the revoking procedure using the smartphone while it is placed in the placement area **1**.

Otherwise, the deletion request is left pending and is only confirmed once the engine is started using another digital key or a card.



It is necessary to place the smartphone in the placement area in order to start and stop the engine and when calibrating.



If the smartphone is no longer in the passenger compartment when you try to switch the engine off, a message is displayed on the instrument panel: press and hold the engine start/stop button **2** for more than two seconds.

If the smartphone is no longer in the passenger compartment, make sure you can retrieve it before pressing and holding. Without a smartphone or card, you will not be able to start the vehicle again.

### Special features of the digital key

– For the digital key to remain active, the smartphone concerned must be connected to the Internet (via WIFI or

mobile network) at least once every 48 hours. Otherwise, connect your smartphone to the internet for a few minutes so that the digital key can be reactivated.

– If a card has been left inside the vehicle and the doors have been locked with the digital key, all of the card's functions will be inhibited. The card's functions will remain inactive until the engine is started again.

In this case, to start the engine you will need to use either the digital key or a card other than that left inside the vehicle.



When the engine is started or stopped, the smartphone should always be sufficiently charged in order to use the digital key.

## DOORS AND OPENING ELEMENTS

### Opening and closing the doors

2

#### Opening from the outside

##### Front doors



With the doors unlocked or the card on you, hold the handle **1** and pull it towards you.

##### Rear doors



With the doors unlocked or the card on you, hold the handle **2** and pull it towards you.



As a safety precaution, the doors should only be opened/closed when the vehicle is stationary.

### Opening from the inside



Pull the handle **3**.



As a safety precaution, the doors should only be opened/closed when the vehicle is stationary.

### Lights-on reminder audible alarm

If you have switched off the ignition and left the lights switched on, a warning buzzer will sound when a door is opened.

## DOORS AND OPENING ELEMENTS

### Door or luggage compartment lid open buzzer




With the vehicle stationary and the ignition switched on, the  warning light **4** on the instrument panel indicates whether the opening element(s) (door, luggage compartment or charging flap) are open or incorrectly closed. When the vehicle reaches approximately 12 mph (20 km/h), the  warning light **4** indicates which door(s) are open or incorrectly closed, accompanied by the "WARNING: Door Open" message **5**.

### Special feature

Once the engine has been switched off, the lights and accessories (radio, etc.) will continue to operate until the driver's door is opened.

### Child safety



To make it impossible for the rear doors to be opened from the inside, lower the lever **6** and check from the inside that the doors are securely locked.

## DOORS AND OPENING ELEMENTS

2



### Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

## Locking, unlocking the opening elements and doors

### If the card does not work:

In certain cases, the card may not work:

- when the card battery is worn, the battery is flat, etc;
- due to the use of electronic devices near to the remote control (e.g. mobile telephone);

- the vehicle is located in a high electromagnetic radiation zone;
- vehicle locked using a digital key → 59.

It is then possible:


- to use the key that is built into the card;
- to lock each of the doors manually;
- to use the interior door locking/unlocking control;
- to use the digital key → 59, depending on the vehicle.

### The card's built-in key



The built-in key 2 is used to lock or unlock the front left-hand door if the card is not working.


### Access with key 2



Slide the rear casing 1 downwards while pressing on area A.

## DOORS AND OPENING ELEMENTS

### Using the key integrated in the card



- Insert the end of the key **2** into the notch **3** at the bottom of the cover **B** on the driver's door;
- move it upwards to remove the cover **B**;
- Insert key **2** into the lock and lock or unlock the driver's door.

Once you are inside the vehicle, put the key back in its casing in the card.

### Locking the doors manually



With the door open, turn the screw **4** (using the end of the key) and close the door.

This means that the door is then locked from the outside.

The doors may then only be opened from the inside or by using the key in the driver's door.

### Interior locking/unlocking door control



The switch **5** simultaneously controls the doors and the luggage compartment door.

If a door or the tailgate is open or not closed properly, the doors and tailgate lock/unlock quickly.

If transporting an object with the luggage compartment door open, you can still lock the doors: **with the ignition off**, press and hold the switch **5** for more than five seconds to lock the other opening elements.

## DOORS AND OPENING ELEMENTS

### Door and tailgate status indicator

**With the ignition on**, the switch **5** indicator light indicates the locking status of the opening elements:

- when the warning light is on, the doors and luggage compartment door are locked;
- indicator light off, the doors and tailgate are unlocked.

**If the ignition is off**, when you lock the doors the warning light remains lit for some time before disappearing.



After locking/unlocking the vehicle using the buttons on the card, the remote locking and "hands-free" unlocking modes are deactivated. To reactivate the "hands-free" mode, restart the vehicle.

### Locking the doors without the card

For example, in the event of a discharged battery or the card temporarily not working, etc.

**With the ignition switched off and a door or the luggage compartment door open**, press and hold the switch **5** for more than five seconds.

When the door is closed, all the doors and tailgate will be locked.

**Note:** unlocking the vehicle from the outside is only possible while the card is in the vehicle's access zone or using the key that is built into the card.



Never leave your vehicle with the card inside.



#### Driver's responsibility

If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.

### Automatic locking when driving

#### Operating principle



After the vehicle is started, the system automatically locks the doors when you reach approximately 6 mph (10 km/h).

The door can be unlocked:

- by pressing the door unlocking switch **1**;
- at a standstill, by opening a front door from inside the vehicle.

**Note:** if a door is opened/closed, it will automatically lock again when the vehicle reaches a speed of approximately 6 mph (10 km/h).

## DOORS AND OPENING ELEMENTS

### Activating/deactivating the function

**To activate it:** with the vehicle stationary and the engine running, press switch **1** for at least five seconds until you hear a beep.

**To deactivate it:** with the vehicle stationary and the engine running, press switch **1** for at least five seconds until you hear two beeps.

The function can also be activated and deactivated via the multimedia screen → **128** (depending on the vehicle).

### Operating faults

If you experience an operating fault (no automatic locking, the switch indicator light **1** does not light up when trying to lock the doors and luggage compartment, etc.), make sure that automatic locking has not been deactivated by mistake and check that all of the opening elements are properly closed. If they are properly closed, contact an approved dealer.



#### Driver's responsibility

If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.

### Luggage compartment

#### Opening/Closing

##### Opening



Press button **1** and open the luggage compartment door.

#### Closing

Lower the luggage compartment lid, depending on the vehicle, initially using the inside handle to assist you.



**Never use the struts to close the luggage compartment door.**

#### Opening manually from inside the vehicle



## DOORS AND OPENING ELEMENTS

If it is impossible to unlock the luggage compartment, it can be done manually from inside:

- access the luggage compartment by folding down the rear bench seatback(s);
- insert a flat-blade screwdriver or similar tool into the emergency release lever **2** and slide it to the left as shown in the illustration;
- push the boot lid to open it.



The attaching of any carrying device (bike rack, luggage box, etc.) resting on the luggage compartment lid is prohibited. To install a carrying device on your vehicle, contact an approved dealer.

### Charging lead storage tray



Depending on the vehicle, this tray is intended to store charging cables. The maximum permissible load per tray is 10 kg.

To access it, open the luggage compartment, then raise the luggage compartment carpet using the handle **3**.



If there is water in the charging lead storage tray, signs of corrosion or foreign bodies in the charging lead connector or in the vehicle charging socket, do not charge the vehicle.

#### **Fire hazard.**

Take care of the lead: do not tread on it, immerse it in water, pull on it or let anything knock against it.

Check and clean the storage tray regularly.

## DOORS AND OPENING ELEMENTS

### Rear parcel shelf



To remove it:

- lower the rear headrests;
- unhook the two suspension cords **4**;
- lift the shelf **5** to unclip it;



Maximum weight on the rear parcel shelf: 2 kg evenly distributed.

- push the shelf **5** inwards and turn it;
- pull the shelf towards you.

To refit, proceed in the reverse order to removal.




Do not place any objects, especially heavy or hard objects, on the parcel shelf.

These may pose a risk to the vehicle occupants if the driver has to brake suddenly or if the vehicle is involved in an accident.

## FRONT SEATS

### Front headrests

#### 2 To raise the headrest



Pull the headrest upwards to the desired height. Check that it is correctly locked.

#### To lower the headrest

Press the button **2** and guide the headrest down to the desired height. Check that it is correctly locked.


#### To remove the headrest

Raise it to its highest position (tilt the seatback backwards). Press the button **2** and lift the headrest to release it.

#### To refit the headrest

Check that the headrest rods are clean **3**.

Insert the headrest rods into the holes **1** (tilt the seatback backwards). Lower the headrest until it locks and press button **2** to adjust to the desired height. Check that each rod **3** is locked on the seatback.



61287



The headrest is an important safety component: ensure that it is in place and in the correct position. The top of your head should be in line with the top of the headrest. The distance between your head and section **A** should be as short as possible.

### Front seats

#### Front seats with manual control

#### To move the seat forwards or back



## FRONT SEATS

Raise the handle **1** to unlock. Release the handle at the desired position and make sure that it is locked.

### Adjusting the lumbar support on the driver's seat

Push the switch **2** forwards or backwards to adjust the lumbar pad.

### To raise or lower the seat base

Move the lever **3** as many times as necessary upwards or downwards.

### To tilt the seatback

Raise the handle **4** as far as possible and tilt the seatback to the desired position. Release the handle at the desired position and make sure that it is locked.



After making adjustments, make sure that the seatbacks are correctly locked in place.



For safety reasons, carry out any adjustments while the vehicle is stationary.

We would advise you not to recline the seatbacks too far to ensure that the effectiveness of the seat belts is not reduced. Nothing should be placed on the floor (area in front of the driver) as these objects may slide under the pedals during sudden braking manoeuvres, thus obstructing their use.

## Heated seats



Depending on the vehicle, with the ignition on, you can activate the heated seats via the multimedia screen **5**:

- pressing the  pictogram on the required seat for the first time activates the heating system at maximum power. Three switch-integrated warning lights are illuminated;
- a second press decreases the heating to medium power. Two integrated warning lights are illuminated;
- a third press decreases the heating to minimum power. One integrated warning light is illuminated;
- a fourth press turns the heating off.

## FRONT SEATS

In order to avoid unnecessary energy consumption, the heated passenger seat can be deactivated automatically in the absence of an occupant.

2

### "Favourites" function



Depending on the vehicle, by pressing the steering wheel control **6**, you can activate the heated seats according to the stored user settings that you have previously defined.

For more information on programming this function, please refer to the multimedia instructions.

# REAR SEATS

## Rear headrests

### Position for use

Lift the headrest fully until it locks. Check that it is correctly locked.

### To remove the headrest



Tilt the bench seat forwards, raise the headrest as much as possible, then press button **1** and remove the headrest.

### To refit the headrest


Tilt the bench seat forwards, then insert the rods into the holes, push in the headrest until it locks to use it in the

high position. Check that it is correctly locked.

### Headrest folding position 2



Press button **1** and lower the headrest completely.



**When the headrest is set at the lowest position, this is for storage only:** it should not be in this position when the seat is occupied.



The headrest is a safety component; check that it is fitted and in the correct position.

## REAR SEATS

### Rear bench seat: functions

#### Functions



#### To fold down the seatback

Ensure that the front seats are far enough forward.

Before folding down a seatback, lower the headrests as far as possible.

Before folding down any side rear seat, **fasten the seat belt buckle** of the seat concerned into its corresponding catch.

This will prevent the seat belt becoming trapped when the seat is returned to its position for use.

In all cases, check that the seat belts are operating correctly.

Pull the strap **1** and lower the seatback **A**.

**Note:** for safety reasons, the seatback **A** is equipped with a retaining system. You may experience resistance when handling.

**To replace the seatback**, proceed in the reverse order to removal.

Raise the seatback until it locks.

Be careful not to jam the seat belt between the seatback and the parcel shelf.

Check that the seat belts work correctly.



When moving the rear seats, ensure that nothing obstructs the anchorage points (passenger's arm or leg, a pet, gravel, cloth, toys, etc.).



**When refitting the seatback**, make sure it is correctly locked in place.

**If seat covers are fitted**, make sure these do not prevent the seatback latch from locking in.

Make sure that the seat belts are positioned correctly.  
Reposition the headrests.



The configuration of the two-seat bench with the small seatback **A** folded down does not allow the central seat to be used as it would be impossible to fasten the seat belt (seat belt catches inaccessible).

# SEAT BELTS

## Introduction

Always wear your seat belt when travelling in your vehicle. You must also comply with the legislation of the particular country you are in.

**Before starting, first adjust your driving position, then ask all occupants to adjust their seat belts to ensure optimum protection.**

## Seat belts

### Adjusting your driving position

- **Sit well back in your seat** (having removed your coat or jacket, etc.). This is essential to ensure that your back is positioned correctly;
- **adjust the distance between the seat and the pedals.** Your seat should be as far back as possible while still allowing you to fully depress the pedals. The seatback should be adjusted so that your arms are slightly bent when you hold the steering wheel;
- **adjust the position of your headrest.** For maximum safety, your head must be as close as possible to the headrest;
- **adjust the height of the seat.** This adjustment allows you to select the seat position which offers you the best possible view;

- **adjust the position of the steering wheel.**



Make sure that the rear bench seat → 74 is locked in position correctly so that the rear seat belts will operate correctly.



Incorrectly adjusted or twisted seat belts may cause injuries in the event of an accident.

Use one seat belt per person, whether child or adult. Even pregnant women should wear a seat belt. In this case, ensure that the lap belt is not exerting too much pressure on the abdomen, but do not allow any slack.

## Adjusting the seat belts



61247

2

To ensure the correct adjustment and positioning of the seat belts on all seats:

- adjust the seats (seat position and seatback angle, if available);
- sit with your back firmly against the seatback;
- move the shoulder strap **1** as close as possible to the base of the neck without it actually resting against it (if necessary, adjust the height of the seat belt if possible) and make sure that the shoulder strap **1** is in contact with the shoulder;
- position the lap belt **2** so that it lies flat on the thighs and against the pelvis.

## SEAT BELTS

The seat belt must be worn as close to the body as possible. e.g. avoid wearing heavy clothing, keeping bulky objects under the belts, etc.

### Locking

Unwind the belt **slowly and smoothly** and ensure that the buckle **3** locks into the catch **5** (check that it is locked by pulling on the buckle **3**).

If the belt jams, allow it to return slightly before attempting to unwind it again.

If your seat belt is completely jammed, pull firmly but smoothly to unwind around 3 cm. Allow it to return slightly before attempting to unwind it again.

If there is still a problem, contact an approved dealer.

### Unlocking

Press the button **4** and the seat belt will be rewound by the inertia reel. Guide the belt.

### Seat belt reminder warning light

This warning light appears on the central display **A** when the vehicle ignition is switched on and if the driver's and/or front passenger's seat belt(s) (if the passenger seat is occupied) is not fastened.



Front seat belt reminder



With the doors closed, the graphic **6** is displayed on the instrument panel for approximately 60 seconds when the vehicle ignition is switched on. This informs the driver of the fastening status of each of the front seat belts every time:

- the doors are opened during driving (vehicle speed above zero);
- a front seat belt is fastened/unfastened.

### Understanding the graphic **6**:

- symbol in green: seat belt fastened;
- symbol in red: the seat is occupied and the seat belt is not fastened;
- symbol in grey: seat not occupied.

With the doors closed, the  warning light appears on the central display when the vehicle ignition is switched on if the driver's and/or front passenger's seat belt(s) (if this seat is occupied) are not fastened.

When the vehicle speed is less than approximately 12 mph (20 km/h), the

 warning light appears on the central display if a front seat is occupied and the seat belt is not fastened.

It is accompanied by the graphic **6** which appears for approximately 60 seconds each time one of the front seat belts is fastened or unfastened.

## SEAT BELTS

When the vehicle speed exceeds approximately 12 mph (20 km/h), if one of the front seat belts is or becomes unfastened during the journey:

- the  warning light flashes on the central display;
- and
- a beep sounds for around 120 seconds;
- and
- the graphic **6** is displayed for approximately 180 seconds and the symbol for the seat concerned appears in red.

Always make sure that the front passengers are properly fastened in and that the number of seat belts indicated as fastened corresponds to the number of front seats occupied.

**Note:** an object placed on the passenger seat may activate the warning light in some cases.

### Rear seat belt reminder

With the doors closed, the graphic **6** is displayed on the instrument panel for approximately 60 seconds when the vehicle ignition is switched on. This informs the driver of the fastening status of each of the rear seat belts every time:

- the doors are opened during driving (vehicle speed above zero);
- a front seat belt is fastened/unfastened.

### Understanding the graphic **6**:

- symbol in green: seat belt fastened;
- symbol in red: the seat is occupied and the seat belt is not fastened;
- grey marker: seat not occupied (depending on vehicle).

Depending on the vehicle, with the

doors closed the  warning light on the central display also appears when the ignition is switched on and if a rear seat is occupied and the seat belt is not fastened.

When the vehicle speed is less than approximately 12 mph (20 km/h), the

 warning light appears on the central display when a rear seat belt is unfastened.

It is accompanied by the graphic **6** which appears for approximately 60 seconds each time one of the rear seat belts is fastened or unfastened.

When the vehicle speed reaches or exceeds approximately 12 mph (20 km/h), if one of the rear seat belts is or becomes unfastened during the journey:

- the  warning light flashes on the central display;
- and
- a beep is emitted for approximately 30 to 120 seconds (depending on the version);
- and
- the graphic **6** is displayed for at least approximately 60 seconds or, depending on the vehicle, 180 seconds and the symbol for the seat concerned appears in red.

Always make sure that the rear passengers are properly fastened in and that the number of seat belts indicated corresponds to the number of rear seats occupied.

**Note:** an object placed on one of the rear passenger seat bases may activate the warning light in some cases.

## SEAT BELTS

### Rear seat belts

#### Rear side seat belts 7




The belts are fastened, unfastened and adjusted in the same way as the front belts.



Check that the rear seat belts are positioned and operating correctly each time the rear bench seat is moved.

#### Rear centre seat belt 8



Slowly unwind the belt **8**.

Click the sliding buckle **9** into the catch of the central seat belt **10**.

# SEAT BELTS

## Warnings

The following information applies to the vehicle's front and rear seat belts.



- No modification must be made to the originally-fitted restraint system components (seat belts, seats and their mountings). For special operations (e.g. fitting child seats) please contact an approved dealer.
- Do not use devices which give any slack in the belts (e.g. clothes pegs, clips, etc.), as a seat belt which is worn too loosely risks causing injury in the event of an accident.
- Never wear the shoulder strap under your arm or behind your back.
- Never use the same belt for more than one person and never hold a baby or child on your lap with your seat belt around them.
- The belt should never be twisted.
- Following an accident, have the seat belts checked and replaced if necessary. Always replace your seat belts as soon as they show any signs of wear.
- When the rear bench seat is being put back, make sure that the seat belts and buckles are correctly positioned so that they can be used properly.
- Make sure that the seat belt buckle is inserted into the appropriate catch.
- Ensure that no objects are placed in the area around the seat belt catch as they could prevent it from being properly secured.
- Make sure the seat belt catch is properly positioned (it should not be hidden away, crushed or flattened by people or objects).

## ADDITIONAL SAFETY DEVICES

2

### Methods of restraint in addition to the front seat belts

#### Introduction

They consist of:

- **seat belt inertia reel pretensioners;**
- **lap seat belt pretensioners;**
- **chest force limiters;**
- **airbags driver and passenger front.**

These systems are designed to act independently or together when the vehicle is subjected to a frontal impact.

Depending on the severity of the impact, the system can cause:

- blocking of the seat belt;
- the seat belt inertia reel pretensioner which is triggered to correct seat belt slack;
- the lap seat belt pretensioner to hold the occupant in their seat;
- the front airbag.

#### Pretensioners



The pretensioners hold the seat belt against the body, holding the occupant more securely against the seat, thus increasing the seat belt's efficiency.

In the event of a severe frontal impact and if the ignition is switched on, the system may engage the following depending on the force of the impact:

- the seat belt inertia reel pretensioner **1** which instantly retracts the seat belt;
- the lap seat belt inertia reel pretensioner **2** on the front seats.



- Have the entire restraint system checked following an accident.
- No operation whatsoever is permitted on any part of the system (pretensioners, airbags, computers, wiring) and the system components must not be reused on any other vehicle, even if identical.
- Only qualified personnel from our Network may work on the pretensioners and airbags, otherwise the system may trigger accidentally and cause injury.
- The electrical trigger system may only be tested by a specially trained technician using special equipment.
- If scrapping your vehicle, contact an approved dealer for disposal of the gas generator of the pretensioners and airbags.

#### Load limiter

Above a certain severity of impact, this mechanism is used to limit the force of the belt against the body so that it is at an acceptable level.

## ADDITIONAL SAFETY DEVICES

### Driver and passenger front airbags

Fitted to the driver and passenger sides.

A symbol on the lower section of the windscreen indicates if this equipment is present (depending on the vehicle).

Each airbag system consists of:

- an airbag and gas generator fitted on the steering wheel for the driver and in the dashboard for the passenger;
- an electronic unit for monitoring the system controlling the gas generator electrical trigger;
- remote sensors;
- control warning lights, displayed on the roof console **3**:

-  lit up, passenger airbag activated;
-  lit up, passenger airbag disabled.



The airbag system uses pyrotechnic principles. This explains why, when the airbag inflates, it will generate heat, produce smoke (this does not mean that a fire is about to start) and make a banging noise. In a situation where an airbag is required, it will inflate immediately and this may cause some minor, superficial grazing to the skin or other problems.



### Operation

This system is only operational when the ignition is switched on.

In a severe frontal impact, the airbags inflate rapidly, cushioning the impact of the driver's head and chest against the steering wheel and of the front passenger against the dashboard. The airbags then deflate immediately so that the passengers are not in any way prevented from leaving the vehicle.

### Operating faults




This warning light comes on when the engine is started and then goes out after approximately 65 seconds.

## ADDITIONAL SAFETY DEVICES


If it does not come on when the ignition is switched on or if it stays on, there is a fault in the system.

**2** Contact your approved Dealer as soon as possible;

Your protection will be reduced until this fault is rectified.




47713



47737

In the event of a frontal impact with another vehicle of an equivalent or higher category, with an impact area equal to or greater than 40%, where the speed of both vehicles is equal to or greater than 25 mph (40 km/h).



47717

In a side impact with another vehicle of an equivalent or higher category, at an impact speed equal to or greater than 31 mph (50 km/h).

The following cases trigger the pretensioners or airbags.


In a frontal impact against a rigid (non-deformable) surface at an impact speed equal to or greater than 16 mph (25 km/h).

## ADDITIONAL SAFETY DEVICES




**The pretensioners or airbags may be triggered in the following cases:**

- an impact underneath the vehicle (e.g. pavement kerb);
- potholes;
- a drop or hard landing;
- stones;
- ...



**In the following examples, the pretensioners or airbags might not be triggered:**

- a rear impact, however severe;
- the vehicle overturning;



- side impact at the front or rear of the vehicle;
- frontal impact, underneath the tail of a lorry;
- frontal impact against an obstacle with a sharp angle;
- ...

**All of the warnings below are given so that the airbags not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when it inflates.**

# ADDITIONAL SAFETY DEVICES

## Warnings

2



### Warnings in relation to the driver's airbag

- Do not modify the steering wheel or the boss.
- Do not cover the steering wheel boss under any circumstances.
- Do not attach any objects (badge, logo, watch, telephone cradle, etc.) to the steering wheel boss.
- The steering wheel must not be removed (except by qualified personnel from our Network).
- Do not sit too close to the steering wheel: sit with your arms slightly bent (see "Adjusting your driving position" → 75). This will allow sufficient space for the airbag to deploy correctly and be fully effective.

### Warnings in relation to the passenger airbag

- **Fitting seat covers on the front seats is prohibited as this could affect the operation of the passenger airbag.**
- Do not attach or glue any objects (badge, logo, clock, telephone holder, etc.) to the dashboard on or near the airbag.
- Do not place anything between the dashboard and the passenger (animal, umbrella, walking stick, parcels, etc.).
- The passenger must not put his or her feet on the dashboard or seat as there is a risk that serious injuries may be sustained. As a general rule, parts of the body should be kept away from the dashboard (knees, hands, head, etc.).

## ADDITIONAL SAFETY DEVICES

### Methods of restraint in addition to the rear seat belts

#### Introduction

They consist of:

- **side seat belt inertia reel pretensioners;**
- **chest force limiters.**

These systems are designed to act independently or together when the vehicle is subjected to a frontal impact.


Depending on the severity of the impact, the system can cause:

- blocking of the seat belt;
- the seat belt inertia reel pretensioner (which engages to correct seat belt slack).

#### Load limiter

Above a certain severity of impact, this mechanism is used to limit the force of the belt against the body so that it is at an acceptable level.

### Side seat belt pretensioners



The pretensioners hold the seat belt against the body, holding the occupant more securely against the seat, thus increasing the seat belt's efficiency.

With the ignition on, following a significant frontal impact and depending on the severity of the impact, the system may trigger the seat belt inertia reel pretensioner **1** which instantly retracts the seat belt.



- Have the entire restraint system checked following an accident.
- No operation whatsoever is permitted on any part of the system (pretensioners, airbags, computers, wiring) and the system components must not be reused on any other vehicle, even if identical.
- Only qualified personnel from our Network may work on the pretensioners and airbags, otherwise the system may trigger accidentally and cause injury.
- The electrical trigger system may only be tested by a specially trained technician using special equipment.
- If scrapping your vehicle, contact an approved dealer for disposal of the gas generator of the pretensioners and airbags.

### Side protection devices

#### Side airbag

This airbag is fitted to each of the front seats and is activated at the sides of

## ADDITIONAL SAFETY DEVICES

the seats (door side) to protect the occupants in the event of a severe side impact.

2

### **Curtain airbag**

These are airbags fitted along the sides of the vehicle in the ceiling which trigger along the front and rear door side windows to protect the passengers in case of a severe side impact.

# ADDITIONAL SAFETY DEVICES

## Warnings



### **Warning related to the side airbag airbag**

**– Fitting seat covers on the front seats is prohibited as this could affect the operation of the passenger airbag.**

- Do not place any accessories, objects or even pets between the seatback, the door and the internal fittings. Do not cover the seatback with objects such as clothes or accessories. This may prevent the airbag from operating correctly or cause injury when the airbag is deployed.
- No work or modification whatsoever may be carried out on the seat or internal fittings, except by qualified personnel from our Network.
- The slots on the front seatbacks (door side and centre console) correspond to the airbags deployment zone: do not insert objects into these slots.

## ADDITIONAL SAFETY DEVICES

### Warnings

2

All of the warnings below are given so that the airbags not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when it inflates.



The airbag is designed to complement the action of the seat belt. Both the airbag and the seat belt are integral parts of the same protection system. It is therefore essential to wear seat belts at all times. If seat belts are not worn, the occupants are exposed to the risk of serious injury in the event of an accident. It may also increase the risk of minor superficial injuries occurring when the airbag is deployed, although such minor injuries are always possible with airbags.

If the vehicle should overturn or suffer a rear impact, however severe, the pretensioners and airbags are not always triggered. Shocks to the underbody of the vehicle, from pavements, potholes, stones etc. can all trigger these systems.

- Any work or modification on any part of the system airbag (airbags, pretensioners, computer, wiring harness, etc.) is **strictly prohibited** (except by qualified personnel from the network).
- To ensure that the system is in good working order and to avoid accidental triggering of the system which may cause injury, only qualified Network personnel may work on the airbag system.
- As a safety precaution, have the airbag system checked if your vehicle has been involved in an accident, or is stolen or broken into.
- When selling or lending the vehicle, inform the new purchaser of these conditions when handing over this vehicle user manual.
- When scrapping your vehicle, contact your approved dealer for disposal of the gas generator(s).

# CHILD SAFETY

## General information

### Carrying children

Please ensure that you comply with the legislation of your country.

Children, and adults, must be correctly seated and strapped in for all journeys. The children being carried in your vehicle are your responsibility.

A child is not a miniature adult. Children are at risk of specific injuries as their muscles and bones have not yet finished growing. The seat belt alone would not provide suitable protection. Use an approved child seat and ensure you use it correctly.



To prevent the doors being opened, use the "Child lock" feature → 62.



A collision at 31 mph (50 km/h) is the same as falling a distance of 10 metres.

Transporting a child without a restraint is the equivalent of allowing him or her to play on a fourth-floor balcony without railings. Never travel with a child held in your arms.

In the event of an accident, you will not be able to keep hold of the child, even if you yourself are wearing a seat belt.

If your vehicle has been involved in a road accident, replace the child seat and have the seat belts and ISOFIX anchorage points checked.



### Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

### Using a child seat

The level of protection offered by the child seat depends on its ability to restrain your child and on its installation. Incorrect installation compromises the protection it offers the child in the event of harsh braking or an impact.

Before purchasing a child seat, check that it complies with the regulations for the country you are in and that it can be fitted in your vehicle. Consult an ap-

## CHILD SAFETY

proved Dealer to find out which seats are recommended for your vehicle.

The regulations on transporting children are specific to each country. The use of a child seat during transport depends on the age and/or the size and/or weight of the child.

For children who do not need to be transported in a child seat, make sure that the seat belt is correctly adjusted and fastened.

In all cases, you must comply with the regulations of the particular country you are in.

Before fitting a child seat, read the manual and respect its instructions. If you experience any difficulties during installation, contact the manufacturer of the equipment. Keep the instructions with the seat.



Set a good example by always fastening your seat belt and teaching your child:

- to strap themselves in correctly;
- to always get in and out of the car at the kerb, away from busy traffic.

Do not use a second-hand child seat or one without an instruction manual.

Check that there are no objects in the vicinity of the child seat which could impede its operation.



Never leave a child unattended in the vehicle.

Check that your child is always strapped in and

that the belt or safety harness used is correctly set and adjusted. Avoid wearing bulky clothing which could cause the belts to slacken → **75**.

Never let your child put their head or arms out of the window.

Check that the child is in the correct position for the entire journey, especially if asleep.

# CHILD SAFETY

## Choosing a child seat

### Rear-facing child seats



61260

A baby's head is, proportionally, heavier than that of an adult and its neck is very fragile. Transport the child in this position as long as possible (until the age of 2 at the very least). It supports both the head and the neck.

Choose a bucket type seat for best side protection and change it as soon as the child's head is higher than the shell.

### Forward-facing child seats



61261

Up to 18 kg or 4 years, the child may travel on a forward-facing seat.

Choose your seat according to the child's size: their head and abdomen are the areas which must be most protected. A forward-facing child seat which is firmly attached to the vehicle will reduce the risk of impact to the head. Ensure your child travels in a forward-facing seat with a harness for as long as their size permits.

Choose a bucket type seat for optimum side protection.

### Booster cushions



61262

From 15 kg or 4 years, the child can travel using a booster seat, which will enable the seat belt to be adapted to suit his size and shape. The booster seat cushion must be fitted with guides to position the seat belt on the child's thighs rather than the stomach. It is recommended that you use a seatback which can be adjusted in terms of height to position the seat belt in the centre of the shoulder. It must never rest on the neck or on the arm.

Choose a bucket type seat for optimum side protection.

## CHILD SAFETY

2



List of manufacturer's recommended methods of restraint for children:



### Choosing a child seat mounting

There are two ways to attach child seats: using the seat belt or using the ISOFIX system.

#### Attachment via the seat belt

The seat belt must be adjusted in order to ensure it works in the event of sudden braking or impact.

Ensure that the strap paths indicated by the child seat manufacturer are observed.

Always check that the seat belt is correctly fastened by pulling it up, then pulling it out fully whilst pressing on the child seat.

Check that the seat is correctly held by moving it from side to side and back to front: the seat should remain firmly fixed.

Check that the child seat has not been installed at an angle and that it is not resting against a window.



Do not use the child seat if it risks unfastening the seat belt restraining it: the base of the seat

must not rest on the buckle and/or catch of the seat belt.



The seat belt must never be twisted or the tension relieved.

Never pass the shoulder strap under the arm or behind the back.

Check that the seat belt has not been damaged by sharp edges. If the seat belt does not operate normally, it will not protect the child.

Consult an approved Dealer. Do not use this seat until the seat belt has been repaired.

### Attachment using the ISOFIX system

Authorised child seats ISOFIX are approved in accordance with current regulations if any of the four cases below applies:

- Universal ISOFIX 3-point forward-facing seat;
- Semi-universal ISOFIX 2-point seat;
- vehicle-specific;
- i-Size which has either:
  - a strap which attaches to the third ring of the seat concerned;
  - or a strut that rests on the vehicle floor, compatible with the approved

## CHILD SAFETY

seat i-Size, the role of which is to prevent the child seat from moving in the event of a collision.

In the latter three cases check that your child seat can be installed by consulting the list of compatible vehicles.



No modifications must be made to the component parts of the originally fitted restraint system (seat belts, ISOFIX, seats and their mountings).

Attach the child seat with the ISOFIX locks, if these are provided. The ISOFIX system allows quick, easy and safe fitting.

The ISOFIX system consists of two rings and, in some cases, a third ring.



The ISOFIX anchorage points have been exclusively designed for child seats with the ISOFIX

system.

Never fit a different type of child seat, seat belt or other objects to these fittings.

Check that nothing is obstructing the anchorage points.

If your vehicle has been involved in a road accident, have the ISOFIX anchorage points checked and replace your child seat.



Before using an ISOFIX child seat that you purchased for another vehicle, check that its installation is authorised. Consult the list of vehicles which can be fitted with the seat with the equipment manufacturer.




The two rings **1** are located between the seatback and the seat base and

are identified by a  mark.

## CHILD SAFETY

2



The third ring **4** is used to attach the upper strap **2** on some child seats.


### Rear seats

The upper strap **2** should be positioned between the seatback and the rear parcel shelf. To do so, remove the rear parcel shelf → **67**.

Attach the hook **3** to one of the rings **4**

marked by the  symbol.

### Front passenger seat



Attach the hook **3** to the upper strap **2**

on the ring **4** marked by the  symbol.

### All seats

Pull the upper strap **2** so that the back of the child seat comes into contact with the vehicle seatback.



The ISOFIX anchorage points have been exclusively designed for child seats with the ISOFIX system. Never fit a different type of child seat, seat belt or other objects to these fittings. Check that nothing is obstructing the anchorage points. If your vehicle has been involved in a road accident, have the ISOFIX anchorage points checked and replace your child seat.



Check that the seatback of the forward-facing child seat is in contact with the seatback of the vehicle seat. In this case, the child seat may not always rest on the seat base of the vehicle seat.



The child seat strap **must** be attached to the corresponding ring.

## CHILD SEATS

### Fitting a child seat, general information

Some seats are not suitable for fitting child seats.

The diagrams on pages → 95 show you how to attach a child seat.



Fit the child seat in a rear seat wherever possible.

Make sure the child seat or the child's feet do not prevent the front seat from locking correctly → 70.

Check that when installing the child seat in the vehicle it is not at risk of coming loose from its base.

If you have to remove the headrest, check that it is correctly stored so that it does not come loose under harsh braking or impact.

Always attach the child seat to the vehicle even if it is not in use so that it does not come loose under harsh braking or impact.

The types of child seats indicated may not be available. Before using a differ-

ent child seat, check with the manufacturer that it can be fitted.

### In the front seat

The laws concerning children travelling in the front passenger seat differ in every country. Consult the relevant legislation and follow the indications on the diagram.

Before fitting a child seat in this seat (if authorised):

- lower the seat belt as far as possible;
- move the seat as far back as possible;
- gently tilt the seatback away from the vertical position (approximately 25°);
- on equipped vehicles, raise the seat base as far as possible.

Always fully raise the seat headrest so that it does not interfere with the child seat → 70.

After installing the child seat, when this is possible, you can move the vehicle seat forward if necessary (so as to leave enough space in the rear seats for passengers or other child seats). For a rear-facing child seat, do not let it touch the dashboard or move it to the furthest forward position.

Do not change other settings after installing the child seat.



**RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear facing child seat on the front passenger seat, check that the airbag has been deactivated → 109.

### In the rear side seat

A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door.

In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

For the safety of the child in the forward-facing position:

- move the seat in which the child will be seated as far back as possible;
- Move the seat in front of the child forwards, and set the position of the seatback to avoid contact between the seat and the child's legs.

## CHILD SEATS

2



Make sure the child seat or the child's feet do not prevent the front seat from locking correctly

→ 70.

In all situations, remove the headrest of the rear seat on which the child seat is positioned → 73. If necessary, position the rear seat as far back as possible. This must be done before fitting the child seat. Check that the child seat is resting against the back of the rear seat.



### Installing a booster seat (group 2 or 3)

Check that the seat belt → 75 operates (winds)

correctly.

Adjust the seat belt by positioning:

- the shoulder strap on the child's shoulder without it touching their neck;
- the lap belt so that it lies flat on the thighs and against the pelvis.

If necessary, adjust the position of the vehicle seat.



A child seat with a floor support must never be installed on the rear centre seat.

**RISK OF DEATH OR SERIOUS INJURY.**



Fit the child seat in a rear seat wherever possible.

To install a seat ISOFIX in the rear left-hand seat, unfasten the central seatbelt by hand before engaging the locks.

### In rear centre seat

Check that the belt is suitable for securing your child seat. Consult an approved Dealer.




# CHILD SEATS

## Attachment by seat belt

2

### Fitting diagram



## CHILD SEATS



**RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear facing child seat on the front passenger seat, check that the airbag has been deactivated → 109.

2



Check the status of the airbag before fitting a child seat or allowing a passenger to use the seat.



Seat not suitable for fitting child seats.

### Child seat attached using the belt



Seat equipped for attaching a "universal" approved seat using a seatbelt.



Seat enabling a child seat with "B2" approval to be attached by seat belt.



Seat enabling a child seat with "B3" approval to be attached by seat belt.



Using a child safety system which is not approved for this vehicle will not properly protect the baby or child. They risk serious or even fatal injury.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. If necessary, adjust the seat position accordingly.

## CHILD SEATS



Do not fit a child seat when the large seat back is in the folded position.

2

# CHILD SEATS

## Installation table

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

2

Type of child seat	Weight of the child	Front passenger seat		Rear side seats	Rear centre seat
		With airbag deactivated	With airbag activated		
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	X	X	U (2)	X
<b>Rear-facing shell seat</b> Groups 0 or 0 +	< 10 kg and < 13 kg	U (1) (5)	X	U (3)	X
<b>Shell seat/rear-facing seat</b> Groups 0+ and 1	< to 13 kg and 9 to 18 kg	U (1) (5)	X	U (3)	X
<b>Forward-facing seat</b> Group 1	9 to 18 kg	X	U (5)	U (4)	X
<b>Booster seat</b> Groups 2 and 3	15 to 25 kg and 22 to 36 kg	X	U / B2 (5)	U / B2 / B3 (4)	X



**(1) RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear-facing child seat in the front passenger seat, check that the airbag has been deactivated → 109.

**X** = Seat not suitable for fitting child seats of this type.

**U** = Seat enabling a child seat with "Universal" approval to be attached by seat belt: check that it can be fitted.

## CHILD SEATS

**B3; B2** = Boosters in groups 2 and 3 (15 to 25 kg and 22 to 36 kg).

**(2)** A carrycot can be fitted across the vehicle and it will take up at least two seats. Position the child with his or her feet nearest the door.

**(3)** If necessary, position the vehicle seat as far back as possible. In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

**(4)** In all situations, remove the headrest of the rear seat on which the child seat is positioned. This must be done before fitting the child seat. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.

**(5)** Raise the seat to the maximum and position it as far back as possible, tilting the seatback slightly (approximately 25°).

2



# CHILD SEATS

## Attachment using the ISOFIX system

2

### Fitting diagram



## CHILD SEATS

2

 For the front passenger seat, the use of a child seat with a floor support is recommended to avoid triggering the seat belt warning signal.



Using a child safety system which is not approved for this vehicle will not properly protect the baby or child. They risk serious or even fatal injury.



Fitting a seat ISOFIX in the rear-left seat means the middle seat cannot be used. The central seat belt will no longer be either accessible or useable.



**RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear facing child seat on the front passenger seat, check that the airbag has been deactivated → 109.



Seat which does not allow a child seat to be fitted.

### Child seat attached using the mounting ISOFIX



Seat equipped for attaching a ISOFIX or i-Size child seat.



The front and rear seats are equipped with an anchorage point that enables a Universal forward-facing child seat ISOFIX to be fitted. The anchoring points are located on the passenger seatback for the front seat and on the bench seatback for the rear seats.

## CHILD SEATS

2



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted. If necessary, adjust the seat position accordingly.



Do not fit a child seat when the large seat back is in the folded position.



Fit the child seat in a rear seat wherever possible.  
To install an ISOFIX seat in this seat, unbuckle the seat belt by hand before engaging the bolts.

# CHILD SEATS

## Installation table

The table below summarises the information already shown on the diagram on the previous page, to ensure the regulations in force are respected.

2

Type of child seat	Weight of the child	Size of seat [fixture]	Front passenger seat		Rear side seats	Rear centre seat
			With airbag deactivated	With airbag activated		
<b>Carrycot fitted across the vehicle</b> Group 0	< 10 kg	L1 [F] L2 [G]	X	X	IL (2)	X
<b>Rear-facing shell seat</b> Groups 0 or 0 +	< 13 kg	R1 [E]	IL (1) (3)	X	IL (4)	X
<b>Rear-facing seat</b> Groups 0+ and 1	< to 13 kg and 9 to 18 kg	R3 [C]	X	X	IL (4)	X
		R2 [D]	IL (1) (3)			
<b>Forward-facing seat</b> Group 1	9 to 18 kg	F3 [A] F2 [B] F2X [B1]	X	IUF-IL (3)	IUF-IL (5)	X
<b>Booster seat</b> Groups 2 and 3	15 to 25 kg and 22 to 36 kg	B3	X	X	IUF-IL (5)	X
		B2		IUF-IL (6)		
<b>Seat i-Size</b>	Rear-facing seat		i - U (1) (3)	X	i - U (4)	X
	Forward-facing seat		X	i - UF (3)	i - U (5)	X
	Booster seat		X	i - UF (6)	i - U (5)	X

**X** = Seat not suitable for fitting child seats.

## CHILD SEATS

**U** = Seat enabling a child seat with "Universal" approval to be attached by seat belt: check that it can be fitted.

**IUF-IL** = Seat enabling a child seat with "Universal/Semi-universal or vehicle-specific" approval to be attached by ISOFIX (on equipped vehicles): check that it can be fitted.



**(1) RISK OF DEATH OR SERIOUS INJURY:** before fitting a rear-facing child seat in the front passenger seat, check that the airbag has been deactivated → 109.

**(2)** A carrycot can be fitted across the vehicle and it will take up at least two seats. Position the child with his or her feet nearest the door.

**(3)** Adjust the vehicle seat as far back and as low as possible. Tilt the seatback as far as possible, install the child seat and re-adjust the seatback to an angle of about 25°.

**(4)** If necessary, position the vehicle seat as far back as possible. In order to install a rear-facing child seat, move the front seat as far forward as possible, then move the front seat back as far as it will go, without allowing it to come into contact with the child seat.

**(5)** In all situations, remove the headrest of the rear seat on which the child seat is positioned. This must be done before fitting the child seat. Move the seat in front of the child forwards, move the seatback forward to avoid contact between the seat and the child's legs.

The size of the ISOFIX child seat is indicated by a letter:

- F3, F2, F2X [A, B, B1]: for forward-facing child seats in group 1 (9 to 18 kg);
- B3; B2: boosters in groups 2 and 3 (15 to 25 kg and 22 to 36 kg);
- R3, R2 [C, D]: rear-facing seats or shell seats in group 0+ (less than 13 kg) or group 1 (9 to 18 kg);
- R1 [E]: rear-facing shell seats in group 0 (less than 10 kg) or 0+ (less than 13 kg);
- L1,L2 [F, G]: carrycots in group 0 (under 10 kg).

## CHILD SAFETY: DEACTIVATING, ACTIVATING THE FRONT PASSENGER AIRBAG

### Child safety: deactivating, activating the front passenger airbag

#### Front passenger airbag deactivation



Before installing a child seat on the front passenger seat:

- check that the child seat can be installed on this seat;
- it is essential to **deactivate** the airbag for a rear-facing child seat.



To deactivate the airbag: with the vehicle stationary and the ignition switched off, push and turn the lock **1** to the OFF position.

When the ignition is switched on, you

must check that the  warning light is illuminated on the display **2**.

**This light remains continuously lit to let you know that you can fit a child seat.**



The passenger airbag may only be activated or deactivated when the vehicle is stationary

**with the ignition off.**

If it is interfered with when the vehicle is being driven, indicator

lights  and  will come on.

Switch the ignition off then on again to reset the airbag in accordance with the lock position.



#### **DANGER**

As the deployment of the front passenger airbag is not compatible with the positioning of a rear-facing child seat, **NEVER fit a rear-facing child restraint system on a seat protected by an ACTIVATED front airbag. This can cause the CHILD'S DEATH or SERIOUS INJURY.**

## CHILD SAFETY: DEACTIVATING, ACTIVATING THE FRONT PASSENGER AIRBAG

2



bel above) are provided to remind you of these instructions.

(A)



The markings on the dashboard and the labels **A** on each side of the passenger sun visor **3** (see example of la-

## CHILD SAFETY: DEACTIVATING, ACTIVATING THE FRONT PASSENGER AIRBAG

### Activation of the front passenger airbag



You should reactivate the airbag as soon as you remove the child seat from the front passenger seat to ensure the protection of the front passenger in the event of an impact.



**To reactivate the airbag: with the vehicle stationary and the ignition switched off, push and turn the lock 1 to the ON position.**

When the ignition is switched on, you

**must** check that the  warning

light is off and that the  warning light lights up on the display 2 after each start-up for around 1 minute.

The front passenger airbag is activated.

# CHILD SAFETY: DEACTIVATING, ACTIVATING THE FRONT PASSENGER AIRBAG

## Operating faults

2

It is forbidden to fit a rear-facing child seat to the front passenger seat if the airbag activation/deactivation system is faulty.

Allowing any other passenger to sit in that seat is not recommended.

Contact your approved Dealer as soon as possible;



The passenger airbag may only be activated or deactivated when the **vehicle is stationary**

**with the ignition off.**

If it is interfered with when the vehicle is being driven, indicator

lights  and  will come on.


Switch the ignition off then on again to reset the airbag in accordance with the lock position.



# DRIVING POSITION

Driving position: left-hand drive

2



## DRIVING POSITION

### The fittings described below DEPEND ON THE VEHICLE VERSION AND COUNTRY.

**1.** Side air vents.

**2.** Stalk for:

- direction indicator lights;
- exterior lights;
- rear fog lights.

**3.** Instrument panel.

**4.** Driver airbag and horn location.

**5.** Overtake (OV) control.

**6.** Engine start/stop button.

**7.** Centre air vents.

**8.** Multimedia screen.

**9.** Passenger airbag location.

**10.** Glovebox

**11.** Controls for:

- heating or air conditioning;
- hazard warning lights;
- door central locking;
- ...

**12.** USB-C ports in the centre console.

**13.** Gear control.

**14.** Controls for:

- activating/deactivating the electronic parking brake;

– activating/deactivating the AUTOHOLD function;

– ...

**15.** "Hands-free" card holder.

**16.** Induction charging zone or centre console storage compartment.

**17.** Steering column stalk for wind-screen and rear screen wash/wiper.

**18.** Radio remote control.

**19.** DRIVE MODE control.

**20.** Controls for:

- trip computer information read-out and vehicle settings customisation menu;
- remote radio and navigation system.

**21.** Control for adjusting steering wheel height and reach.

**22.** Regenerative braking control.

**23.** Main switch and controls for the Cruise control/Speed limiter/Adaptive cruise control Stop and Go and Active Driver Assist.

**24.** Bonnet release control.

**25.** Fuse box.

**26.** Controls for:

- lighting dimmer for control instruments;
- the "My Safety" function


– activation/deactivation of the "Lane Keep Assist" function (lane departure warning, lane departure prevention, lane centring);

– ...

## DRIVING POSITION

Driver's position, right-hand drive

2



## DRIVING POSITION

### The fittings described below DEPEND ON THE VEHICLE VERSION AND COUNTRY.

1. Side air vents.
2. Passenger airbag location.
3. Centre air vents.
4. Multimedia screen.
5. Engine start/stop button.
6. Stalk for:
  - direction indicator lights;
  - exterior lights;
  - rear fog lights.
7. Instrument panel.
8. Driver airbag and horn location.
9. Overtake (OV) control.
10. Steering column stalk for wind-screen and rear screen wash/wiper.
11. Controls for:
  - lighting dimmer for control instruments;
  - the "My Safety" function
  - activation/deactivation of the "Lane Keep Assist" function (lane departure warning, lane departure prevention, lane centring);
  - ...
12. Bonnet release control.
13. Radio remote control.
14. DRIVE MODE control.
15. Controls for:
  - trip computer information read-out and vehicle settings customisation menu;
  - remote radio and navigation system.
16. Control for adjusting steering wheel height and reach.
17. Regenerative braking control.
18. Main switch and controls for the Cruise control/Speed limiter/Adaptive cruise control Stop and Go and Active Driver Assist.
19. Controls for:
  - heating or air conditioning;
  - hazard warning lights;
  - door central locking;
  - ...
20. USB-C ports in the centre console.
21. Gear control.
22. Controls for:
  - activating/deactivating the electronic parking brake;
  - activating/deactivating the AUTOHOLD function;
  - ...
23. "Hands-free" card holder.

24. Induction charging zone or centre console storage compartment.

25. Glovebox

26. Fuse box.

# TRIP COMPUTER

## General information

2

### Trip computer



Depending on the vehicle, this includes the following functions:

- mileage;
- trip settings;
- information messages;
- operating fault messages (associat-

ed with the  warning light);

- warning messages (connected to the

 warning light).

All these functions are detailed in the vehicle user manual.

Repeatedly press upwards/downwards on the switch **1** to browse between these functions.

### Selections

(the display depends on the vehicle equipment and country)

a) trip settings:


- average energy consumption since the last reset and current energy consumption;
- distance travelled since last reset.

b) reset the pressure of the tyres;

c) service interval;

d) trip log, operating faults and information messages.

## Vehicle fitted with instrument panel



The functions are displayed in zones **2**.

### Resetting the journey parameters (reset button)

With one of the trip parameters selected as the display, press and hold the switch **1** downwards until the display resets to zero.

### Automatic resetting of the journey parameters

Resetting occurs automatically when the maximum value of any of the parameters is exceeded.

# TRIP COMPUTER

## Reading energy consumption values

Some vehicle equipment items consume energy: the energy consumed by the vehicle may therefore differ from the energy consumed on the electric counter.

## Interpreting some of the values displayed after resetting

The values showing average energy consumption and range will become more stable and reliable the further you have travelled since the last time the Reset button was pressed.

For the first few miles after pressing the reset key you will notice that the range increases as you travel. This is because the average energy consumption since the last reset is taken into account. However, the average energy consumption may fall when:

- the vehicle stops accelerating;
- when driving from an urban area on to the open road.



Some on-board computer information appears on the navigation system display. The trip settings mileage recorder is reset simultaneously in the on-board computer and the navigation system.

## Resetting the estimated range

After the traction battery has been fully recharged, you can select two types of resetting: manual or automatic.

### Manual reset

Select the trip setting to reset, then press and hold the switch **1** to reset the range.

### Automatic reset

The range is automatically reset when the traction battery is fully charged. The calculated value corresponds to an average use, taking into account the exterior temperature.

If a particularly economical driving pattern is identified, the calculation is corrected and the range is increased.

# TRIP COMPUTER

## Journey settings

2

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY**

Examples of selections	Interpreting the display selected
 + 13,4 kWh	<b>a) Trip settings.</b> <b>Current energy consumption.</b>  <b>Average energy consumption.</b> The value is displayed after having travelled at least 400 metres since the last re-set.  <b>Distance travelled</b> since last reset.  <b>b) Reset the pressure of the tyres</b> <b>→ 175</b>
 12,8 kWh/100 km	
Journey 1284,7 km	
Tyre pressure init. long press	

## TRIP COMPUTER

2

Examples of selections	Interpreting the display selected
<p>Service in 1,203 miles (1,936 km) or three months</p>	<p><b>c) Service interval.</b>            Distance remaining until the next service (displayed in miles or kilometres), then when the service nears, several scenarios are possible:</p> <ul style="list-style-type: none"> <li>– interval less than <b>932 miles (1,500 km) or one month</b>: the "Service in" message is displayed along with the remaining distance or time;</li> <li>– when a service is due, the "Service due" message is displayed accompanied by the first limit (distance or time);</li> <li>– range equal to <b>0 miles (0 km) or date of service reached</b>: the message "Service Required" is displayed accompanied by the  warning light. The vehicle requires a service as soon as possible.</li> </ul>
<p><b>Resetting the display after the service in accordance with the maintenance schedule.</b>            The service interval must only be reset after a service which complies with the recommendations in the maintenance schedule.</p> <p><b>Special feature:</b> to reset the service interval, press and hold one of the display reset buttons for approximately 10 seconds until the display shows the service range permanently.</p>	
Examples of selections	Interpreting the display selected
<p>Settings Press "OK"</p>	<p><b>d) Vehicle settings customisation menu.</b>            ➔ 128</p>
<p>WARNING: Boot Open</p>	<p><b>e) Trip log.</b>            Successive display:</p> <ul style="list-style-type: none"> <li>– information messages;</li> <li>– operating fault messages.</li> </ul>

# TRIP COMPUTER

## Information messages

These can help in the vehicle starting phase, or give information about a selection or a driving status.

Examples of information messages are given in the following pages.

Examples of messages	Interpreting the display selected
<b>"Disconnect the cable to start"</b>	Indicates that the charging cable is still plugged into the vehicle.
<b>"Check the connections"</b>	Unplug, then plug in the vehicle.
<b>"Check the charging terminal"</b>	If the message still shows, this may be caused by the external charging conditions or by the home installation.
<b>"Check the charging terminal"</b>	Indicates a possible electrical fault or a defective charging cable: change the charging terminal or location or have the cable checked.
<b>"Power cut off during charging"</b>	Indicates an electrical fault while charging. Restart charging.
	If this does not work, have the electrical installation checked.

# TRIP COMPUTER

## Operating fault messages

They appear along with the  warning light and indicate that you must drive very carefully to an approved dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.

They disappear when the display selection key is pressed or after several seconds and are stored in the computer log. The

 warning light stays on. Examples of operating fault messages are given in the following pages.

Examples of messages	Interpreting the display selected
"Check airbag"	Indicates a fault in the restraint system in addition to the seat belts. In the event of an accident, it is possible that they may not be triggered.
"Check vehicle"	Indicates a fault on one of the pedal sensors or in the secondary 12 V battery management system.
"Check braking system"	Indicates wear or the need to check the braking system.
"Check Post-collision"	Indicates a problem with the multi-collision braking.
"Check vehicle socket"	Indicates overheating at the vehicle-side charging socket. Wait for approximately 20 minutes then try again. If this does not work, contact an approved dealer.
"Check electrical system"	Indicates a fault in the traction system.
"Battery charging impossible"	Indicates a fault on the traction battery recharge system.

# TRIP COMPUTER

## Warning messages

2

They appear along with the **STOP** warning light and indicate that, for your own safety, you must stop the vehicle as soon as traffic conditions allow. Stop your engine and do not restart it. Call an approved Dealer.

Some examples of warning messages are given below. **Note:** the messages appear on the display either individually or alternately (when there are several messages to be displayed), and may be accompanied by a warning light and/or a beep.

Examples of messages	Interpreting the display selected
"Braking system fault"	Indicates a fault in the braking system.
"Steering fault"	Indicates a fault in the steering system.
"Electric engine fault"	Indicates that the vehicle is losing power.
"Electrical fault"	Indicates a fault in the electric system.
"Puncture"	Indicates that at least one tyre is punctured or severely underinflated.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

# TRIP COMPUTER

## Displays and indicators

### Selection of views



Depending on the vehicle, use control **1** to browse and select the various views on the instrument panel.

Several views are proposed:

- charging view: displays the range, battery percentage and remaining charging time on the instrument panel only when the vehicle is charging;
- classic view: displays the speed, active driving aids, information area and, depending on the vehicle, the power meter on the instrument panel;
- navigation view: displays the speed, active driving aids and the information

area on the instrument panel. It also duplicates the road map from the multimedia system onto the entire instrument panel;

- realistic scene: displays the speed, active driving aids, information area as well as your vehicle and its surroundings (lanes, vehicles around you, etc.) on the instrument panel;
- minimum view: displays only essential information, the speed, active driving aids and the information area on the instrument panel.


### Instrument panel



lights up when the driver's door is opened. In some cases, the appear-

ance of a warning light is accompanied by a message.

Depending on the vehicle, you can customise your instrument panel with the content and colours of your choice. Please refer to the multimedia instructions for more information.



### Speedometer 2

#### Excessive speed audible alarm

Depending on the vehicle and country,

the  warning light is displayed and a beep sounds. This beep sounds as soon as the vehicle is travelling at over 75 mph (120 km/h).

## TRIP COMPUTER

This warning light remains lit for as long as the vehicle is travelling at over 75 mph (120 km/h).

2

### Information on driving aids 3

#### Navigation in progress information 4

Depending on the vehicle, you can display information from the multimedia screen (compass, telephone, navigation, etc.) or information from the trip computer.

Please refer to the multimedia instructions for more information.

### Battery information 5 (traction battery charging rate, estimated range)



### Power meter 6



# TRIP COMPUTER

## Total mileage recorder **7**


## Regenerative braking level warning light **9**



## Information area **8**

Depending on the vehicle, use the control **10** to browse and select the various widgets on the instrument panel:

- trip computer information (mileage recorder, consumption, etc.);
- telephone, multimedia (audio source currently playing, etc.) information;
- vehicle information (warning messages, etc.);
- ...



## Charging cable "Plugged In" warning light **11**

This comes on when the charging cable is plugged into the vehicle.

## Charge level **12**

The gauge indicates the level of energy remaining.

## Remaining charge time **13**

## Traction battery charge rate **14**

## Reserve threshold

When the traction battery charge reaches approximately 7% or, depending on the vehicle, approximately 12%,

the gauge and indicator light **15** appear in yellow, accompanied by a beep.

To optimise your range → **173**.


## Immobilisation threshold imminent

When the charge level reaches about 4% or, depending on the vehicle, about 6%, a beep will sound again and the meter will light up in red or, depending on the vehicle, 30 seconds after the meter lights up in red.

When the charge level reaches 3.5% or, depending on the vehicle, approximately 5%, the range value is no longer displayed. Engine performance gradually decreases until the vehicle comes to a halt → **326**.

# TRIP COMPUTER

## Estimated range 16



High **17**: visibility of range in optimal conditions (e.g. driving on A-roads or dual carriageways with little use of thermal comfort).

Low **18**: visibility of range in adverse conditions (e.g. driving on a motorway in winter or in a traffic jam with intensive use of thermal comfort).

To optimise your range → **173**.

## Instrument panel in miles

(option to switch to km/h)

With the vehicle stationary and the engine switched on, from the multimedia screen **16** select the "Vehicle" world,

press the "Settings" menu, "Units" then "Speed".

Choose between km/h or mph.

The speedometer and some of the distance information displayed on the instrument panel are converted.

To return to the previous mode, repeat the same operation.

**Note:** once the battery is switched off, the trip computer automatically returns to the original unit of measurement.

Please refer to the multimedia instructions for more information.



To use certain driving aid functions, it is necessary to change the unit of measurement on the instrument panel in order to obtain the appropriate information when driving in a country where the speed units differ from those set as default on your vehicle.



For safety reasons, carry out any adjustments while the vehicle is stationary.

## Vehicle settings personalisation menu

### Introduction



Depending on the vehicle equipment, this function allows you to activate/deactivate and adjust some of the vehicle's functions.

### Accessing the settings menu

With the vehicle stationary and the engine running, from the multimedia screen **1** select the "Vehicle" world, press the "Vehicle" menu then the "Outside" tab to access the various settings.

# TRIP COMPUTER

## Adjusting the settings

Select a tab then the function to be modified (the display depends on the vehicle equipment and country):

### a) "Access":

- « Auto door lock while driving » ;
- « Hands-free lock/unlock » ;
- « Access and start by phone » ;
- ...

### b) "Welcome":

- « External lighting sequence » ;
- « Internal sequence sound » ;
- « Automatic mirrors' unfolding » ;
- « Internal light function » ;
- ...

### c) "Driving lights":

- « Adaptive Vision » ;
- « Driving side selection » ;
- ...

### d) "Wiping":

- « Rear wiper when in reverse gear » ;
- « Automatic front wiper » ;
- ...

Depending on the function, select:

- "ON" or "OFF" to activate or deactivate;

or

- a time period to adjust the time during which the headlights are illuminated

(e.g. for the "Follow me home" function).

Please refer to the multimedia instructions for further information.



For safety reasons, carry out any adjustments while the vehicle is stationary.

## "Favourites" function



Depending on the vehicle, by pressing the steering wheel control **2** you can activate the following functions according to the stored user settings that you have previously defined:

- heated seats;
- heated steering wheel;
- setting selection (access, welcome, lighting, wiper, etc.);
- "Hands-free Park Assist" function;
- Save mode;
- ...

For more information on programming this function, please refer to the multimedia instructions.



For safety reasons, carry out any adjustments while the vehicle is stationary.

# TRIP COMPUTER

## Clock and outdoor temperature

### Setting the time



The time and outdoor temperature are displayed on the multimedia screen **1**.

To set the time, from the multimedia screen **1** select the "Vehicle" world, press the "Settings" menu then "Time setting".

You can access various settings:

- « Time format » ;
- « Select country time zone » ;
- "Set the time zone";
- ...

Please refer to the multimedia instructions for further information.

## Exterior temperature indicator

### Special feature:

When the outside temperature is between  $-3^{\circ}\text{C}$  and  $+3^{\circ}\text{C}$ , the  $^{\circ}\text{C}$  figures flash (this indicates a risk of ice formation).



If the power supply is cut (battery disconnected, supply wire cut, etc.), the clock must be reset.

We recommend that you do not adjust these settings while driving.



### Exterior temperature indicator

As ice formation is related to climatic exposure, local air humidity and temperature, the external temperature alone is not sufficient to detect ice.

## WARNING LIGHTS

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**



**Instrument panel A:** this lights up when the driver's door is opened. To adjust the dashboard brightness, refer to the multimedia instructions.

In some cases, the appearance of a warning light is accompanied by a message.



For your own safety, the **STOP** warning light requires you to stop immediately, as soon as traffic conditions allow. Switch off the engine and do not restart it. Call an approved dealer.



If no lights or sounds are apparent, this indicates a fault in the instrument panel. This indicates that it is essential to stop immediately (as soon as traffic conditions allow). Ensure that the vehicle is correctly immobilised and contact an approved Dealer.



Warning light  means you should drive **very carefully to an authorised dealer as soon as possible.** If you fail to follow this recommendation, you risk damaging your vehicle.



**Side light tell-tale light**



**Dipped beam headlight tell-tale light**



**Main beam headlight tell-tale light**



**Automatic main beam headlight indicator light**



**Rear fog light tell-tale**



**Left-hand direction indicator tell-tale light**



**Right-hand direction indicator tell-tale light**

## WARNING LIGHTS



"Adaptive Vision" lights malfunction warning light



Door status warning light



Electronic parking brake applied warning light → 164



"Autohold" system warning light



Pedestrian horn fault warning light



Front driver airbag and passenger → 109 fault warning light



Low windscreen washer level warning light



Automatic wiping function warning light

### **STOP** Urgent stop warning light

This lights up when the ignition is switched on and goes out as soon as the engine is switched on. The warning light comes on with other warning lights and/or messages and is accompanied by a beep.

For your own safety, it requires you to stop immediately, as soon as traffic

conditions allow. Switch off the engine and do not restart it. Call an approved dealer.



### Warning light

This lights up when the ignition is switched on and goes out as soon as the engine is switched on. The warning light may light up in conjunction with other warning lights and/or messages on the instrument panel.

It means you should **drive very carefully** to an approved Dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.



### Warning light

If it appears in red during driving and is

accompanied by the **STOP** indicator light, you must, for your safety, stop as soon as traffic conditions allow. Switch off the engine and do not restart it. Call an approved dealer.

If it appears in yellow during driving

and is accompanied by the 

warning light, visit an approved dealer as soon as possible. **Meanwhile, drive with care.** If you fail to follow this recommendation, you risk damaging your vehicle.



### Electrotechnical system warning light

It lights up along with the warning light



and a beep when the electrical assembly temperature is too high. Stop the vehicle and switch off the ignition. Consult an approved Dealer.

**If it lights up accompanied by the**

**warning light  , a beep and the "EVACUATE IN SAFETY" message**, switch off the ignition and do not restart the engine. Leave the vehicle and consult an approved dealer.



The "EVACUATE IN SAFETY" message accompanied by the warn-

ing light **STOP** and a beep requires that you stop the vehicle immediately, depending on the traffic conditions. Switch off the ignition. Leave it switched off. Exit the vehicle, get all passengers out of the vehicle and keep them away from the vehicle and traffic.

**Fire hazards**

## WARNING LIGHTS



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.



### Electrotechnical system fault warning light

When it comes on, this indicates an electrotechnical fault related to the electrical assembly (traction battery and electric motor). Contact your approved Dealer straight away.



### Electric motor fault warning light

When it comes on, this indicates a fault with the electrotechnical system linked to the electric motor. Contact your approved Dealer straight away.



### Traction battery gauge warning light

This appears in yellow when the traction battery charge level has reached the reserve threshold.



### Traction battery fault warning light

If it appears, accompanied by the



warning light, this indicates a fault related to the operation of the traction battery. Contact your approved Dealer straight away.



### Secondary 12 V battery charge warning light

If it comes on, accompanied by the



STOP warning light and a beep, this means that the electrical circuit is overcharged or discharged → 312.



### Limited performance warning light

This appears when the traction battery temporarily does not deliver its nominal power. During this period, vehicle performance is reduced. Opt for a smoother driving style until the warning light disappears.



### Charging cord plugged in warning light

This comes on when the charging cable is plugged into the vehicle → 20.



### Anti-lock braking warning light

This lights up when the ignition is switched on and goes out after a few seconds.

If it does not go out after the ignition is switched on, or lights up when driving, there is a fault with the ABS. Braking will then be as normal, without the ABS. Contact your approved Dealer straight away.



### Electronic Stability Program (ESC) and traction control system warning light

The warning light may appear for several reasons.



### Electronic Stability Program (ESC) and traction control system unavailability warning light



### Tyre under-inflation warning light

This lights up when the ignition is switched on or when the engine starts, then disappears after a few seconds → 175.



### "Hands-free parking" function warning light



### Variable power assisted steering warning light

It lights up when the ignition or the en-

## WARNING LIGHTS

engine is switched on and goes off after a few seconds.

If it comes on while driving, alongside

the warning light **STOP**, this means there is a system fault. Call an approved dealer.

### Brake circuit fault warning light

It lights up when the ignition or the engine is switched on and goes off after a few seconds.

If it comes on during braking and is ac-

companied by the **STOP** warning light and a beep, it indicates that the fluid level in the circuit is low or that there is a braking system fault.

Stop as soon as traffic conditions allow and consult an approved Dealer.

### Brake pedal warning light

This lights up when the brake pedal should be depressed.

### Charging programming warning light

### Air conditioning programming indicator

### "Hands off steering wheel" detection warning light

### "Active emergency braking" function warning light → 208

### Warning light to indicate a fault or unavailability of the "Active emergency braking" function → 208

### Overspeed warning light

### Lane departure warning light


### Lane departure prevention warning light

### Lane Centring warning light

### Speed limiter warning light

### Adaptive cruise control warning light Stop and Go

## On display *B*



### Airbag passenger ON → 109

### Airbag passenger OFF → 109

### Front seatbelt reminder warning light → 75

# STEERING

## Steering wheel

### Adjusting the steering wheel height and depth



Lower the lever **1** and set the steering wheel to the required position.


Then, raise the lever fully, beyond the point of resistance to lock the steering wheel.

Make sure that the steering wheel is correctly locked.



For safety reasons, only adjust the steering wheel when the vehicle is stationary.

### Steering wheel heating



(depending on the vehicle)

This function heats the steering wheel **4**.

#### Operating principle

When the temperature is reached, the function regulates the temperature of the heated areas for approximately 30 minutes and then switches off automatically.

### Activating the function

With the ignition on, press the button **5** on the multimedia screen **2**.



### Deactivating the function

#### – Automatically:

The function switches off automatically after the regulation phase of approximately 30 minutes.

#### – Manually:

To deactivate the function during the regulation phase, press the button **5** on the multimedia screen **2**.

**Note:** the function is also accessible via the **3** "Favourites" button on the steering wheel **4**.

# STEERING

## "Favourites" function



Depending on the vehicle, by pressing the steering wheel control **6** you can activate the heated steering wheel according to the stored use settings that you have previously defined.

For more information on programming this function, please refer to the multimedia instructions.

## Power-assisted steering

Never drive with an inadequately charged battery.

## Variable power assisted steering

The variable power-assisted steering system is equipped with an electronic

control system which alters the level of assistance to suit the vehicle speed.

Steering is made easier during parking manoeuvres (for added comfort) while the force needed to steer increases progressively as the speed rises (for enhanced safety at high speeds).

## Special case

in the event of a battery fault (battery disconnected, discharged, etc.), the power-assisted steering must be reset. To do this:

- the vehicle stationary and on flat ground;
- with only the driver in the vehicle,

start the engine: the  and/or the "Turn steering wheel fully right and left" message appear(s) on the instrument panel;

- turn the steering wheel fully to the left, then to the right. The warning light and/or the message will disappear the next time the engine is started.



Never switch off the ignition when travelling downhill, and avoid doing so in normal driving (power steering and brake servo will not function).



Never leave the steering wheel on full lock when the vehicle is stationary. With the engine switched off, or if there is a system fault, it is still possible to turn the steering wheel. The force required will be greater. A noise may be heard when the steering wheel is moved quickly. This is normal.

## REAR VIEW

### Rear view mirrors

#### Exterior rear view mirrors with electrical adjustment:



When you select a door mirror using one of the switches **3**, the indicator light built into the switch will appear. Then use the button **2** to adjust it to the desired position.

#### Heated rear view mirrors

While the engine is running, mirror de-icing is activated simultaneously with the rear screen de-icing/demisting.



For safety reasons, carry out any adjustments while the vehicle is stationary.

#### Electrical folding mirrors

Depending on the vehicle, mirrors are folded out automatically when the vehicle is unlocked. The door mirrors fold in when the vehicle is locked.

You can deactivate/activate automatic folding of the door mirrors → **128**.

You can force folding by pressing the switch **1**. In this situation, the door mirrors will remain folded until the button **1** is pressed again, regardless of automatic folding.

#### Special case

When the rear view mirror has been manually deployed or folded back, it is possible to reset it to a usage position.

To do this, press the switch **1**. A mechanical noise from the rear view mirror unit will be heard.

If a tapping noise cannot be heard, press the switch **1** again until the tapping noise can be heard from the door mirror.



Objects observed in the rear view mirror glass are actually closer than they appear.

For your safety, take this into account in order to correctly assess the distance before any manoeuvre.

## REAR VIEW

### Interior rear view mirror

Its position can be adjusted.

2

### Rear view mirror with lever 4



When driving at night, to avoid being dazzled by the headlights of the vehicle behind, shift the small lever **4** located behind the rear view mirror.

### Rear view mirror with lever 5



The rear view mirror automatically darkens when you are being followed by a vehicle using main beam headlights or in very bright lighting.

# LIGHTING AND SIGNALS

## Exterior lighting and signals

### Daytime running lights



66097



Rotate the ring **4** until the AUTO symbol is aligned with the mark **3**.

The daytime running lights come on automatically (without any action on the stalk **1**) when the engine is started and they switch off when the engine is switched off.

### Side lights

 Turn the ring **4** until the symbol is aligned with the mark **3**.

This indicator light on the instrument panel comes on.

**Note:** depending on the vehicle, the side lights can only be manually activated when the parking brake is applied. Otherwise, the "Unavailable po-

sition lights" message is displayed on the instrument panel to inform you that it is not possible to activate the side lights.

### Dipped beam headlights

#### Manual operation

Turn the ring **4** until the symbol is aligned with the mark **3**.

This indicator light on the instrument panel comes on.



Before driving at night, check that the electrical equipment is operating correctly and adjust the headlight beams (if your vehicle is not carrying its normal load). As a general precaution, check that the lights are not obscured (by dirt, mud, snow or objects being transported).

#### Automatic operation

Turn the ring **4** until the AUTO symbol is aligned with the mark **3**: with the engine running, the dipped beam headlights switch on or off automatically according to the exterior light level, without any action on the stalk **1**.

## LIGHTING AND SIGNALS

Depending on the vehicle, the dipped beam headlights will appear automatically after several sweeps of the windscreen wiper blades.



When driving on the left-hand side of the road in a left-hand drive vehicle (or vice versa), you must adjust your headlights for the length of your stay → 143.

### Main beam headlights

66097



With the engine on and the dipped beam headlights on, push the

stalk **1** (movement **A**).

This indicator light on the instrument panel comes on.

To return to the dipped beam headlights position, push the stalk **1** again.

### Automatic main beam headlights

66097



Depending on the vehicle, this system switches the main beam headlights on and off automatically.

It uses a camera located behind the interior rear view mirror to detect vehicles that are being followed and those coming in the opposite direction.

**Note:** at night, in urban areas with street lighting, the automatic main

beam headlights automatically switch off.

The main beam headlights come on automatically if:

- the exterior light level is low;
- no other vehicle or lighting is detected;
- the vehicle speed is above approximately 25 mph (40 km/h).

If any of the above conditions are not fulfilled, the system switches to dipped beam headlights.

**Note:** make sure that the windscreen is not obscured (dirt, mud, snow, condensation, etc.).

### Activation/deactivation

#### To activate the automatic main beam headlights

Turn the ring **4** until the AUTO symbol is aligned with the mark **3**, then press the switch **5**.

The indicator light  on the instrument panel lights up if the dipped beam headlights are on.

## LIGHTING AND SIGNALS

### To deactivate the automatic main beam headlights

Press the switch **5**: the  warning light disappears from the instrument panel.

**Note:** when you push the stalk **1**, the automatic main beam headlights func-

tion is deactivated, the  warning light disappears from the instrument panel and the vehicle activates the main beam headlights.



The system may encounter difficulties under certain conditions, including:

- extreme weather conditions (rain, snow, fog, etc.);
- obstruction in front of the windscreen or camera;
- when a following or oncoming vehicle has weak or hidden lighting;
- incorrect settings for the front headlights;
- reflecting systems;
- ...

### Operating faults

When the "Check Automatic Lighting" message appears on the instrument panel, the system is deactivated.

Consult an approved dealer.



Using a portable navigation system at night in the area of the windscreen below the camera may disturb the operation of the "automatic main beam headlights" system (**risk of reflections on the windscreen**).



The "automatic main beam headlights" system should under no circumstances be used to replace the driver's attention and responsibility with regard to vehicle lighting and adapting to light, visibility and traffic conditions.

### Switching off the lights

66097



The lights will go out automatically when the driver's door is opened or the vehicle is locked, or one minute after the engine is switched off.

In this case, the next time the engine is started the lights will be switched back on according to the position of the ring **4**.

### Lights-on reminder audible alarm

If the lights are on after the engine is switched off, a warning beep sounds when the driver's door is opened to warn you that the lights are still on.

## LIGHTING AND SIGNALS

### Operating faults

Depending on the vehicle, when the "WARNING: Check Lighting" message

appears accompanied by the 

warning light and/or the  warning light flashes on the instrument panel, this indicates that there is a lighting fault.

Consult an approved dealer.

### Welcome and goodbye function

(depending on the vehicle)

Once the function is activated, the dipped beam headlights and the rear side lights light up automatically on detecting the card or when the vehicle is unlocked.

They switch off automatically:

- approximately fifteen seconds after they are switched on;
  - when starting the engine, based on the position of the lighting stalk;
- or
- upon locking the vehicle.

### Activating/deactivating the function

For activation or deactivation of the external welcome, refer to the multimedia instructions.

### "See-me-home lighting"

660097



This function enables you to briefly switch on the side lights and dipped beam headlights (e.g. to provide light when opening a gate).

**With the engine stopped and the lights switched off, after opening the driver's door, with the ring 4 in position AUTO, pull the stalk 1 towards you: the side lights and dipped beam headlights will switch on for approximately 30 seconds along with the**

 and  warning lights on the instrument panel.

To increase this duration, you may pull the stalk up to four times (total time restricted to approximately two minutes).

The "Lighting on during \_\_\_" message appears with the lighting time on the instrument panel to confirm the action.

You can then lock your vehicle.

### Deactivating the "See-me-home lighting" function

To switch off the lights before they switch off automatically, turn the ring 4 to any position, then return it to position AUTO.

**Note:** if the Welcome and Goodbye function is activated, once the engine is switched off, the procedure for deactivating the "See-me-home lighting" function must be carried out before pulling the stalk (otherwise the lights remain lit by the "Welcome and Goodbye" function).

# LIGHTING AND SIGNALS

## Rear fog light

66097



 **To activate the rear fog light**, turn the ring **4** until the AUTO symbol is aligned with the mark **3**, then turn the rotary switch to align the mark **6** with the symbol **2**.

Warning light  comes on the instrument panel.

Operation of the fog lights depends on the exterior lighting selected, and an indicator light will light up on the instrument panel.

To avoid inconveniencing other road users, remember to switch off this light when it is no longer needed.

 **To deactivate the rear fog light**, turn the rotary switch again to align the mark **6** with the symbol **2**.

Warning light  goes out on the instrument panel.

The rear fog light switches off when the exterior lights are switched off.

 When driving in fog or snow, or when transporting objects which are taller than the roof, the lights do not come on automatically. The fog light is controlled by the driver: the warning lights on the instrument panel inform you whether they are on (warning light on) or off (warning light off).

## Headlight beam adjustment

### Operation



the switch **A** can be used to adjust the height of headlight beams according to the load.

With the dipped beam headlights on, press or raise switch **A** as many times as required to select the required position on the instrument panel. The position selected is displayed on the instrument panel for approximately 15 seconds.

**Note:** if the lights are on, at each engine start-up the selected position is displayed on the instrument panel for approximately 15 seconds.

## LIGHTING AND SIGNALS

2



When driving on the left in a left-hand drive vehicle (or vice versa), you must adjust your lights **temporarily** for the duration of your trip.

# LIGHTING AND SIGNALS

Table of adjustment position examples

	Examples of positions for adjusting the control <b>A</b> according to the load
<b>Driver only</b>	0
<b>Driver alone with a front passenger</b>	0 or 1
<b>All seats occupied</b>	1 or 2
<b>Driver with passengers and luggage (or load) reaching the maximum permissible all-up weight</b>	2 or 3
<b>Driver without passengers and luggage (or load) reaching the maximum permissible all-up weight</b>	2 or 3 or 4

The table below gives some examples. In all cases, adjust the control **A** according to the vehicle load so that the road can be seen and other drivers are not dazzled.

# AUDIBLE AND VISUAL SIGNALS

## Horn



Press the steering wheel boss **A** to sound the horn.

## Headlight flasher

To flash the headlights, pull the stalk **1** towards you, then release.

## Direction indicators

Move the stalk **1** in the same direction as you want to move the steering wheel.

### One-touch mode

Briefly shift the stalk **1** upwards or downwards, not exceeding the point of resistance, then release it: the stalk

will return to its original position and the direction indicator light concerned will flash three times.

## Hazard warning lights



 Press the switch **2**. This switch activates all four direction indicators and the side indicator lights simultaneously.

It must only be used in an emergency to warn drivers of other vehicles that you have had to stop in an area where stopping is prohibited or unexpected, or that you are obliged to drive under special conditions.

# WIPER

## Windscreen wash, wipe

### Vehicle fitted with intermittent windscreen wipers



**A. single sweep:**

a short push will trigger one sweep of the wipers;

**B. off;**

**C. intermittent wiping:**

the wipers will pause for several seconds between sweeps. You can change the interval between sweeps by turning the ring **2**;

**D. slow continuous wiping;**

**E. fast wiping speed.**

66008



### Special feature

**When driving the vehicle,** the wiping speed slows down whenever the vehicle stops.

For example, fast wiping speed will slow to normal wiping speed.

As soon as the vehicle moves off, wiping will return to the speed originally selected.

Any action on the stalk **1** overrides and cancels the automatic function.

### Vehicle fitted with front windscreen wiper rain sensor



The rain sensor is located on the windscreen, in front of the interior rear view mirror.

**A. Single sweep:**

a short push will trigger one sweep of the wipers;

**B. off;**



### C. automatic wiper function:

when this position is selected, the system detects water on the windscreen and triggers the wipers at a suitable wiping speed.

It is possible to change the triggering threshold and the interval between sweeps by turning the ring **2**:

- **F**: maximum sensitivity;
- **G**: minimum sensitivity.

The higher the sensitivity, the quicker the wipers will react and the faster the wipe.

When activating automatic wiping or when increasing sensitivity, one sweep of the blades is performed.

The  warning light appears on the instrument panel to confirm that the function is activated.

### Note:

- the rain sensor is only intended as a driving aid. In the event of reduced visibility, the driver should manually activate the wipers. In foggy weather or during snowfalls, wiping is not automatically triggered and remains under the driver's control;

- in the event of temperatures below zero, automatic wiping is not activated when the vehicle is started. It is automatically activated as soon as the vehicle exceeds a certain speed (approximately 5 mph (8 km/h));

- do not activate automatic wiping in dry weather;
- fully de-ice the windscreen before activating automatic wiping;
- when washing using a roller type car wash, return the stalk **1** to the off position **B** to deactivate automatic wiping.

### Operating faults

In the event of a malfunction of the automatic wiping, the wiper is set to intermittent wiping. Call an approved dealer.

The rain sensor operation may be interrupted in the event of:

- damaged windscreen wipers: a film of water or traces left by a blade in the sensor's detection zone may increase the response time of the automatic wiper, or increase the wiping frequency;
- a windscreen with any chip or crack near the sensor, or a windscreen covered in dust, dirt, insects, ice, the use of washing wax and water-repellent chemicals. The windscreen wiper will be less sensitive or may even not react at all;

**D. slow continuous wiping;**

**E. fast wiping speed.**

### Special feature

**When driving the vehicle**, the wiping speed slows down whenever the vehicle stops.

For example, fast wiping speed will slow to normal wiping speed.

As soon as the vehicle moves off, wiping will return to the speed originally selected.

Any action on the stalk **1** overrides and cancels the automatic function.

### Precautions

- In the event of ice, check whether the blades are stuck to the windscreen before operating the wiping mechanism. If you activate the wipers while the blades are stuck down with ice,

## WIPER

you may risk damaging both the blade and the wiper motor.

- Do not activate the wipers on a dry screen. This will lead to premature wear or damage to the blades.

### Specific front wiper position (service position)

This position enables the blades to be lifted to remove them from the windscreen.

It may be useful to:

- clean the blades;
- release the blades from the windscreen in winter;
- replace the blades → 331.

With the engine off or running, lift the stalk **1** twice to position **A** (single sweep).

The blades stop slightly away from the bonnet.

To return the blades to the lowered position, with the ignition on, ensure that the wipers have folded down onto the windscreen, then move the stalk **1** to position **A** (single sweep).

Before switching on the ignition, place the wipers on the windscreen. Otherwise, there may be a risk of damage to the bonnet or the wipers when they are switched on.



Before any action involving the windscreen (washing the vehicle, de-icing or cleaning the windscreen, etc.) return the stalk **1** to position **B** (park).

**Risk of injury and/or damage.**



In the event of obstacles on the windscreen (dirt, snow, ice, etc.), clear the windscreen (including the central area located behind the interior rear view mirror) before starting the wipers (**risk of motor overheating**).

If an object is preventing a blade from moving, it may stop functioning.

Remove the obstacle and reactivate the wiper using the wiper stalk.

## Windscreen washer



**With the ignition on**, pull the stalk **1** then release it.

A longer pull will trigger, in addition to the windscreen washer, two sweeps of the wipers followed, a few seconds later, by a third.

### Note:

- activating the windscreen washer using the stalk **1** for more than 30 seconds may cause the washer pump to cut out. **This prevents the pump from overheating;**
- in temperatures below zero, the washer liquid risks freezing to the windscreen, thereby reducing visibility. Heat the windscreen using the demister control before cleaning.

## WIPER

2



When working in the engine compartment, ensure that the windscreen wiper stalk is in position

**B** (off).

**Risk of injury.**



### Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:

- it must remain clean: clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

In all cases, replace it as soon as it begins to lose efficiency: approximately once a year → **331**.

### Precaution for using the wipers

- In freezing or snowy conditions, clear the screen before starting the wipers (risk of motor overheating);
- ensure that no objects are obstructing the travel of the blade.

## Rear windscreen wash, wiper

### Rear windscreen wiper

68098



With the ignition on, rotate the ring **3** on the stalk **1** until the symbol is aligned with the mark **2**:

- **off**;
- **intermittent wiping**;

The wipers will pause for several seconds between sweeps. The wiping frequency varies according to the vehicle speed;

- **slow continuous wiping**.

To stop the operation, rotate the ring **3** again.

## WIPER

**Note:** when washing using a roller type car wash, return the ring **3** on the stalk **1** to the off position to deactivate automatic wiping.

Follow usage recommendations.

At the end of use, remember to return the rear wiper control to the stop position, so that wiping is not inadvertently activated during the next use.



Do not use the wiper arm to open or close the tailgate.



Before taking any action involving the rear screen (washing the vehicle, de-icing, cleaning, etc.) return the stalk **1** to the off position.

**Risk of injury and/or damage.**



### Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:

- it must remain clean: clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

In all cases, replace it as soon as it begins to lose efficiency: approximately once a year → **331**.

### Precautions for using the wipers

- In freezing or snowy conditions, clear the screen before starting the wipers (risk of motor overheating);
- ensure that no objects are obstructing the travel of the blade.

# WIPER

2

## Activation/deactivation of the rear screen wiper

Engaging reverse gear triggers intermittent wiping (if the front wipers are in operation). If your vehicle is equipped with a vehicle settings customisation menu, you can opt to activate or deactivate this function ➔ **128**.

For vehicles not fitted with a settings customisation menu, you can have this function deactivated by an authorised dealer.

In the event of obstacles present on the rear window (dirt, snow, etc.), the wiper will try to sweep away all the obstacles. If an obstacle prevents the blade from moving, it can be stopped. Remove the obstacle, wait for around 30 seconds and reactivate the wiper using the wiper stalk.

## Precautions

- In the event of ice, check that the blades are not stuck to the windscreen before operating the wipers. If you activate the wiper while the blade is blocked by ice, you risk damaging both the blade and the wiping motor.
- Do not operate the wipers on a dry screen. This will lead to the premature wear or damage to the blades.

## Rear screen wash/wipe



With the ignition on, push and hold the stalk **1** then release it.

Holding the stalk for longer will trigger (in addition to the windscreen washer) two sweeps of the rear wiper followed, a few seconds later, by a third (drip wiping function).

When the stalk is released, it returns to the rear wipe position.

### Note:

- activating the rear screen washer using the stalk **1** for more than 30 seconds may cause the screen washer pump to cut out. **This prevents the pump from overheating.**
- in temperatures below zero, the washer fluid risks freezing to the rear screen, thereby reducing visibility. Heat the rear screen using the demister control before clearing it.

# STARTING, STOPPING THE ENGINE

## Starting the engine



67199



66297

The card must be in the detection zone **1**.

### To start:

- press the brake pedal;
- press the button **2**. The "READY" message appears on the instrument panel, accompanied by a beep.

The message disappears when the vehicle speed is above approximately 3 mph (5 km/h).

### Special features

- If one of the starting conditions is not met, the "Press Brake + START" message is displayed on the instrument panel;
- in some cases, it will be necessary to move the steering wheel whilst pressing the start button **2** to help unlock the steering column: in this case the "Turn Steering Wheel + START" message will inform you.

**i** Depending on the vehicle, you may have a digital key that offers all the functions of the card. However, if a card has been left inside the vehicle and the doors have been locked with a digital key, all of the card's functions will be inhibited. For further information, please see the "Digital key" section → **59**.

**i** During a system update via the multimedia system it will not be possible to start the vehicle. Wait for the update to be completed before starting the vehicle. For more information on system updates, please refer to the multimedia instructions.

**i** The vehicle can only be started if the charging cord is unplugged from the vehicle.

# STARTING, STOPPING THE ENGINE



## "Hands-free" starting with the luggage compartment open

In this case, the card should not be located in the luggage compartment, to prevent the risk of loss.

### Accessories function

(switching on the ignition)

Once you have gained access to your vehicle, you may use some of its functions (radio, navigation, wipers, etc.).

To use the other functions, with the card in the passenger compartment, press the button **2** without pressing the pedals.

## Operating faults



In certain cases, the hands-free card may not work:

- the card battery is flat, the secondary 12 V battery is discharged, etc.;
- the card is near to appliances operating on the same frequency (monitor, mobile phone, video game device, etc.);
- the vehicle is located in a high electromagnetic radiation zone.

The "Place card on zone + START" message appears on the instrument panel.

Press the brake pedal then place the card **4** (button side down) on the

"hands-free" card placement area **3** on the upper console **A**.

Press the button **2** to start the vehicle. The message goes out.

# STARTING, STOPPING THE ENGINE

## Stopping the engine



The vehicle must be at a standstill.

Press the button **2**: the engine stops, the "READY" message disappears from the instrument panel and the electronic parking brake is applied.

If the card is no longer in the passenger compartment when you try to switch the engine off, the "Keycard absent : press/hold START" message appears on the instrument panel: press the button **2** for more than two seconds.

After the engine is switched off, any accessories being used (radio, etc.) will continue to function for approximately 45 minutes.

When the driver's door is opened, the accessories stop working.



Never switch off the ignition before the vehicle has stopped completely. Once the engine has stopped, the power-assisted steering and passive safety devices, such as airbags and pretensioners, will no longer operate.



### **Driver's responsibility when parking or stopping the vehicle**

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

# STANDING START PROCEDURE



The standing start procedure (Launch Control) is a function that allows the vehicle to accelerate at maximum speed when the tyre-to-ground grip is optimal.

**Note:** the Launch Control function is only available if the traction battery and engine have reached their operating temperatures.

To enable the best performance, we recommend using the function when the battery is mostly charged.

 Heavy use of the system will reduce the service life of the mechanical components. For further information, please contact an approved dealer.

## Activating the system

The system is activated as follows:

- with the engine running and the vehicle stationary, engage **D** position;
- Sport mode is activated ➔ **281**;
- press the brake pedal firmly using your left foot;
- keeping your foot on the brake pedal, press the Overtake (OV) button on the steering wheel **1** until the "Launch Control ready Full throttle" message is displayed on the instrument panel;
- release button **1**;
- within 60 seconds, keeping your left foot pressing the brake pedal, press the accelerator down fully **beyond the point of resistance** using your right foot until the "Launch Control active Release brake" message is displayed on the instrument panel;
- within four seconds, release the brake pedal to enable sporty starting of the vehicle accompanied by a special animation on the instrument panel



Do not use this function on slippery or wet roads.  
**Risk of loss of control of the vehicle.**

## Conditions for non-activation of the system

Certain conditions will prevent activation of the system:

- engaging **R** or **N** position;
- with Save or Normal mode activated, the "Launch Control unavailable in this DRIVE MODE" message is displayed on the instrument panel ➔ **281**;
- the traction battery charge level is too low;
- the traction battery temperature is too low or too high;
- the engine temperature is too low or too high;
- failure of a vehicle system (ESC, etc.).

**Note:** if the function is inhibited by one of these conditions, the "Launch Control unavailable" message is displayed on the instrument panel.



Using this function significantly accelerates tyre wear ➔ **318**.

## STANDING START PROCEDURE



Because of the acceleration gained, this function should only be used if traffic conditions permit, and in compliance with the local driving regulations.

Please ensure all the conditions are met before each use.

**Risk of accident or serious injury.**

# "OVERTAKE" FUNCTION

## Introduction



When you press the "OV" button **1** on the steering wheel, the engine delivers the maximum performance, instantly increasing the vehicle's acceleration.

You must press and hold the "OV" button **1** in order to keep the function activated. The maximum duration of the function is approximately 10 seconds.

Beyond this and/or when the button is released, the vehicle resumes its normal operation.



Because of the acceleration gained, this function should only be used if traffic conditions permit, and in compliance with the local driving regulations. Please ensure all the conditions are met before each use.  
**Risk of accident or serious injury.**

## Activating the system

To activate the function, the following conditions must be met:

- with the engine on, **D** position is engaged;
- Normal or Sport mode is activated  
➔ **281**;
- the vehicle speed is not zero;
- the accelerator pedal is pressed;
- the traction battery and the engine have reached their operating temperature.

## Display



At any time, you can check if the function is available by consulting the remaining range on the "OV" gauge **2** displayed on the instrument panel.

When the "OV" gauge **2** is empty, the function is no longer available and it is necessary to wait for it to gradually recharge. To do this, simply release the "OV" button **1** and the gauge **2** will start to recharge gradually.

The time required to fully recharge the "OV" gauge **2** is 30 seconds maximum.

**Note:** it is not necessary to wait for the gauge **2** to be fully recharged in order to activate the function. This is available as long as the gauge is not empty.

## "OVERTAKE" FUNCTION

### Conditions for non-activation of the system

Certain conditions will prevent activation of the system:

- engaging **R** or **N** position;
- the "Save" mode is activated. In this case, the "Overtake unavailable in this DRIVE MODE" message is displayed on the instrument panel → **281**;
- the "OV" gauge **2** is empty;
- the traction battery charge level is too low;
- failure of a vehicle system (ESC, etc.).

### Operating limits and temporarily unavailability

Under certain conditions (battery or engine temperature too hot or too cold, etc.), the availability of the "Overtake" function may be limited or even temporarily inhibited.

When the function is limited, the "OV" gauge **2** on the instrument panel may not be fully recharged.

If the function is inhibited, the "OV" gauge **2** is displayed as empty on the instrument panel. If you press the "OV" button **1**, the "Overtake unavailable" message appears on the instrument panel to inform you that the function is unavailable.

# GEAR CONTROL

## Selection controls



The **R**, **N** and **D** switches can be used to engage various gearbox positions:

- **R**: reverse;
- **N**: neutral;
- **D**: drive in automatic mode.

The engaged position is displayed on the instrument panel as a reminder.

### To engage **N** position

With the vehicle stationary and the engine running, press the brake pedal and briefly press the **N** switch (the built-in indicator light on the **N** switch lights up in white and **N** is displayed on the instrument panel).

### Driving in automatic mode

With the vehicle stationary, the engine running and your foot on the brake pedal, briefly press the **D** switch (the built-in indicator light on the **D** switch lights up in white and **D** is displayed on the instrument panel).

**Note:** with **D**, **R** position engaged, with the vehicle stationary, the vehicle will move forward as soon as you release the brake pedal (without pressing on the accelerator pedal).

If one of the conditions is not met, the current position flashes for approximately five seconds and the "Press brake pedal" message is displayed on the instrument panel for approximately five seconds.

In most traffic conditions, you will not have to touch the switches.

**Note:** with the engine running and the vehicle moving at between 0 and 9 mph (14 km/h), with **N** or **R** position engaged, it is not necessary to press the brake pedal to engage **D** position. This is useful during parking manoeuvres requiring a number of alternate forward and reverse movements.

### To select reverse gear

With the vehicle stationary, the engine running and your foot on the brake pedal, briefly press the **R** switch (the

built-in indicator light on the **R** switch lights up in white and **R** is displayed on the instrument panel).

**i** With **D**, **R** position engaged, with the vehicle stationary, the vehicle will move forward as soon as you release the brake pedal (without pressing on the accelerator pedal).

If the brake pedal is not pressed down, the current position flashes for approximately five seconds and the indicator light **1** remains displayed on the instrument panel.

**Note:** with the engine running and the vehicle moving at between 0 and 6 mph (10 km/h), with **N** or **D** position engaged, it is not necessary to press the brake pedal to engage **R** position. This is useful during parking manoeuvres requiring a number of alternate forward and reverse movements.

### Parking the vehicle

With the vehicle stationary, press the brake pedal and briefly press the **N** switch.

## GEAR CONTROL

**Note:** once engaged after the engine is stopped, **N** position is maintained until the vehicle ignition is switched on again.

**Ensure that the parking brake is engaged and that the vehicle is immobilised → 164.**



The electronic parking brake can be used to immobilise the vehicle. Before leaving the vehicle, check that the electronic parking brake is fully applied. The application of the electronic parking brake is confirmed by the illumination of the indicator light on the electronic parking brake switch

and the  warning light on the instrument panel until the doors are locked. Depending on the vehicle, a label is affixed at the top of the windscreen as a reminder → 164.



Engaging the gear control **N** position does not mechanically lock the drive wheels: ensure that the vehicle is immobilised before leaving the vehicle.



For safety reasons, do not switch off the ignition before the vehicle has come to a complete standstill.



An impact to the underside of the vehicle while manoeuvring (e.g. striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g. deformation of an axle). To avoid any risk of accident, have your vehicle checked by an approved dealer.

### Operating faults

In the event of an engine fault or an electrical fault (battery fault, etc.), make sure that the vehicle is properly immobilised.

# REGENERATIVE BRAKING SYSTEM

## Introduction

3



1



2

By releasing the accelerator, the vehicle uses regenerative braking to slow down the vehicle.

All of this energy is converted to electricity to recharge the traction battery.

The steering wheel control **2** can be used to increase or decrease regenerative braking.



The regenerative braking should under no circumstances be used as a substitute for the brake pedal.




Under certain conditions (fully charged battery too hot or too cold, engine hot, etc.), the regenerative braking system performance will be limited, resulting in reduced engine braking when releasing the accelerator pedal.

On the instrument panel, the power meter indicator **1** informs you of the available regenerative braking potential. Nevertheless, the braking capacity when using the brake pedal will be preserved and will still enable the vehicle speed to be limited.

# REGENERATIVE BRAKING SYSTEM

## Regenerative braking change control 2




The touch control **2** can be used to change the regenerative braking level:

- turn the control **2** towards **A** to increase the engine braking when you release the accelerator pedal;
- turn the control **2** towards **B** to reduce the engine braking when you release the accelerator pedal.

The level selected using control **2** does not act as long as the Adaptive Cruise Control function is activated → **242**.

## Driving with the regenerative braking control



## Regenerative braking levels

Depending on the level selected using the control **2**, the indicator **3** informs you of the regenerative braking level:

- **C**: "Free-wheel" level for a smooth and economical ride, associated to Save mode by default. Requires you to drive with greater anticipation;
- **D**: low engine braking when releasing the accelerator pedal, associated to Normal and Sport mode by default;
- **E**: medium engine braking when releasing the accelerator pedal;
- **F**: high engine braking when releasing the accelerator pedal.

**Note:** when the engine is switched off, the current regenerative braking level is stored.

# PARKING BRAKE

## Electronic parking brake

### Assisted operation

3



### Applying the electronic parking brake

**With the vehicle stationary**, the electronic parking brake can be used to immobilise the vehicle:

- **by pressing the engine start/stop button 1** ;
- or
- **when the driver's seat belt is unfastened**;
- or
- **when the driver's door is opened**.



The electronic parking brake can be used to immobilise the vehicle. Before leaving the vehicle, check that the electronic parking brake is fully applied. Warning light 2 on switch 3 and warning

light  on the instrument panel illuminate to show that the parking brake is applied but switch off when the doors are locked. Depending on the vehicle, a sticker is located on the upper section of the windscreen to remind you of this.

In all other instances, the electronic parking brake is not applied automatically. Manual mode must be used.

To confirm that the electronic parking

brake is applied, the  warning light on the instrument panel and warning light 2 on the switch 3 light up.

After the engine is switched off, the indicator light 2 goes out a few minutes after the electronic parking brake has

been applied and the  warning

## PARKING BRAKE

light goes out when the vehicle is locked.

**Note:** in some situations (electronic parking brake failure, manual release of the parking brake, etc.), to indicate that the electronic parking brake is released a beep sounds and the "WARNING: Apply Parking Brake" message appears on the instrument panel:

- **with the engine on:** when the driver's door is opened;
- **with the engine off:** when a front door is opened.

In this case, pull and release the switch **3** to apply the electronic parking brake.

### Assisted release of the parking brake

The parking brake is released:

- once the vehicle starts to accelerate;
- or
- when shifting from **N** to **R/D**.



The electronic parking brake can be used to immobilise the vehicle. Before leaving the vehicle, check that the electronic parking brake is fully applied. Warning light **2** on switch **3** and warning light  on the instrument panel illuminate to show that the parking brake is applied but switch off when the doors are locked. Depending on the vehicle, a sticker is located on the upper section of the windscreen to remind you of this.

### Manual operation

You can apply the electronic parking brake manually.

### Manually applying the electronic parking brake

Pull the switch **3**. Warning light **2** and the  warning light appear on the instrument panel.

### Manually releasing the electronic parking brake

Press the button **1** without pressing the pedals to switch the ignition on. Press the brake pedal then press switch **3**: the indicator light **2** for the

switch and the  warning light displayed on the instrument panel both disappear.

### Brief stop

To apply the electronic parking brake manually (when stopping at a red light, stopping when the engine is running, etc.): pull and release the switch **3**. The brake is released as soon as the vehicle is started up again.

### Special cases

To park on a slope or while towing a trailer, for example, pull switch **3** for a few seconds to enable maximum braking.

For safety reasons, the automatic release is deactivated when the driver's door is open or not shut properly, the driver's seatbelt is unfastened and the engine is running (in order to prevent the vehicle from moving without the driver). The "Release Parking Brake" message appears on the instrument

## PARKING BRAKE

panel when the driver presses the accelerator pedal.

### Operating faults

– If there is a fault, the  warning light illuminates on the instrument panel accompanied by the "Check Parking Brake" message and, in some

cases, the  warning light. Contact your approved Dealer straight away.

– If there is an electronic parking

brake fault, the  warning light comes on, along with the "Parking brake failure" message, a beep and, in

some cases, the  warning light.  
– In the event of a parking brake failure, with the instrument panel off, the indicator light on switch **2** will flash.

This means that you must stop as soon as traffic conditions allow.



If the "Electric System Failure" or "Check battery" or "Parking brake failure" message appears, you must immobilise the vehicle by pulling the switch **3** for approximately 10 seconds.

If the conditions and the slope require it, chock the wheels of the vehicle.

#### **Risk of loss of immobilisation of the vehicle.**

Call an approved dealer.



If no lights or sounds are apparent, this indicates a fault in the instrument panel. This indicates that it is essential to stop immediately (as soon as traffic conditions allow). Ensure that the vehicle is correctly immobilised and contact an approved Dealer.



Never leave your vehicle without the parking brake applied and without switching off the engine. This is because when the vehicle is stationary with the engine running and a gear engaged, the vehicle may begin to move if you accelerate.

#### **There is a risk of accidents.**

## PARKING BRAKE

"Autohold" function

# PARKING BRAKE

## Introduction

Vehicle stopped (e.g. at a red light, an intersection, a traffic jam, etc.), the function ensures braking force even when the driver releases the brake pedal.

The braking force is released as soon as the driver accelerates sufficiently with a gear engaged.

## Activation



Press the switch **1**.

The warning light on the switch **2** comes on to confirm that the function is activated.

## Deactivation

Press the switch **1**. If your vehicle is maintained by braking force you can also press the brake pedal.

The warning light on the switch **2** disappears to confirm that the function is deactivated.

If the braking force is maintained, the parking brake is applied automatically when:

- the driver opens the door;
- or
- the driver unfastens their seat belt;
- or
- the vehicle is immobilised for more than approximately three minutes.

 Upon each start-up, the function continues the mode set at the time the engine was last switched off.



The electronic parking brake can be used to immobilise the vehicle. Before leaving the vehicle, check that the electronic parking brake is fully applied. The indicator light is lit on switch **2** and the



warning light appears on the instrument panel until the doors lock. Depending on the vehicle, a sticker is located on the upper section of the windscreen to remind you of this.

## Conditions for maintaining the braking force

The following conditions must be met:

- the driver's door is closed;
- and
- the driver's seat belt is fastened;
- and
- the electronic parking brake is released;
- and
- the vehicle is not stationary on a very steep slope.

## PARKING BRAKE

The maintaining of braking force is confirmed by the  warning light on the instrument panel.

### Conditions for interrupting the braking force

The following conditions must be met:

- the driver accelerates sufficiently with a gear engaged;

or

- the driver disables the function.

The  warning light disappears from the instrument panel.

# ENVIRONMENT

## Introduction

Your vehicle has been designed with respect for the **environment** in mind for its entire service life: during its production, usage and at the end of its service life.

## Manufacture

Your vehicle has been manufactured at a factory which complies with a policy to reduce the environmental impact on the surrounding areas (reduction of water and energy consumption, visual and noise pollution, atmospheric emissions and waste water; sorting and reusing waste).

## Please make your own contribution towards protecting the environment too.

– Parts and vehicles at the end of their life must not be thrown away. They must be handed to a legal entity that complies with environmental standards.



61496

## Recycling

Your vehicle is at least 85% recyclable and at least 95% recoverable.

To achieve these objectives, many of the vehicle components have been designed to enable them to be recycled.

The materials and structures have been carefully designed to:

- allow these components to be easily removed and reprocessed by specialist companies;
- promote a circular economy (re-use, recycling, recovery, etc.)

This is particularly true for electrified vehicle batteries.

In order to preserve raw material resources, your vehicle also includes many parts made from recycled plastics or renewable materials.

- Worn parts and components that are replaced during routine vehicle maintenance, such as tyres, must be disposed of at dedicated collection points.
- Worn **electrical** and **electronic** components that are replaced (such as batteries, etc.) must not be thrown away as rubbish. Take them to an approved Dealer or consult your local authority for information on appropriate recycling facilities.
- To optimise the recycling of your vehicle at the end of its life, you can contact an authorised dealer or visit the manufacturer's website to be directed to collection points that guarantee respect for the environment complying with local laws.

# DRIVING ADVICE, ECO-DRIVING

## Introduction

Range is accredited in according to a standard regulatory method. Identical for all manufacturers, this enables vehicles to be compared with one another.

Range in real time depends on vehicle usage conditions, equipment fitted and the user's driving style. To optimise range, please refer to the following advice.

Depending on the versions, you will be provided with functions which enable you to lower energy consumption:

- on the instrument panel:
  - the power meter;
- on the multimedia screen:
  - data relating to your energy consumption;
  - an energy consumption graph;
  - scores based on your driving style;
  - Eco driving advice;
  - a route planner;
  - a Save driving mode.

## Power meter



(on the instrument panel)

The charge meter gives you a real-time view of the energy consumed or recovered when the vehicle is moving.

### "Energy recovery" A usage zone

When driving, if you lift your foot off the accelerator pedal or press the brake pedal, the motor generates electrical current during deceleration, and this energy is used to slow down the vehicle and recharge the traction battery → 162.

### "Optimal" B usage zone

Indicates economical driving, balanced between recovery and energy expenditure.

## "Energy consumption" C usage area

The traction battery supplies the electrical energy required for the motor to move the vehicle.



The presence and display of this information depends on the ambient setting selected → 125.

## Journey record

On equipped vehicles, once the engine is switched off, a "Journey log" is displayed on the multimedia screen 3. This log shows the information relating to your last journey:

- your average energy consumption;
- the number of miles/kilometres travelled;
- an overall grade taking into account acceleration, braking anticipation and your skill in managing speed;
- advice to enable you to improve your rating.

Please refer to the multimedia instructions for further information.

## Navigation system

Using the information available on your navigation system (traffic information,

## DRIVING ADVICE, ECO-DRIVING

nearest charging station, etc.) makes it easy to manage your journey and optimise charging times.

### Save mode

Save mode is a function that optimises vehicle range. It acts on some of the vehicle's energy-consuming systems (air conditioning, etc.) and on the vehicle's behaviour (acceleration, cruise control, deceleration, etc.)

### Activation/deactivation from the multimedia screen 3



Depending on the vehicle, to activate or deactivate the function, please refer to the multimedia instructions.

### Activation/deactivation using the switch 4



Depending on the vehicle, press the switch 4.

While driving, it is possible to exit Save mode temporarily in order to improve the engine performance.

To do this, press the accelerator pedal firmly and fully. Save mode is reactivated when you take pressure off the accelerator pedal.



While Save mode is activated, the vehicle speed is limited to approximately 81 mph (130 km/h).

## VEHICLE RANGE: ADVICE

In real usage, the range of an electric vehicle may vary depending on several factors over which you have partial control, which may make a considerable difference to the vehicle range.

These factors are:

- speed and driving style;
- road type;
- heating level;
- tyres;
- use of electrical accessories;
- vehicle loading.

Furthermore, activating Save mode enables the vehicle to automatically take charge of all energy consumers (engine power, etc.) in order to reduce their consumption to the fullest possible extent ➔ 171.

### Speed and driving style



Driving at high speed will significantly reduce your vehicle's range.

Examples (at a steady speed):

- reducing the speed from approximately 80 mph (130 km/h) to 68 mph (110 km/h) allows you to save up to around 20% of fuel range;
- reducing your speed from approximately 56 mph (90 km/h) to 50 mph (80 km/h) allows you to save up to around 10% of fuel range.

"Sporty" driving reduces your vehicle's range: opt for a "smoother" driving style.

#### Advice:

- drive at a constant speed;

- keep an eye on the tools available to you to view the driving conditions (current fuel consumption, journey record, etc.) ➔ 171;
- adapt your driving style to avoid excessive energy consumption;
- favour energy recovery: anticipate traffic changes by taking your foot off the accelerator pedal or braking gradually.

### Road type




Do not try to maintain the same speed up a hill; accelerate no more than you would on the level. Keep your foot in the same position on the accelerator pedal.

# VEHICLE RANGE: ADVICE

## Heating levels

62429



3


The use of heating or air-conditioning reduces vehicle range.

To maintain your vehicle range, we recommend that you select the "programming" mode before using the vehicle → 291.

## Vehicle loading

Avoid pointlessly overloading your vehicle.

## Tyres



An under-inflated tyre increases energy consumption. Comply with the specified tyre pressures for your vehicle.

When driving, use tyres made by the same manufacturer, with the same dimensions, type and structure as the original tyres. The use of non-recommended tyres may significantly reduce the vehicle range → 318.

# TYRE PRESSURE MONITORING SYSTEM

## Introduction



If the vehicle is equipped with the function, this system monitors the tyre pressure.

## Operating principle

Each wheel has a sensor in the inflation valve which periodically measures the tyre pressure.

The system displays the current pressures on the instrument panel **1** and alerts the driver in the event of insufficient pressure.

## Resetting the standard level for the tyre pressures

This should be performed:

- when the standard tyre pressure needs to be changed to adapt to usage conditions (empty, carrying a load, motorway driving, etc.);
- after swapping a wheel (however, this practice is not recommended);
- after changing a wheel.

It should always be done after checking the tyre pressure of all four tyres when cold.

Tyre pressures must correspond to the current usage of the vehicle (empty, carrying a load, motorway driving, etc.).



If the vehicle is equipped with a navigation system, the resetting procedure may also be carried out using the multimedia screen: please see the equipment instructions.



## Resetting procedure via the instrument panel **1**

Ignition on, **vehicle stopped**:

- repeatedly press the switch upwards/downwards **2** as many times as necessary to reach the "" tab « Tyre Pressure »;
- press downwards and hold (around 3 seconds) the **2** switch to start the reset.

The flashing tyres symbol indicates that the request to reset the reference tyre pressure value has been acknowledged.

Reset can take several minutes of driving.

If the reset is followed by short journeys, the step 3 display in the table of

## TYRE PRESSURE MONITORING SYSTEM

messages may remain after several successive restarts.

**Note:** the tyre pressure reference value cannot be less than that recommended and indicated on the edge of the door.

### Resetting procedure via the multimedia screen 3



The resetting procedure must be carried out while the vehicle is stationary and the ignition is switched on.

Please refer to the multimedia instructions for further information.



For your own safety, the

**STOP**

warning light requires you to stop immediately, as soon as traffic conditions allow.

# TYRE PRESSURE MONITORING SYSTEM

## Message display

The table shows the possible messages related to the tyre resetting procedure.

Steps	Displays	Messages	Readings
1		Reset tyre pressure, press and hold	With the ignition on and the vehicle stationary, to start resetting the pressure of all four tyres, press downwards and hold the switch <b>2</b> .
2		Tyre pressure learning started	The "---" symbols in front of each wheel will flash to indicate that the system has registered the tyre pressure reset for all four wheels.
3			The "---" symbols in front of each wheel will remain lit. This system resets the tyre pressure of all four tyres. You can now drive. <b>Note:</b> during the reset, tyre pressure monitoring remains in operation.
4			The pressure value of the four tyres is displayed: the resetting procedure is complete and successful.

# TYRE PRESSURE MONITORING SYSTEM

## Readjustment of tyre pressures

The pressure of the four tyres must be set when cold (refer to the label located on the edge of the driver's door).

If the tyre pressures cannot be checked when they are cold, the recommended pressures should be increased by 0.2 to 0.3 bar (3 PSI).

**Never deflate a hot tyre.**



This function is an additional driving aid.

The function does not take the place of the driver.

ver.

It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver. Check the tyre pressures once a month.

## Replacing wheels/tyres

Contact an approved dealer to replace the tyres and to find out about accessories compatible with the system that are available from the brand's Network: using any other accessory could affect the correct operation of the system.



### Changing a wheel

The system may take several minutes depending on use for the new wheel positions and pressures to be recognised; check the tyre pressures after all operations.

## Tyre repair product and inflation kit



As the valves are specifically designed, only use equipment approved by the network.

See pages → 321.

# TYRE PRESSURE MONITORING SYSTEM

## Tyre pressure faults

The information on the instrument panel signals any potential tyre pressure faults (e.g. deflated or punctured tyre). The

**STOP** warning light requires that, for your own safety, you stop the vehicle as soon as traffic conditions allow.

The table lists the warning messages which appear on the instrument panel **1** when the system detects a tyre pressure fault.

Indicator lights	Messages	Displays (depending on the vehicle)	Readings
 comes on (not flashing).	Adjust Tyre Pressure		The wheel and associated pressure value are displayed in yellow. This indicates that tyre under-inflation has been detected. Check and adjust the pressure of the four tyres then reset the system.
 +  comes on (not flashing).	Puncture		The wheel and associated pressure value are displayed in red. This indicates that the tyre concerned is punctured or severely underinflated. Adjust the pressure of the four tyres while cold and reset the system if the tyre is deflated. Replace the tyre (or have it replaced) if it is punctured.
 flashes then stays on, accompanied by the 	Check Tyre Pressure Sensors		One or more wheels are no longer displayed. This indicates that at least one wheel is not fitted with a sensor or that the sensor is faulty. Consult an approved Dealer.
 comes on (not flashing).			This indicates that the system has not been able to determine the pressure of each tyre. This may be caused by the use of a sensor not recommended by an approved dealer. The tyre pressure sensor monitoring system remains in operation.

# DRIVER CORRECTION DEVICES AND AIDS

## Introduction

Depending on the vehicle, they comprise:

- the **ABS (anti-lock braking system)**;
- **of the electronic stability program ESC with understeer control and traction control**;
- **emergency braking assistance with (depending on the vehicle) braking anticipation**;
- **hill start assistance**;
- **multi-collision braking**;
- **regenerative braking system**.

Other driving assistance systems are described in this leaflet.



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions. However, the functions do not take the place of the driver. **They do not increase the vehicle's limits and should not encourage you to drive more quickly.** Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).

## ABS (anti-lock braking system)

Under heavy braking, the ABS prevents the wheels from locking, allowing the stopping distance to be managed and keeping control of the vehicle.

Under these circumstances, the vehicle can be steered to avoid an obstacle whilst braking. In addition, this system can increase stopping distances, particularly on roads with low surface grip (wet ground etc.).

You will feel a pulsation through the brake pedal each time the system is activated. The ABS does not in any way improve the vehicle's "physical" performance relating to the road surface and roadholding. It is still **essential** to follow the rules of good driving practice (such as driving at a safe distance from the vehicle in front etc.).



In an emergency, apply **firm and continuous pressure** to the brake pedal.

There is no need to pump it repeatedly. The ABS will modulate the force applied in the braking system.

## Operating faults

–  and  are lit on the instrument panel accompanied, depending on the vehicle, by the "Check ABS", "WARNING: Check Braking System" and "Check ESC" messages: the ABS, ESC and emergency braking assistance are deactivated **but braking is still possible**;

– , ,  and

 lit on the instrument panel ac-

## DRIVER CORRECTION DEVICES AND AIDS

accompanied by the "WARNING: Braking System" message: **this indicates a fault with the braking system.**

In both cases, please contact an approved dealer.



Your braking systems are partially operational. However, **it is dangerous to brake suddenly** and it is essential to stop immediately, as soon as traffic conditions allow. Call an approved dealer.

### Electronic stability control ESC with understeer control and traction control

#### Electronic stability program ESC

This system helps you to keep control of the vehicle in critical driving conditions (avoiding an obstacle, loss of grip on a bend, etc.).

#### Operating principle

A sensor in the steering wheel detects the direction selected by the driver.

Other sensors throughout the vehicle measure the actual direction.

The system compares driver input to the actual trajectory of the vehicle and corrects the trajectory if necessary by

controlling the braking of certain wheels and/or engine power. In the event that the system is engaged, indi-

cator light  flashes on the instrument panel.

#### Understeer control

This system optimises the action of the ESC in the case of pronounced understeering (loss of front axle road holding).

#### Traction control

This system helps to limit wheelspin of the drive wheels and to control the vehicle when pulling away accelerating or decelerating.

#### Operating principle

Using the wheel sensors, the system measures and compares the speed of the drive wheels at all times and slows down their over-rotation. If a wheel is starting to slip, the system brakes automatically until the drive supplied becomes compatible with the level of grip under the wheel again.

#### Operating faults

When the system detects an operating fault, the "Check ESC" message and

the  and  warning lights appear on the instrument panel. In this

case, the ESC and traction control system are deactivated.

Consult an approved dealer.

### Emergency brake assist

This system supplements the ABS and helps reduce vehicle stopping distances.

#### Operating principle

The system is for detecting an emergency braking situation. In this case, the braking system immediately develops maximum power and may trigger ABS regulation.

ABS braking is maintained as long as the brake pedal is applied.

#### Brake lights come on

Depending on the vehicle, these may flash in the event of sudden deceleration.

#### Braking anticipation

Depending on the vehicle, when you rapidly release the accelerator, the system anticipates the braking manoeuvre in order to reduce stopping distances.

#### Special cases

When using the cruise control:

– if you use the accelerator pedal when you release it, the system may be triggered;

## DRIVER CORRECTION DEVICES AND AIDS

– if you do not use the accelerator, the system will not be triggered.

### Operating faults

When the system detects an operating fault, the "WARNING: Check Braking System" message appears on the in-

strument panel along with the  warning light.

Consult an approved dealer.



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions. These functions do not take the place of the driver. **They do not increase the vehicle's limits and should not encourage you to drive more quickly.** Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).

### Hill start assistance

Depending on the gradient of the incline, this system assists the driver when starting on a hill. It prevents the vehicle from rolling backwards by automatically applying the brakes when the driver lifts his/her foot off the brake pedal to depress the accelerator pedal.

### System operation

It only operates when the of the gear control is in a position other than **N** and the vehicle is completely stationary (brake pedal pressed).

The system holds the vehicle for approximately **2 seconds**. The brakes are then gradually released (the vehicle will move according to the slope).



The hill start assistance system cannot completely prevent the vehicle from rolling backwards in all situations (extremely steep gradients etc.).

In all cases, the driver may depress the brake pedal to prevent the vehicle from rolling backwards.

The Hill Start Assist function should not be used for prolonged stops: use the brake pedal.

This function is not designed to immobilise the vehicle permanently.

If necessary, use the brake pedal to stop the vehicle.

The driver must remain particularly vigilant when driving on slippery or low-grip surfaces.

**Risk of serious injury.**

### Multi-collision braking

Multi-collision braking reduces the risk of an additional collision after an accident by temporarily bringing your vehicle to a standstill.

# DRIVER CORRECTION DEVICES AND AIDS

## Operating principle

When the airbag system detects a collision, the pretensioners or airbags are triggered → 80 and the "Multi-collision braking" function activates the Electronic Stability Program (ESC) to brake the vehicle.

Multi-collision braking is deactivated during operation if:

– the braking force generated by the driver pressing the brake pedal is greater than the force produced by the automatic braking triggered by the function.

**Note:** multi-collision braking requires the proper functioning of your vehicle's braking system.

## Operating faults

When the system detects an operating fault, the "Check Post-collision" mes-

sage and the  warning light appear on the instrument panel.

In this case, the function is deactivated. Consult an approved dealer.

## Regenerative braking system

When braking, the regenerative braking system can convert the energy produced by the vehicle deceleration into electric energy.

This will recharge the 400 V traction battery and provide greater vehicle range.

## Operating faults

–  lit on the instrument panel, accompanied by the "WARNING: Check Braking System" message: **braking assistance is still operational.**

Under these conditions, the feel of applying the brake pedal may be different.

You are recommended to apply strong continuous pressure to the pedal.

Please see an authorised dealer.

–  lit on the instrument panel, accompanied by the "WARNING: Braking System" message: **this indicates a fault with the braking system.**

Please call an authorised dealer.



For your own safety, the

 warning light requires you to stop immediately, as soon as traffic conditions allow. Switch off the engine and do not restart it. Call an approved dealer.

# ADDITIONAL DRIVING AID FUNCTIONS

## My Safety

### Introduction

The "My Safety" function can be used to deactivate or activate a set of driver assistance functions simultaneously.

Depending on the vehicle, you can configure the "My Safety" function from the multimedia screen by selecting the driving aid functions to be switched off as a group.

### Operation



### "All On" mode

Depending on the vehicle, the functions and configurations of driving assistance concerned are:

- overspeed sound alert → 217;
- lane departure prevention → 185;
- driver vigilance warning → 215;
- emergency lane departure prevention → 192.

When the "All On" mode is activated: the "My Safety All ON selected" message is displayed on the instrument panel to confirm this. The driving aids that are available in the mode are activated.

### "Custom" mode

From this mode you can **deactivate** or **reactivate** certain driving aids that are available in the "All On" mode previously configured using the "My Safety Custom" setting.

With the ignition on, **press** button **1** twice in succession to activate the "Custom" mode. The first time you press it, the "Press again for My Safety Perso" message is displayed on the instrument panel. On the second press, the indicator light on the button **1** goes out. The "Custom" mode is activated. The "My Safety Perso selected" message is displayed on the instrument panel.

To switch back to "All On" mode, **press once** on the button **1**. The indicator light on button **1** lights up.



Depending on the vehicle and on the length of time following the last time the engine was stopped, the "All On" mode is reactivated:

- when the vehicle is unlocked;
- or
- when a door is opened;
- or
- when the engine is restarted.

### Configuring "My Safety Custom"



For safety reasons, carry out any adjustments while the vehicle is stationary.

## ADDITIONAL DRIVING AID FUNCTIONS



The "My Safety Custom" settings saved for the "Custom" mode are stored when the engine is last stopped or when the doors are locked.

### Configuration from the multimedia screen 2



Please refer to the multimedia instructions for more information.

## Lane departure prevention

### Introduction



Using information from the **1** camera, the function triggers corrective action on the vehicle steering system when a continuous or broken line is crossed or when approaching the roadside (divider, barrier, pavement, embankment, etc.) without activating the direction indicator lights.

Depending on the setting, in the event of crossing a broken line without activating the direction indicator lights, the function:

- warns the driver without corrective action on the steering system;
- or

- performs corrective action on the steering system.



You can **retake control of the vehicle** at any time by operating the steering wheel.

### Location of the camera 1

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

## ADDITIONAL DRIVING AID FUNCTIONS

### Activation/deactivation

#### From the multimedia screen 2



Please refer to the multimedia instructions for more information.

#### Using the switch 3



– **To deactivate the function**, if it has been deactivated from the "Custom" mode of the "My Safety" function → 184, press switch 3 twice. The



warning light appears in yellow on the instrument panel.

– **To reactivate the function**, press

the switch 3 once. The  warning light is displayed on the instrument panel.

### Operation



When the function is activated, the



warning light and the left-hand and right-hand line indicators 4 are displayed in grey on the instrument panel.

**The function is ready to alert or intervene** if the vehicle speed is over approximately 43 mph (70 km/h) and if

the  warning light and right-hand or left-hand line indicators 4 are displayed in white.

**The function is in operation** if the vehicle:

– approaches a roadside without activating the direction indicators;

## ADDITIONAL DRIVING AID FUNCTIONS

- crosses a continuous line without activating the direction indicators;
- crosses a broken line without activating the direction indicators, if the "Operation on broken line" setting is selected.

In these cases:

- the function triggers an action on the vehicle's steering system to correct the vehicle trajectory;

- the  warning light and the indicator **4** on the side of the breached line changes to yellow on the instrument panel.

If the corrective action on the steering

system is not sufficient, the  warning light and the indicator **4** on the side of the breached line change to red on the instrument panel, accompanied by a vibration on the steering wheel.

If the "Operation on broken line" setting is not selected, **the function sounds the alarm** if the vehicle crosses a broken line without activating the direction indicators, and there is no roadside close enough to the line.

In this case, the function warns the driver:

- by a vibration in the steering wheel; and

- the  warning light and the indicator **4** on the side of the breached line change to red on the instrument panel.

**Note:** on bends, the function allows for slightly cutting the bend.

### Special cases

#### "Keep control" warning

- If the system is operating and does not detect any activity on the steering wheel, the "Keep control" message appears on the instrument panel accompanied by a beep and, depending on

the vehicle, the  warning light appears in red until the driver has regained control of the vehicle.

- If the system has been in operation for too long, the "Keep control" message appears on the instrument panel accompanied by a beep and, depend-

ing on the vehicle, the  warning light appears in red and the indicator **4** on the side of the line concerned flashes until the driver has regained control of the vehicle.



You can interrupt the trajectory correction at any time by moving the steering wheel.

### Vehicle equipped with "Active Driver Assist"

If the "Lane Centring" function is activated at the same time as the "Lane departure prevention" function, the display of the warning light will vary as follows:

- the "Lane centring" function is in operation: the green  warning light

replaces the  warning light displayed in white or grey on the instrument panel. Therefore, the "Lane Centring" function status is given priority in terms of informing you;

- the "Lane centring" function is put on standby and the "Lane departure prevention" function neither alerts nor inter-

venes: the grey  warning light

replaces the  warning light displayed in white or grey on the instrument panel. Therefore, the "Lane Centring" function status is given priority in terms of informing you;

## ADDITIONAL DRIVING AID FUNCTIONS

– the "Lane Centring" function is put on standby while the "Lane Departure Prevention" function is ready or in operation:

the  warning light is displayed in red or in yellow on the instrument panel. Therefore, the "Lane Departure Prevention" function status is given priority in terms of informing you.

In any case, you are informed at all times of the status of the function when it controls the steering system of your vehicle. The most useful information is always displayed.

### Function temporarily unavailable/ disabled

The system is temporarily unavailable or disabled when:

- very fast lane departure;
- driving continuously on a line;
- approximately four seconds after changing lanes;
- tight bends;
- impaired visibility;
- one of the direction indicators is activated;
- activating the hazard warning lights;
- engaging reverse gear;
- strong acceleration;
- the lane width changes;
- operation of the Electronic Stability Control system;

- operation of the anti-lock braking system;
- the active emergency braking system is triggered;
- intervention of another function that controls the steering system, such as the "Lane Centring" function.

If the function is unavailable, the  warning light and left-hand and right-hand correction indicators **4** change to grey on the instrument panel.

When the front camera is obscured, the "Front camera no visibility" message is displayed on the instrument panel. Clean the area where the sensors are located

### Automatic deactivation

The function is automatically deactivated when:

- the vehicle dynamics control system is deactivated;
- the electronic stability system is malfunctioning;
- the anti-lock braking system is malfunctioning;
- a towbar is electrically connected to the trailer hitch socket;
- the  warning light appears.

When the function is deactivated, the



warning light is displayed in yellow on the instrument panel.

### Adjusting settings from the multimedia screen **2**



## ADDITIONAL DRIVING AID FUNCTIONS

### Using the switch 3



To access the function settings from the multimedia screen **2**, refer to the multimedia instructions:

– "Operation on broken line": use this setting to select the function response if the vehicle crosses a broken line without activating the direction indicators:

- selected setting: the function may trigger an action on the vehicle's steering system to correct the vehicle trajectory;
- setting not selected: the function can warn the driver by means of a vibration at the steering wheel without correcting the vehicle trajectory.

– "Vibration": adjust the steering wheel vibration for the "Lane departure prevention" function;

– "Lane exit anticipation": adjust the line detection sensitivity level. To do this, select:

- "Late": line detected upon crossing;
- "Standard": line detected on approach;
- "Early" line detected nearby.

Please refer to the multimedia instructions for further information.

### Operating faults

When the system detects an operating fault, the left-hand and right-hand line

indicators and the  warning light appear in yellow on the instrument panel.

In some cases, they are accompanied by the following message:

- « Driving assist unavailable » ;
- or
- « Check Front camera » ;
- or
- « Check Driving assist » .

Consult an approved dealer.

# ADDITIONAL DRIVING AID FUNCTIONS

## Warnings



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

### **System servicing/repairs**

- In the event of an impact, the camera alignment may be changed, and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the camera is located (repairs, replacements, windscreen modifications etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

### **In the event of system disturbance**

Some conditions can disturb or damage the system's operation, such as:

- windscreen obscured (by dirt, ice, snow, condensation etc.);
- a complex environment (tunnel, etc.);
- poor weather conditions (snow, rain, hail, black ice, etc.);
- poor visibility (night, fog, etc.);
- the road markings are irregular or difficult to distinguish (e.g. partially erased, excessive spacing, uneven road surface, etc.);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction; etc.);
- the road is narrow, winding or undulating (tight bends, etc.);
- closely following a vehicle travelling in the same lane.

In this case, the function "Lane departure prevention" may trigger incorrectly or not at all.

### **Risk of unwanted, incorrect correction or no correction of trajectory.**

#### **Deactivating the function**

You must deactivate the function if:

- the area of the camera has been damaged (on the windscreen side or the interior rear-view mirror side);
- the road is slippery (snow, black ice, aquaplaning, gravel etc.);
- poor visibility (night, fog, etc.);


## ADDITIONAL DRIVING AID FUNCTIONS

- the windscreen is cracked or distorted (do not carry out windscreen repairs in this area; have it changed by an approved dealer);
- the vehicle is towing a trailer or a caravan;
- the vehicle is entering an area with several surface markings (an area with road works etc.).

## ADDITIONAL DRIVING AID FUNCTIONS

### Emergency lane departure prevention

#### Introduction



Using information from the front radar **2** and the camera **1**, the function triggers corrective action on the vehicle steering system in the event of a risk of collision with a vehicle coming from the opposite direction in the adjacent lane, without the direction indicator having been activated.

Depending on the vehicle, using information from the side radars **3** and the camera **1**, the function triggers corrective action on the vehicle steering system in the event of a risk of collision with a vehicle moving at the same speed or at a higher speed, if within the detection area of the rear radars.

 You can **retake control of the vehicle** at any time by operating the steering wheel.

 This system provides an additional driving aid. This system is not, under any circumstances, intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

#### Location of the camera **1**

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).

#### Location of the front radar **2**

Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted/attached front number plate), impacted, modified (including paintwork) or hidden by any accessory fitted on the front of the vehicle (on the front bumper, logo, etc.)

## ADDITIONAL DRIVING AID FUNCTIONS

### Location of the side radars 3

Ensure that the radar area is not obstructed (by dirt, mud, snow etc.), impacted or modified (including paint-work etc.).

### Activating/deactivating the function

From the "My Safety" switch **A**



Press switch **A** twice if the function has been disabled from the Personal mode of the "My Safety" function → 184.



To reactivate the function, press the switch **A**.

From the multimedia screen **B**



Please refer to the multimedia instructions for more information.

### Detection of an oncoming vehicle



## ADDITIONAL DRIVING AID FUNCTIONS



When driving at a speed between approximately 43 mph (70 km/h) and 68 mph (110 km/h), if there is a risk of collision with a vehicle coming from the opposite direction in an adjacent lane and within the detection zone **C**, without the direction indicator having been activated, the system:

– **warns you of a collision risk:**

the "Risk of collision" message is displayed on the instrument panel accompanied by the warning light **4** in red, the line on the relevant side and a beep. The symbol **5** appears for the relevant side on the instrument panel; and

– **triggers corrective action on the steering system.**




You can interrupt the trajectory correction at any time by moving the steering wheel.




This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

### If case of overtaking



## ADDITIONAL DRIVING AID FUNCTIONS



ken) and there is a risk of collision with a vehicle located in the blind spot **D** and it is moving in the same direction as your vehicle or with a vehicle that is rapidly approaching from behind in an adjacent lane that is in the detection area **E**, the system:

- **warns you about a risk of collision:** the warning light **6** flashes, the "Lateral obstacle detected" message is displayed on the instrument panel, accompanied by the warning light **4** in red, the line on the relevant side and a beep. The symbol **5** appears for the relevant side on the instrument panel; and
- **triggers corrective action on the steering system.**



While driving at a speed over approximately 43 mph (70 km/h), when approaching a line (continuous or bro-

- strong acceleration;
- the lane width changes;
- operation of the Electronic Stability Control system;
- operation of the anti-lock braking system;
- operation of the active emergency braking system;
- ...

The system cannot be activated when:

- the camera does not detect a line (solid or broken) on the relevant side;
- the camera does not simultaneously detect the two boundaries of the lane in which your vehicle is moving;
- reverse gear is engaged;
- the field of vision of the camera is obstructed;
- the front radar is obscured;
- depending on the vehicle, the rear radars are obscured;
- ...

Depending on the vehicle, if one of the side radars is obscured the message "Side radars no visibility" will appear on the instrument panel.

When the front radar is obscured, the "Front radar no visibility" message is displayed on the instrument panel.

When the front camera is obscured, the "Front camera no visibility" message is displayed on the instrument panel.

## ADDITIONAL DRIVING AID FUNCTIONS

Clean the area where the sensors are located.

### Automatically deactivating the function

The system is automatically deactivated when:

- the vehicle dynamics control system is deactivated;
- the electronic stability system is malfunctioning;
- the anti-lock braking system is malfunctioning;
- a towbar is electrically connected to the trailer hitch socket;

– the **STOP** warning light is displayed.

If the vehicle is equipped with a towbar that is recognised by the system, the message "Trailer: side radars unavailable" is displayed to inform you that the emergency lane departure prevention function has been deactivated.

If the vehicle is towing a trailer or caravan, unexpected or unnecessary corrections may occur. You can deactivate the system to avoid unexpected or unnecessary corrections.

### Operating faults

When the function detects an operating fault, the following messages may be displayed on the instrument panel:

- « Check Front camera » ;  
or
  - « Front radar to check » ;  
or
  - « Check Driving assist » ;  
or, depending on the vehicle,  
– « Check Side radars ».
- Consult an approved dealer.

# ADDITIONAL DRIVING AID FUNCTIONS

## Warnings



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

### **System servicing/repairs**

- In the event of an impact, the alignment of the camera or radar(s) may be altered and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the camera or radars are located (replacements, repairs, windscreen modifications etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

### **In the event of system disturbance**

Some conditions can disturb or damage the system's operation, such as:

- windscreen obscured (by dirt, ice, snow, condensation etc.);
- a complex environment (tunnel, etc.);
- poor weather conditions (snow, rain, hail, black ice, etc.);
- poor visibility (night, fog, etc.);
- the road markings are irregular or difficult to distinguish (e.g. partially erased, excessive spacing, distorted road surface...);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction; etc.);
- the road is narrow, winding or undulating (tight bends, etc.);
- closely following a vehicle travelling in the same lane.

In this case, the "lane departure prevention" function may be activated incorrectly or not at all.

### **Risk of unwanted, incorrect correction or no correction of trajectory.**

#### **Deactivating the function**

You must deactivate the function if:

- the camera area (on the windscreen side or the interior rear-view mirror side) or radar area(s) have been damaged;
- the road is slippery (snow, black ice, aquaplaning, gravel etc.);
- poor visibility (night, fog, etc.);

## ADDITIONAL DRIVING AID FUNCTIONS


- the windscreen is cracked or distorted (do not carry out windscreen repairs in this area; have it changed by an approved dealer);
- the vehicle is towing a trailer or a caravan;
- the vehicle is being towed (breakdowns);
- the vehicle is entering an area with several surface markings (area with road works, etc.);
- you are not driving on a paved road.

3

# ADDITIONAL DRIVING AID FUNCTIONS

## Blind spot warning


### Introduction



Using information from the sensors installed on each side of the rear bumper (zone **C**), the function warns the driver:

- when a vehicle is in the blind spot **A** and moving in the same direction as your vehicle;  
and/or
- when there is a risk of collision with a vehicle that is in zone **B** and moving faster than yours in an adjacent lane.

The function warns you when your vehicle is travelling at a speed above approximately 9 mph (15 km/h).




This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.



The function does not notify the driver if the other vehicles are not moving.

### Special feature



Ensure that zone **C** around the radars on each side of the rear bumper is not obstructed (by dirt, mud, snow, etc.). If a radar is obscured, the "Side radars no visibility" message will appear on the instrument panel. Clean the area where the sensors are located.

## ADDITIONAL DRIVING AID FUNCTIONS

### Warning light 1




A warning light **1** is located on each door mirror **2**.

#### Note:

- clean the **2** door mirrors regularly so that the warning lights **1** can be seen properly;
- if you overtake another vehicle, the warning light **1** will only come on if that vehicle remains for a long enough period in your vehicle's blind spot **A**.

### Displays

#### Display D



First warning: **direction indicator not activated**, the warning light **1** indicates that a vehicle is detected in the blind spot and/or that a vehicle is rapidly approaching from the rear in an adjacent lane.

#### Display E

**Direction indicator activated**, the warning light **1** flashes when the function detects a vehicle in the blind spot and/or a vehicle is rapidly approaching from the rear on the side towards which you will turn the steering wheel.

If you deactivate the direction indicator, the function will return to the initial warning (display **D**).

#### Conditions for non-function

- When driving on a road with tight bends;
- in reverse.

If the vehicle is equipped with a towbar recognised by the system, the "Trailer: blind spot warning off" message is displayed on the instrument panel to inform you that the function is not operational.

For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer.

#### Operating faults

If the system detects a fault, the "Check Side radars" message is displayed on the instrument panel.

Consult an approved dealer.

## ADDITIONAL DRIVING AID FUNCTIONS



Due to the presence of sensors behind the bumper, it is advisable to entrust any operation on the bumper (repair, replacement, paintwork, etc.) to a qualified professional.

# ADDITIONAL DRIVING AID FUNCTIONS

## Warnings



- The system's detection range operates according to a standard lane width. If you are driving in wide traffic lanes, the system might not be able to detect a vehicle in the blind spot.
- In the event of very bad weather conditions (heavy rain, snow, etc.), the system may be temporarily disrupted.

Remain aware of driving conditions.

**There is a risk of accidents.**



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The driver should always adapt their speed to the traffic conditions, regardless of the system indications.

The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

### **System servicing/repairs**

- In the event of an impact, radar alignment may be changed, and its operation will consequently be affected. Consult an approved dealer.
- Any work in the area where the radars are located (repairs, replacements, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

### **System disturbance**

Some conditions can disturb or damage the system's operation, such as:

- complex surroundings (metal bridges, tunnels, roads with barriers at the edge, etc.);
- poor weather conditions (snow, hail, black ice, etc.);
- the vehicle is fitted with a towbar that is not recognised by the system.

### **Risk of false alarms or absence of warnings**

If the system behaves abnormally contact an authorised dealer.

## ADDITIONAL DRIVING AID FUNCTIONS



### Limitation of the system operation

- The radar area should be kept clean and free of any modifications in order to ensure the proper operation of the system.
- Small objects moving close to the vehicle (motorcycles, bicycles, pedestrians, etc.) may not be recognised by the system.
- When turning into a bend, the radars may temporarily cease to detect vehicles in adjacent lanes.
- The function may warn you late when two other vehicles are approaching from the rear, side by side in the adjacent lanes (driving on a 3-lane road) and at a much higher speed than your vehicle.
- The system may not provide a warning when the other vehicles are travelling at a significantly different speed.
- If the vehicle is being overtaken by a long vehicle (e.g. heavy goods vehicle overtaking at a similar speed to the vehicle) the system may interrupt the warning before the end of the manoeuvre.
- The vehicle is travelling on a winding road.

## ADDITIONAL DRIVING AID FUNCTIONS

### Safe distance alert

#### Introduction



Using the information from the radar **2** and camera **1**, this function informs the driver of the time interval between their vehicle and the vehicle in front so that a safe stopping distance between the two vehicles can be maintained.

#### Location of the camera **1**

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).

#### Location of the radar **2**

Ensure that the radar area is not obstructed (by dirt, mud, snow, a badly fitted front number plate etc.), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

#### Activation/deactivation from the multimedia screen **3**



From the "Vehicle" world on your multimedia screen **3**, press the "Driving assistance" menu.


Activate or deactivate the "Following distance" function.



Each time the vehicle is started, the function continues the mode saved the last time the engine was stopped.

# ADDITIONAL DRIVING AID FUNCTIONS

## Operation



With the function activated, the indicator light **4** is displayed on the instrument panel and informs the driver of the distance between their vehicle and the vehicle in front.

- **A** (grey): function not operational;
- **A** (green): no vehicle detected;
- **B** (green): the time interval is greater than or equal to approximately two seconds (distance between the two vehicles adapted to your speed);
- **C** (yellow): the time interval is between approximately one and two seconds (insufficient distance between the two vehicles);
- **D** (red): the time interval is less than or equal to approximately one second

(very insufficient distance between the two vehicles).

If the interval between the two vehicles is less than approximately 0.5 second, the indicator light **4** on display **D**, will remain lit in red on the instrument panel.

Under certain conditions, the time interval may not be displayed:

- while cornering;
- when changing lane;
- if the vehicle in front is sufficiently far or outside the range of the radar or camera.

# ADDITIONAL DRIVING AID FUNCTIONS

## Warnings



The measurement is displayed for information: the system does not carry out any action on the vehicle. This function is not designed for use in urban conditions or for a dynamic driving style (sudden cornering, acceleration, braking, etc.), but rather for stable driving conditions.

The function does not interact with the braking system.

The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system.

Any work carried out in the area where the radar or camera is located (repairs, replacements, windscreen and/or bumper modifications, etc.) must be carried out by a qualified professional.

## ADDITIONAL DRIVING AID FUNCTIONS



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

### **System servicing/repairs**

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work carried out in the area where the radar and/or camera is located (replacements, repairs, windscreen and/or bumper modifications, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

### **In the event of system disturbance**

- obstruction of the windscreen or the bumper (by dirt, ice, snow, condensation etc.);
- a complex environment (metal bridge, tunnel, etc.);
- poor weather conditions (snow, hail, black ice, etc.);
- poor visibility (night, fog, etc.);
- poor contrast between the vehicle preceding it and the surrounding area (e.g. white vehicle in a snowy area, etc.);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction; etc.);
- the road is narrow, winding and undulating (tight bends etc.)

### **Risk of erroneous false alarms.**

## ADDITIONAL DRIVING AID FUNCTIONS

### Active emergency braking

#### Introduction



Using information from the camera **1** and the radar **2**, the system determines the distance between your vehicle:

– from the vehicle ahead in the same lane;

or

– from any oncoming vehicles in the context of a manoeuvre to change direction;

or

– and vehicles passing perpendicularly;

or

– and stationary vehicles;

or

– surrounding pedestrians and cyclists.

The system informs the driver if there is a risk of head-on collision to enable appropriate emergency manoeuvres (pressing the brake pedal and/or turning the steering wheel).

Depending on the reactivity of the driver, the system can assist with braking in order to limit damage or prevent a collision.

**The system is otherwise inactive and does not trigger an alert.**



This function is an additional driving aid.

This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.



**This system can apply maximum braking to the vehicle** until it is completely stationary if necessary.

For safety reasons, always wear your seat belt when travelling in your vehicle and make sure that it is loaded so that no items can be thrown forward and hit the occupants.

#### Location of the camera **1**

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).

#### Location of the radar **2**

Make sure that the area around the radar is not obscured (by dirt, mud, snow or an incorrectly fitted number plate), impacted, altered (including paintwork) or hidden.

#### Operation

When driving, when there is a risk of collision, the system:

– **alerts you of a collision risk:** the "Detected obstacle" message appears on the instrument panel accompanied by a beep.

## ADDITIONAL DRIVING AID FUNCTIONS

**Note:** if the driver presses the brake pedal and the system still detects a risk of collision, the braking force may be increased if it is not sufficient to prevent the collision.

– **can trigger braking:** if the driver does not react to the alert and the collision becomes imminent, the red warn-

ing light  and the "Brake" message are displayed on the instrument panel accompanied by a sound signal.

### **Note:**

– if the driver uses the vehicle controls (steering wheel, pedals, etc.) the system may delay its reaction or not activate;

– if active emergency braking has caused the vehicle to stop, the vehicle is kept stationary for a short time. Beyond this time limit, the driver must keep the vehicle stationary by holding their foot on the brake pedal;

– after the system activates braking, the message "Advanced Safety triggered" will be displayed.



In the event of an emergency manoeuvre, you can stop the braking at any moment by:

- tapping the accelerator pedal;
- or
- turning the steering wheel as a collision avoidance manoeuvre.



### **Special features of warnings**


Depending on the speed, the warning and braking may be activated simultaneously.

### **Vehicle detection**

#### **Detection of vehicles travelling in the same lane**

A risk of a collision with the vehicle in front of you in the same lane is detectable by the system when the vehicle is travelling at a speed over approximately 4 mph (7 km/h).

#### **Detection of oncoming vehicles in the context of a manoeuvre to change direction**



When you wish to change direction (e.g. **A**), oncoming vehicles are detected by the system when:

- your vehicle is travelling at a speed between approximately 4 mph (7 km/h) and 19 mph (30 km/h);
- you have activated the direction indicator light.

#### **Detection of vehicles crossing the lane perpendicularly**

Vehicles crossing the lane perpendicularly are detected by the system when:

## ADDITIONAL DRIVING AID FUNCTIONS

– your vehicle is travelling at a speed between approximately 12 mph (20 km/h) and 37 mph (60 km/h).

### Detection of vehicles stopped in the lane

Stationary vehicles are detected by the system when:

– your vehicle is travelling at a speed between approximately 4 mph (7 km/h) and 53 mph (85 km/h).

### Detection of pedestrians and cyclists

### Detection of pedestrians and cyclists in the same lane

The system detects pedestrians and cyclists when:

– your vehicle is travelling at a speed between approximately 4 mph (7 km/h) and 53 mph (85 km/h).

### Detection of pedestrians and cyclists when changing direction

The system detects pedestrians and cyclists when:

– your vehicle is travelling at a speed between approximately 4 mph (7 km/h) and 19 mph (30 km/h).

### Activation/deactivation

-  Depending on the vehicle, according to the length of time following the last time the engine was stopped, the function is reactivated:
- when the vehicle is unlocked;
  - or
  - when a door is opened;
  - or
  - when the engine is restarted.

### Activating, deactivating the system from the multimedia screen 3



To activate or deactivate the function, refer to the multimedia instructions. Select "ON" or "OFF".

### Settings



For safety reasons, carry out any adjustments while the vehicle is stationary.

## ADDITIONAL DRIVING AID FUNCTIONS

### Settings from the multimedia screen 3



With the vehicle stationary, to access the function settings from the multimedia screen 3, refer to the multimedia instructions:

"Warning anticipation": adjust the alert sensitivity level. To do this select:

- « Late » ;
- « Standard » ;
- « Early ».

Please refer to the multimedia instructions for more information.

### Temporarily not available

If the system detects a temporary fault, the  warning light appears on the instrument panel.

The possible causes are:

- the system is temporarily blinded (glare from the sun, dipped beam headlights, bad weather conditions etc.). The system will be operational again when visibility conditions are better;
- the system is temporarily interrupted (e.g. the windscreen, front or rear bumper or logo is obscured by dirt, mud, snow, condensation, etc.) In this case, park the vehicle and switch off the engine. Clean the windscreen, the front bumper or the logo. The next time the engine is started, after around five or ten minutes of driving, the warning light and the message disappear. If this is not the case, this may arise from another cause; contact an approved dealer.

### Operating faults

If the system detects a temporary fault, the  warning light appears on the instrument panel. Consult an approved dealer.

# ADDITIONAL DRIVING AID FUNCTIONS

## Warnings



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The triggering of this function may be delayed or prevented when the system detects clear signs of control of the vehicle by the driver (action on the steering wheel, pedals etc.).

The system cannot be activated when:

- the gear control is in Neutral position;
- the Electronic Stability Control (ESC) has been triggered.

### **System servicing/repairs**

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected.  
Deactivate the function and consult an authorised dealer.
- Any work in the area where the radar and/or camera is located (repairs, replacements, windscreen modifications, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

## ADDITIONAL DRIVING AID FUNCTIONS



### **System disturbance**

Some conditions can disturb or damage the system's operation, such as:

- a complex environment (metal bridge, tunnel, etc.);
- poor weather conditions (snow, rain, hail, black ice, etc.);
- poor visibility (night, fog, etc.);
- poor contrast between the object (vehicle, pedestrian etc.) and the surrounding area (e.g. pedestrian dressed in white located in a snowy area etc.);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction; etc.);
- windscreen obscured (by dirt, ice, snow, condensation etc.);
- ...

**In these conditions, the system may not react, may warn the driver or may brake inadvertently.**

### **Limitation of the system operation**

- Each time the vehicle is started, the system carries out a calibration according to the vehicle surroundings and may be inactive for a length of time between approximately two to five minutes of driving;
- the radar and camera zones must be kept clean and free of any modifications in order to ensure the proper operation of the system;
- the system may not respond to small vehicles such as motorbikes as effectively as to other vehicles;
- the system may not operate properly when the road surface is slippery (rain, snow, black ice, etc.);
- to ensure correct operation, the system needs to distinguish the entire obstacle. So the system cannot detect:
  - pedestrians/cyclists in the darkness or in poor lighting conditions;
  - partially visible pedestrians/cyclists;
  - pedestrians less than approximately 80 cm;
  - pedestrians carrying large objects;
  - ...

**In these conditions, the system may not react, may warn the driver or may brake inadvertently.**

## ADDITIONAL DRIVING AID FUNCTIONS



### **Deactivating the function**

You must deactivate the function if:

- the camera area has been damaged (e.g. on the inside or outside of the windscreen);
- the front of the vehicle has been damaged (impact, distortion, scratch on the radar, etc.);
- the vehicle is being towed (breakdowns);
- the windscreen is cracked or distorted (do not carry out windscreen repairs in this area; have it changed by an approved dealer);
- you are not driving on a paved road.

**In the event of the system behaving abnormally, deactivate it and contact an authorised dealer.**

### **Halting the function**

You can halt the active braking function at any time by tapping the accelerator pedal or by turning the steering wheel in a collision avoidance manoeuvre.

# ADDITIONAL DRIVING AID FUNCTIONS

## Driver vigilance warning

### Introduction

The driver vigilance warning is a function that analyses the behaviour of the driver (driving style, vehicle steering, etc.) and alerts them if there is a risk of falling asleep.

It takes into account indicators such as:

- steering wheel movements;
- driver actions on other systems (indicators, brake pedal, etc.).



This function is an additional driving aid in case of risk of fatigue. The function does not operate on the vehicle. The function cannot, under any circumstances, replace the driver's responsibility during driving.

The driver must always adapt their driving according to their alertness, regardless of the system's indications.

### Operation



The function is set to warn the driver if:

- a few minutes have elapsed since the vehicle last stopped;
- the vehicle speed is greater than approximately 43 mph (70 km/h).

If there is a risk of fatigue or impaired attention, the "Fatigue warning Have a break" **1** message is displayed on the instrument panel, accompanied by a beep.

Press switch **2 OK** to delete the warning.

After deleting the message, the system continues vigilance monitoring and issues a new warning if necessary.



The driver vigilance warning constantly monitors the driver's attention and can provide several warnings per journey. The system resets every time the engine is started.

### Activation/deactivation



For safety reasons, carry out any adjustments while the vehicle is stationary.

## ADDITIONAL DRIVING AID FUNCTIONS

3

**i** Depending on the vehicle, depending on the length of time following the last time the engine was stopped, the alerts are reactivated:

- when the vehicle is unlocked;
- or
- when a door is opened;
- or
- when the engine is started.

**i** When the alerts are deactivated, the system continues to assess the driver's state of fatigue.

### Activating and deactivating alerts using the "My Safety" button 3



The alerts can be deactivated or activated using "Custom" mode in the "My Safety" function → 184.

If the alerts have previously been deactivated using "Custom" mode:

- **to deactivate the alerts**, press the button 3 twice in succession. The indicator light on the button 3 goes out;
- **to reactivate alerts**, press the button 3 once. The indicator light on the button 3 lights up.

### Activating and deactivating the alerts from the multimedia screen 4



To activate or deactivate the alerts, please refer to the multimedia instructions.

Select "ON" or "OFF".

### Limitations of system operation

Some conditions can disrupt or damage the system operation, for example:

- certain driving styles (incorrect driving etc.);
- driving on a road in poor condition;
- strong side wind;
- the clock is incorrectly configured (depending on the vehicle);

## ADDITIONAL DRIVING AID FUNCTIONS

- winding roads;
- trailer traction.

### Operating faults

If the system detects a fault, the "Check Fatigue Warning System" mes-

sage and the  warning light are displayed on the instrument panel.

Have the system checked by an authorised dealer.

### Detection of road signs

#### Introduction



The system displays speed limits on the instrument panel according to road signs detected on the side of the road.

It mainly uses information provided by the camera **1** attached to the windscreen, behind the rear view mirror. Depending on the country, the system also uses information from a map to interpret certain signs (town entrance, etc.).

The sign displayed on the instrument panel changes when a road sign is detected by the system.

Once the speed limiter or the adaptive cruise control is activated, you can adapt the limited speed setpoint to the speed displayed on the instrument panel by the system → **238** and → **242**.

If the detected speed limit is exceeded, the road sign displayed on the instrument panel is modified to inform the driver.

#### Location of the camera **1**

Make sure the windscreen is not obscured (by dirt, mud, snow, condensation etc.).

#### Special features

**For vehicles with a map subscription:**

- if the vehicle is travelling in a country where the speed units differ from those

of the vehicle, the system displays the speed limit sign in the unit of the country, alongside the speed limit converted to the unit used by the vehicle's instrument panel;

- for countries where the speed limit is reduced during rainy weather on some types of roads, the system may alter the detected speed limit after a few seconds of the windscreen wipers being activated.

#### Operation

#### Warning lights



The function displays the following warning lights:

- 2.** Speed limit signs and additional speed limit signs (speed on exit ramp

## ADDITIONAL DRIVING AID FUNCTIONS

with arrow, speed with a caravan, speed limit with length of application, etc.)

**3.** Additional road signs (start of no overtaking zone).

If the detected speed limit is exceeded, a circle around the road sign flashes (warning light **2**) accompanied, depending on the vehicle, by a beep emitted for a few seconds to warn you.

It remains illuminated on the instrument panel as long as the vehicle is exceeding the detected speed limit.



### Map subscription

Road sign detection is associated with a map subscription.

**To manage the subscription, please refer to the multimedia instructions.**

If there is no subscription, the system will be limited to taking into account the speed limit signs when they are detected by the camera.

The system will no longer take into account information related to the maps. The speed limit availability may be affected.

### Activation/deactivation



For safety reasons, carry out any adjustments while the vehicle is stationary.



Depending on the length of time following the last time the engine was stopped, the sound alert is reactivated:

- when the vehicle is unlocked;
- or
- when a door is opened;
- or
- when the engine is restarted.

### Activating, deactivating the over-speed sound alert using the "My Safety" button **4**



The sound alert can be deactivated or activated using "Custom" mode in the "My Safety" function ➔ **184**.

If the sound alert has previously been deactivated using "Custom" mode:

- **to deactivate the sound alert**, press the button **4** twice in succession. The indicator light on the button **4** goes out;
- **to reactivate the sound alert**, press the button **4** once. The indicator light on the button **4** comes on.

## ADDITIONAL DRIVING AID FUNCTIONS

### Activating, deactivating the over-speed sound alert from the multimedia screen 5



To activate or deactivate the sound alert, please refer to the multimedia instructions.

Select "ON" or "OFF".

### Variation of the limited speed or cruising speed



To adapt the speed limiter, cruise control or adaptive cruise control setpoint to the detected speed limit, press the 6 switch.

### Temporary unavailability

If the system is unavailable for reasons related to the camera or map data, the



symbol or, depending on the ve-

hicle, the yellow  symbol is displayed on the instrument panel. If there is still a problem, contact an approved dealer.

The system cannot detect the speed limit if:

- the windscreen is not clean;
- the camera is blinded by the sun;
- there is insufficient visibility (fog, etc.);
- the signs are not legible (snow, etc.) or are hidden (by another vehicle or by trees);
- map information is not up to date.

**Note:** when the front camera is obscured, the message "Front camera no visibility" appears on the instrument panel. Clean the windscreen area in front of the camera.

### Operating faults

When the system detects an operating fault, the  or, depending on the

vehicle, the yellow  symbol is displayed on the instrument panel.

In some cases, they are accompanied by the following message:

- "Driving aids unavailable";
- or
- "Check front camera";
- or
- "Check driving aids".

Consult an approved dealer.

## ADDITIONAL DRIVING AID FUNCTIONS

### Warnings



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

The driver should always adapt their speed to the traffic conditions, regardless of the system indications.

The system may not detect all speed limit signs or may interpret them incorrectly.

The driver must not ignore road signs undetected by the system and should give priority to complying with the actual road signs and the highway code.

In the event of poor visibility (fog, snow, frost, etc.), it is possible that the system may not indicate the correct speed to the driver.

# ADDITIONAL DRIVING AID FUNCTIONS

## Active driver assist

### Introduction

The "Active driver assist" is a driving aid system for use outside built-up areas, on wide roads with visible lines.

This system consists of the **"Adaptive cruise control Stop and Go" function → 242** and the **"Lane Centring" function**.

This system enables the driver to:

- maintain vehicle speed based on a previously stored speed;
- adjust the distance between their vehicle and the vehicle in front;
- direct the trajectory of the vehicle in the lane;
- adapt the vehicle speed to the speed shown on the road signs, automatically or after confirmation by the driver (depending on the vehicle).

### The Stop and Go adaptive cruise control function.

Depending on the country, based on information from a radar, a camera and map data transmitted via a GSM connection, the adaptive cruise control Stop and Go enables you to maintain a selected speed, know as the cruising speed, while maintaining a following

distance with the vehicle in front in the same lane.

The cruising speed can adjust automatically to a speed limit change (depending on the country).

If the vehicle in front stops, the Stop and Go adaptive cruise control may brake your vehicle to a complete stop before setting off again.



Important: you should keep your feet near the pedals and your hands on the steering wheel at all times to prepare for any event.

The system controls acceleration and deceleration of your vehicle using the engine and braking system.

The Stop and Go adaptive cruise control function can be activated from 0 mph, according to conditions on the road (traffic, weather, etc.).

It is represented by the  → 242 symbol.

#### Note:

– the driver must observe the maximum speed limit and safe distances according to the legislation in the country where they are driving;

– the adaptive cruise control can brake the vehicle up to a third of the braking capacity. Depending on the situation, the driver may need to brake harder.



The Stop and Go adaptive cruise control does not trigger an emergency stop and its braking capability is limited.

### The "Lane Centring" function

Using information from a camera, the "Lane Centring" function manipulates the steering system to direct the vehicle in the lane.

If the conditions allow it, the function is available:

- from approximately 0 mph with a vehicle in front;
- or
- from approximately 37 mph (60 km/h) without a vehicle in front.

The "Lane Centring" function is a comfort feature.

It is represented by the  warning light.

**Note:** in the event of a sharp bend, the function's lateral retention capacities are limited and require the driver to

## ADDITIONAL DRIVING AID FUNCTIONS

take immediate action on the steering wheel.

### Additional information

Depending on the vehicle, the "Active driver assist" function may be used with other driving aid functions.

Please note that:

– when the "Lane Centring" function is in adjustment mode, this will suspend the "Lane departure prevention" function if it has already been activated. When the "Lane Centring" function is not controlling the steering system, the "Lane departure prevention" function may be reactivated if conditions allow.


3



# ADDITIONAL DRIVING AID FUNCTIONS

## Location of components

3



# ADDITIONAL DRIVING AID FUNCTIONS

## 1 Camera

Detects markings on the ground and the position of vehicles on the various traffic lanes.

It receives information from the radar **7** and merges it with its own information to determine the trajectory and speed of the vehicle (acceleration/braking). Amongst other things, it controls the system activation/deactivation parameters (door opening status, etc.).

Depending on the vehicle, it processes information to detect the presence of the driver's hands on the steering wheel.

Make sure the windscreen is not obscured (by dirt, mud, snow, etc.).

## 2 Aerial and maps

(depending on the country)

Road maps and certain driving conditions (roundabouts and cornering) are downloaded according to the journey taken by the vehicle. The system can anticipate deceleration following a change of the speed limit indicated on road signs, depending on the parameters selected by the driver.

The system can also adjust the vehicle's speed when approaching a tight bend or roundabout.

## 3 Electronic parking brake

It the vehicle stationary under certain conditions.

## 4 Torque sensor

Depending on the vehicle, it detects hands on the steering wheel.

## 5 Power-assisted steering

It operates the front wheels to guide the vehicle trajectory according to the information transmitted by the computer **6**.

## 6 Engine computer

It controls and directs the engine to carry out the required acceleration.

## 7 Radar

Calculates the distance between your vehicle and the vehicle in front.

The system's maximum range is approximately 150 metres. This may vary according to the road conditions (ground relief, weather conditions, etc.)

Ensure that the radar area is not obstructed (dirt, mud, snow, a badly fitted front number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo etc.).

## 8 Active vehicle control

This system provides information on vehicle dynamics to the computer **6** (speed, lateral acceleration, etc.) and acts on the braking system to control deceleration and to keep the vehicle stationary.




The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system.

# ADDITIONAL DRIVING AID FUNCTIONS

## Controls

3



66352

## ADDITIONAL DRIVING AID FUNCTIONS

**9.** Switch for selecting/deselecting the driving aids, depending on the vehicle:

- speed limiter;
- adaptive cruise control;
- the Active driver assist;
- Off.

**10.** Safe distance settings

**11.** Put the function on standby (and store the limit speed) (0).

**12** Recall the stored cruising speed (RES).

**13**

- Upwards: activates, increases cruising speed or stores the current speed (SET/+).
- Downwards: activate, decrease cruising speed or store the current speed (SET/-).

**14** Pop-up button (depending on the vehicle): adapt the speed setpoint to

detected speed limits  → **217.**

### Displays on the instrument panel

**17.** "Stop and Go adaptive cruise control" function warning light .

**18.** Stored cruising speed.

**19.** Vehicle in front.

**20.** Stored safe distance

**21.** Left-hand and right-hand line indicators

**22.** "Lane centring" function warning

light .

### Steering wheel **23**

The driver must always keep their hands on the steering wheel.

If the driver turns the steering wheel with enough force, the "Lane Centring" function is interrupted to enable the driver to regain control of the vehicle.

Under certain conditions (sharp bends, etc.) a vibration may be triggered on the steering wheel to warn the driver that they must regain control of the vehicle.

If the driver does not handle the steering wheel (no hands are detected) the "Lane Centring" function is deactivated after several alerts.

## ADDITIONAL DRIVING AID FUNCTIONS

### Activating/deactivating the "Active driver assist" function

#### Activating the function

3



To activate the function, press the switch **9** as many times as required to start it at 25.

The warning light **22**  is displayed in grey on the instrument panel.

Then press the steering wheel control **13** upwards (SET/+) or downwards (SET/-).

The "Active driver assist", consisting of the Adaptive cruise control Stop and Go and the "Lane Centring" function, is then activated.

The green warning light **22**  and the left-hand and right-hand line indicators **21** are displayed on the instrument panel to confirm that the function is in operation and directing your vehicle towards the centre of the lane.

You can interrupt the "Lane Centring" function at any time by forcefully turning the steering wheel. As soon as you stop turning the steering wheel, the "Lane Centring" function is reactivated.

**Note:** you must keep your hands on the steering wheel when using the "Lane Centring" function. Under no circumstances should you take your hands off the steering wheel.

#### Deactivating the function


Press the switch **9**. Deactivation of the function is confirmed by the disappearance

of the warning light **22**  and the right-hand and left-hand line indicators **21** from the instrument panel.

**Note:** if the "Lane departure prevention" function was previously activated and the conditions allow, it will automatically reactivate.

#### Adjusting the position in the lane

(depending on the vehicle)



To adjust the position in the lane, the "Lane Centring" function must be in adjustment mode, the green warning light **22** must be displayed on the instrument panel and the vehicle speed must be below 31 mph (50 km/h).

In these conditions, you can adjust your position in the lane by turning the steering wheel slightly to the right or left, so that the vehicle shifts to the selected side without the "Lane Centring" function being deactivated. As soon as your offset is at least about 15 cm from the middle of the lane, without the vehicle approaching less than about 30 cm from the edge of the lane, you have about 10 seconds to adjust the offset precisely. The vehicle then remains in the offset position when you

## ADDITIONAL DRIVING AID FUNCTIONS

stop exerting effort to turn the steering wheel. The lines **21** indicate the offset applied. To return to the centre of the lane, turn the steering wheel slightly in the opposite direction, then stop trying once the vehicle has reached the centre.

Under certain conditions (e.g. bend, speed), the vehicle may be re-centred automatically.

### "Lane Centring" function on standby

The "Lane Centring" function is put on standby automatically in the following cases:

- the system no longer detects the lines or only one line is detected in your lane;
- the lane is too narrow or too wide;
- the system does not detect any hands on the steering wheel;
- in some driving conditions (roundabout, intersection, the bend is too sharp, etc.);
- the speed of the vehicle is higher than the maximum speed;
- the vehicle speed is below approximately 30 mph (48 km/h), without a vehicle in front;
- the vehicle crosses a line;
- the system is temporarily disrupted (for example: camera obscured by dirt, mud, snow, condensation, etc.).

Certain actions carried out by the driver also suspend the "Lane Centring" function:

- activating the indicators;
- turning the steering wheel with enough force.

The function is confirmed to be on standby by the appearance of the grey

warning light **22**  and the left-hand and right-hand line indicators **21** on the instrument panel.



Important: you should keep your feet near the pedals and your hands on the steering wheel at all times to prepare for any event.

Once the conditions are met, the function again directs the vehicle in the

lane. The warning light **22**  and the right-hand and left-hand line indicators **21** are displayed in green on the instrument panel.



You can affect **the vehicle trajectory** at any point by turning the steering wheel.

## ADDITIONAL DRIVING AID FUNCTIONS

### "Keep hands on steering wheel" warning



When the "Lane Centring" function no longer detects your hands on the steering wheel, several warning levels will be triggered:

- **after approximately 15 seconds**, the "Keep hands on steering wheel" message appears in yellow on the instrument panel;
- **after approximately 30 seconds**, the "Keep hands on steering wheel" message appears on the instrument

panel and the warning light **24**  appears in red, accompanied by a gradually increasing sound signal;

– **after approximately 35 seconds**, if the driver does not put their hands on the steering wheel after the warning is displayed, an audible warning sounds continuously. The brakes are then briefly applied repeatedly to inform the driver that they must retake control of the vehicle by putting their hands on the steering wheel. If the driver does not respond, the "Active driver assist" activates the hazard warning lights and slows down the vehicle until it comes to a complete stop.

 The driver can interrupt this manoeuvre at any time by placing their hands on the steering wheel, braking or deactivating the "Active driver assist".

– **after the vehicle has stopped**, the electronic parking brake is automatically applied, the warning lights stay

on, the warning light **24**  goes out and the "Lane centering deactivated" message appears in red on the instrument panel to inform you.

 In the first two alert levels, when the system again detects the presence of the driver's hands on the steering wheel, the system stops the alerts. The function continues to direct the vehicle in the lane.

**Note:** in some situations, the "Lane Centring" function may no longer detect your hands on the steering wheel and may emit an alert:

- the driver is holding the steering wheel very lightly;
- the driver is wearing gloves;
- ...

## ADDITIONAL DRIVING AID FUNCTIONS

### In the case of a sharp bend



In the case of a sharp bend, and depending on the vehicle speed, the function's side retaining capacities will be limited and require the driver to carry out immediate action on the steering wheel so that the vehicle remains in the lane.

If the driver does not intervene, the function triggers the vibration of the steering wheel to signal that the vehicle is about to breach a line and that the driver needs to carry out immediate action.

The warning light **22**  and the left-hand or right-hand line indicator **21**

concerned appear in red on the instrument panel.

**If the vehicle crosses a line completely and moves out of its lane or if the bend is too sharp, the "Lane Centring" function is put on standby.**

The function is confirmed to be on standby by the appearance of the grey

warning light **22**  and the left-hand and right-hand line indicators **21** on the instrument panel.

 The "Lane Centring" function cannot assist the driver when negotiating a roundabout or an intersection and may automatically switch to standby. In all cases, the driver must always turn the steering wheel to manage the vehicle trajectory under these driving conditions.

### Operating faults

If an operating fault is detected in relation to the "Lane Centring" function, the "Driving assist unavailable" or "Check Driving assist" message is displayed on the instrument panel and the function is deactivated.

Consult an approved dealer.

# ADDITIONAL DRIVING AID FUNCTIONS

## Warnings



The "Active driver assist" is an additional driving aid. It can under no circumstances replace the driver's responsibility to respect speed limits and safe distances and to be vigilant.

The driver must always be in control of the vehicle.

The driver must always adapt their trajectory and speed according to the surroundings and driving conditions, regardless of system indications.

Except for lines delimiting lanes and the speed limit signs within the limits of the system's detection capacity, the road sign information (other traffic signs, traffic lights, pedestrian crossings, etc.) are not recognised by the system. These do not trigger any alert or reaction by the system.

The "Active driver assist" uses the "Stop and Go adaptive cruise control" and "Lane Centring" functions. The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

Use the "Active driver assist" exclusively outside built-up areas, on wide roads with visible lines.

It must not be used in heavy traffic, on winding or slippery roads (black ice, aquaplaning, gravel) or during bad weather (fog, rain, side winds etc.).

**There is a risk of accidents.**

### **System servicing/repairs**

– In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the system and consult an authorised dealer.

– Any work in the proximity of the radar and/or camera (replacements, repairs, windscreen modifications, paintwork etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

## ADDITIONAL DRIVING AID FUNCTIONS



### Deactivating the system

You must deactivate the system if:

- the vehicle is travelling on a winding road;
- the vehicle is being towed (breakdowns);
- the vehicle is towing a trailer or a caravan;
- the vehicle is being driven in a tunnel or close to a metallic structure;
- the vehicle arrives at a toll point, a roadwork area or on a narrow lane;
- the vehicle is being driven up or down a very steep slope;
- the visibility is poor (glaring sun, fog, etc.);
- the weather conditions are poor (rain, snow, side winds, etc.);
- the vehicle is being driven on a slippery road surface (rain, snow, gravel, etc.);
- the camera area has been damaged (e.g. interior or exterior windscreen area); the windscreen is cracked or distorted;
- the radar area has been damaged (impacts, etc.);
- the surface of the steering wheel is damaged or damp.

**In the event of the system behaving abnormally, deactivate it and contact an authorised dealer.**

## ADDITIONAL DRIVING AID FUNCTIONS



**Some conditions can disrupt or damage the system operation, for example:**

- obstruction of the windscreen or the radar area (by dirt, ice, snow, condensation etc.) Frequently check the cleanliness and condition of the windscreen, front wiper blades and front bumper;
- a complex environment (tunnel, etc.);
- poor weather conditions (snow, heavy rain, hail, black ice, etc.);
- poor visibility (night, fog, etc.);
- poor contrast between the vehicle preceding it and the surrounding area (e.g. white vehicle in a snowy area, etc.);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction; etc.);
- narrow, winding or undulating road (tight bends, etc.);
- the tar lines detected as a line by the system;
- narrowing/widening lanes;
- road markings which are worn, lacking in contrast or very widely spaced from one another (lines partially erased; etc.);
- multiple markings on the road (roadworks area, slip roads connecting to adjacent motorways, hard shoulder, etc.);
- road signs that do not include an arrow, located on a motorway exit;
- an area with low connectivity that makes it impossible to geolocate the vehicle, or maps that are not up-to-date;
- a vehicle with a significant difference in speed;
- use of mats not adapted to the vehicle. On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals.**

**In these cases:**

- **Risk of unwanted braking or acceleration.**
- **Risk of unwanted, incorrect correction or no correction of trajectory.**

Many unforeseen situations may affect the system operation. Certain objects or vehicles that can appear in the camera or radar detection zone may be interpreted by the system incorrectly, possibly leading to inappropriate acceleration or braking.

**You should always be attentive to sudden events that might occur while you are driving. Always maintain your vehicle under control by keeping your feet near the pedals and your hands on the steering wheel, so that you are ready to act in any event.**

## ADDITIONAL DRIVING AID FUNCTIONS

### Active emergency braking in reverse gear

#### Introduction



In addition to the "Parking assistance" → 258 function and using information from the four central sensors located at the rear of the vehicle, the system detects fixed obstacles located behind your vehicle. If there is a significant risk of collision, the system automatically causes the vehicle to brake.

**Note:** make sure that the four central sensors located at the rear of the vehicle are not obscured (by dirt, mud, snow, etc.).

#### Operation



#### Fixed rear obstacle detection

When in reverse gear and moving at a speed between approximately 2 mph and 5 mph (4 km/h and 8 km/h), if there is a risk of collision with a fixed obstacle, the system **automatically brakes the vehicle**. Visual feedback **2** is displayed on the multimedia screen **1** accompanied by a beep.

Once the vehicle has stopped, the vehicle must be held stationary by the driver keeping their foot on the brake pedal.



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.



An impact to the underside of the vehicle while manoeuvring (e.g. striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g. deformation of an axle). To avoid any risk of accident, have your vehicle checked by an approved Dealer.

## ADDITIONAL DRIVING AID FUNCTIONS

### Activating or deactivating the system



To activate or deactivate the function via the multimedia screen **1**, select the "Vehicle" world, then "Driving assistance", then "Parking". Activate the "Active emergency braking in reverse gear".

If the function is deactivated, the **3** warning light is displayed on the multimedia screen.

### Operating faults

When the system detects an operating fault, active emergency braking in reverse gear is automatically deactivated.

The **3** warning light is displayed on the multimedia screen accompanied by, depending on the type of malfunction, the following message on the instrument panel:

- « Parking sensors unavailable » ;
- or
- « Check Parking sensors » ;
- or
- « Driving assist unavailable » ;
- or
- « Check Driving assist ».

Clean the ultrasonic sensors. If there is still a problem, contact an approved dealer.



If the vehicle is fitted with a towbar recognised by the system and a trailer has been connected, active emergency braking in reverse gear is automatically deactivated and the following message is displayed on the instrument panel: "Trailer: parking sensors unavailable", accompanied by the warning light **3** on the multimedia screen.

# ADDITIONAL DRIVING AID FUNCTIONS

## Warnings



### **Active emergency braking in reverse gear**

This function is an additional driving aid. This function cannot, under any circumstances, replace the vigilance and responsibility of the driver.

Some climatic and environmental conditions can disrupt or damage the system. As a consequence, the driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.

The triggering of this function may be delayed or prevented when the system detects clear signs of control of the vehicle by the driver (action on the steering wheel, pedals etc.).

### **System servicing/repairs**

- In the event of an impact, the rear sensors and their performances may be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the sensors are located (repairs, replacements, bumper modifications etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

### **Deactivating the function**

You must deactivate the function if the vehicle is being towed (breakdown recovery) or if the vehicle is fitted with a towbar that is not recognised by the system.

In the event of the system behaving abnormally, deactivate it and contact an authorised dealer.

# SPEED LIMITER

## Introduction

The speed limiter function controls the engine and braking system to help you not to exceed a driving speed that you have chosen, known as the **limit speed**.

**i** With Save mode activated, the limit speed cannot exceed the maximum speed in Save mode → 171.

## Controls



**1.** Switch for selecting/deselecting the driving aids, depending on the vehicle:

- Active Driver Assist;
- adaptive cruise control;
- cruise control;
- speed limiter;
- OFF.

**2.** Puts the function on standby and stores the limited speed (0).

**3.** Recalling the stored limit speed (RES).

**4.**

- Upwards: activates, increases limited speed or stores the current speed (SET/+).
- Downwards: activates, decreases limited speed or stores the current speed (SET/-).

**5.** Pop-up button (depending on the vehicle): adapt the speed setpoint to

detected speed limits  → 217.

**i** Depending on the vehicle, you can link the speed limiter function to the "Road sign detection" function → 217 by pressing the switch **5**.

When the "OFF" mode is selected before the ignition is switched off, the "Speed limiter" function will be activated by default the next time the engine is started.

## Driving

When a limit speed has been set but not yet reached, driving is similar to driving a vehicle without the speed limiter function.

Once you have reached the stored speed, no effort on the accelerator pedal will allow you to exceed the programmed speed except if necessary (refer to information on "Exceeding the limit speed").

# SPEED LIMITER

## Switching on



Press switch **1** as many times as necessary to select the speed limiter. The warning light **6** appears in grey. The "Speed limiter OK SET to activate" message is displayed on the instrument panel accompanied by dashes to indicate that the speed limiter function is activated and waiting for a limit speed to be stored.

To store the current speed, press the switch **4** upwards (SET/+) or downwards (SET/-): the limited speed replaces the dashes and, depending on the vehicle, the warning light **6** appears in white.

The minimum stored speed is 12 mph (20 km/h).

## Varying the limit speed



You can change the limit speed by repeatedly pressing or by pressing and holding on control **4**:

- upwards (SET/+) to increase the speed;
- downwards (SET/-) to decrease the speed.

## Automatic speed limiter with speed limit sign recognition

Using the camera, the "Road sign detection" function → **217** and the map, the system automatically limits the vehicle speed when a speed limit road sign is identified and passed.

## Activation/deactivation

From the multimedia screen, in the "Vehicle" world, select "Driving aids". Then, from the "Speed adaptation" menu, go to the "Adaptive cruise control" section and select "To speed limits".

**Note:** activation/deactivation is also possible by pressing and holding the contextual button **5**.

## Exceeding the limit speed

It is possible to exceed the limit speed at any moment. To do this, press the accelerator pedal **firmly down** (close to or beyond the point of resistance, depending on the vehicle).

While the speed is being exceeded, the speed limiter flashes in yellow/orange on the instrument panel.

Then, release the accelerator pedal: the speed limiter function will return as soon as you reach a speed lower than the memorised speed.



**You must keep your feet near the pedals to be ready to react in an emergency.**

## SPEED LIMITER



If the speed limiter is not available (after several attempts to activate), contact an approved dealer.

3

### Putting the function on standby



The speed limiter function is suspended when you press switch **2** (0).

The limit speed is stored and displayed in grey on the instrument panel.

### Recalling the limit speed

If a speed has been stored, you can recall it by pressing the switch **3**.



When the speed limiter is set to standby, pressing the control **4** upwards or downwards reactivates the function without taking into account the stored speed: it is the speed at which the vehicle is moving that is taken into account.

# SPEED LIMITER

## Switching off the function



**i** To exit the driving assistance, press switch **1** as many times as necessary until you reach OFF. The "Driving Assistance deactivated" message appears on the instrument panel. In this case, the next time the engine is started, the "Speed limiter" function will be activated and waiting for a speed limit to be stored.

The speed limiter function is interrupted when you press the switch **1** to de-select the speed limiter. In this case, the speed is no longer stored.

The warning light **6** disappears from the instrument panel to confirm that the function has stopped.

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Introduction

Based on information from a radar or camera, the Stop and Go adaptive cruise control function gives you the option of maintaining a selected speed, known as the cruising speed, while keeping a safe distance from the vehicle in front in the same lane.

Depending on the vehicle, when the "Road Sign Detection" function is activated → 217, the system can adapt the speed of your vehicle according to the speed limit signs recognized by the camera.

Depending on the country, the system will use the camera and the map to adjust the vehicle speed in advance according to the context and road incidents (roundabouts, bends, upcoming road signs or speed limit zones).

If the vehicle in front stops, the Stop and Go adaptive cruise control may brake your vehicle to a complete stop before setting off again.

The system controls acceleration and deceleration of your vehicle using the engine and braking system.

The system's maximum range is approximately 130 metres. This may vary according to the road conditions (ground relief, weather conditions, etc.).

According to conditions on the road (traffic, weather, etc.), the Stop and Go adaptive cruise control function can be activated from 0 mph.

The function is indicated by the  symbol.

### Note:

- the driver must observe the maximum speed limit and safe distances according to the legislation in the country where they are driving;
- the adaptive cruise control can brake the vehicle up to around a third of the braking capacity. Depending on the situation, the driver may need to brake harder.

 While Save mode is activated, the cruising speed cannot exceed the maximum speed in Save mode → 171.

 The regenerative braking system and the regenerative braking control are not available when the adaptive cruise control function is activated.

 The Stop and Go adaptive cruise control does not trigger an emergency stop and its braking capability is limited.



This function is an additional driving aid.

It can under no circumstances replace the driver's responsibility to respect speed limits and safe distances or to be vigilant.

The driver must always be in control of the vehicle.

The driver must always adapt their speed according to the surroundings and traffic conditions.

**Use the Stop and Go adaptive cruise control function outside built-up areas, on wide roads with visible lines.**

The cruise control may have limited operation on very winding or slippery roads (black ice, aquaplaning, gravel) or during bad weather (fog, rain, side winds, etc.)

**There is a risk of accidents.**

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Location of the camera 1



Make sure the windscreen is not obscured (by dirt, mud, snow, etc.).

## Location of the radar 2

Ensure that the radar protection plate is not obstructed (dirt, mud, snow, a badly fitted number plate), impacted, modified (including painting) or hidden by any accessory fitted on the front of the vehicle (on the grille or logo, etc.).

## Controls



**3.** Switch for selecting/deselecting the driving aids, depending on the vehicle:

- speed limiter;
- adaptive cruise control;
- Active Driver Assist;
- OFF.

**4.** Put the function on standby (with cruising speed stored) (0).

**5** Recall the stored cruising speed (RES).

**6**

- Upwards: activates, increases cruising speed or stores the current speed (SET/+).

- Downwards: activate, decrease cruising speed or store the current speed (SET/-).

**7** Pop-up button (depending on the vehicle): adapt the speed setpoint to detected speed limits



→ 217.

**8** Adjusting the following distance.

 Depending on the vehicle, you can link the cruise control function to the "Road sign detection" function → 217 by pressing the switch 7.



The radar and camera zones must be kept clean and free of any tampering in order to ensure the proper operation of the system.

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Displays



**9.** Stop and Go adaptive cruise control warning light.

**10.** Stored cruising speed.

**11.** Vehicle in front.

**12.** Stored safe distance



Important: you should keep your feet near the pedals at all times to prepare for any event.

## Switching on



Press switch **3** to select the adaptive cruise control at **13**. The warning light **9** appears in grey. The "Adaptive Cruise Control ready: SET to activate" message appears on the instrument panel accompanied by dashes to indicate that the cruise control function is in operation and waiting to store a cruising speed.

This function cannot be activated when:

- the parking brake is applied;
- the driver's seat belt is not fastened;
- one or more doors are incorrectly closed;
- the "Hands-free parking" function is already activated.

The "Adaptive Cruise Ctl unavailable" message is displayed on the instrument panel.

## Activating cruise control

When stationary or at a steady speed, push the control **6** upwards (SET/+) or downwards (SET/-): the function is activated and the current speed is stored.

The minimum cruising speed is 12 mph (20 km/h).

The cruising speed **10** replaces the dashes and cruise control is confirmed by the appearance of the cruising speed in green and the warning light **9**.

If you try to set the function to a speed over the vehicle's maximum speed, the "Invalid Speed" message will be displayed and the function will remain deactivated.

Once a cruising speed is memorised and the cruise control function is active, you may lift your foot off the accelerator pedal.


**Note:** if your vehicle speed is lower than approximately 12 mph (20 km/h), the function uses a default cruising speed of 12 mph (20 km/h). The vehicle will accelerate until it reaches the stored cruising speed.

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Activating cruise control with speed limit sign recognition (display A)



## Activating cruise control with advance speed limit sign recognition (display B)



The letter "A" **16** is displayed on the instrument panel to confirm the activation of the cruise control with anticipated speed limit sign recognition.



(depending on the vehicle)

If the vehicle is equipped with the "Road Sign Detection" function → 217, press the pop-up button 7 to adapt the vehicle's speed to the speed limits 14 detected by the camera.

When passing the sign, the cruising speed 10 adopts the value of the detected speed 14.

Using the camera, the "Road Sign Detection" function → 217 and the maps, the system anticipates the automatic adaptation of the vehicle speed until the next speed limit sign is identified 15 and passed.

### Activation/deactivation

From the multimedia screen, in the "Vehicle" World, select "Driving assistance". Then, from the "Comfort" menu, select "Speed limit adaptive cruise control".

### Note:

- you can also activate/deactivate the function by pressing and holding the pop-up button 7;
- in some cases (if there is a significant difference between the vehicle speed and limited speed), the system may request that you validate the speed manually by pressing the pop-up button 7: the white square 17 is displayed around the indicated speed to inform you.

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Operation

With the function activated, the following speeds are displayed on the instrument panel:

- cruising speed **10**;
- the current speed limit detected by the system on the section of road on which the vehicle is travelling **14**;
- the speed detected by the system on the next section of road or speed limit zone **15**.

The detected speed **15** is taken into account by the system. The vehicle speed gradually adapts until it becomes the cruising speed **10**, without any action taken by the driver. The speed indicated at **15** is displayed at **14** when passing the speed limit sign or zone identified.

**The driver must always stay vigilant regarding the speed applied by the system and remains responsible for the vehicle speed.**

If the function is not activated, the operation is identical to setting the cruising speed with speed limit sign recognition (display **A**).

## Activating cruise control with advance recognition of the road layout (display **C**)



Using the camera, the "Road sign detection" function → 217 and the maps, the system can anticipate and manage the automatic adaptation of the cruising speed **10** when the vehicle approaches a roundabout or a bend.

If the vehicle is approaching a bend or roundabout, a warning light **18** appears on the instrument panel. The vehicle adjusts its speed to a speed appropriate to the feature detected.

**The driver must always stay vigilant regarding the speed applied by the system and remains responsible for the vehicle speed.**

## Activation/deactivation

From the multimedia screen, in the "Vehicle" World, select "Driving assistance". Then, from the "Comfort" menu, select "Road layout adaptive cruise control".

In the "Adaptive regulation" menu, select "To road context".

When the function is not activated, the operation is the same as setting the cruising speed with speed limit sign recognition (display **A**) or, setting the cruising speed with advanced speed limit sign recognition (display **B**).

The following symbols show the features taken into account by the system:

-  roundabout;
-  bend.

## Controlling cruising speed

You can resume control of the vehicle speed at any time by:

- putting the function on standby:
  - by pressing the brake pedal;
  - or by pressing the switch **4** (0);
- by pressing the driving aids selection/deselection switch **3**.

When automatically adapting the speed to the signs and/or road layout,

## STOP AND GO ADAPTIVE CRUISE CONTROL

it is possible to ignore these events. Press the button **5** (RES) to resume the stored cruising speed.

### Safe distance control activation

As soon as cruise control is activated, the default safe distance **13** is displayed in green on the instrument panel.

If the system detects a vehicle in your lane, an outline of a vehicle **12** appears above the distance gauge **13** on the instrument panel.

Your vehicle adapts its speed to that of the vehicle in front and applies the brakes if necessary (the brake lights come on) in order to maintain the distance displayed on the instrument panel.

**Note:** the size of the outline **12** varies according to the distance separating you from the vehicle in front. The larger the outline, the closer the vehicle in front.

### Setting the cruising speed


You can vary the cruising speed by pressing repeatedly (for low variation) or pressing and holding (for high variation) on the control **6**:

– downwards: (SET/-) to decrease the speed;

– upwards: (SET/+) to increase the speed.

### Adjusting the following distance

You can vary the safe distance from the vehicle in front at any time by pressing switch **8** repeatedly.



The horizontal distance gauge on the instrument panel indicates the various available safe distances:

- distance gauge **D**: long distance (corresponding to approximately 2.4 seconds);
- distance gauge **E**: intermediate distance 2 (corresponding to approximately two seconds);

- distance gauge **F**: intermediate distance 1 (corresponding to approximately 1.6 second);
- distance gauge **G**: short distance (corresponding to approximately 1.2 second).

The selected distance gauge appears in green on the instrument panel. The other gauges remain in grey.

**Note:** the distance must be set according to the traffic level, local regulation and weather conditions.



The safe distance is adjusted by default on the distance gauge **E**.

### Exceeding the cruising speed

The cruising speed may be exceeded at any time by applying the accelerator pedal.

If it is exceeded, the cruising speed **10** appears in yellow.

If the driver presses the accelerator pedal, the "Distance Control" function will no longer operate.

Then, release the accelerator pedal: the cruise control and safe distance control will automatically resume the speed and distance instructions that you had previously selected.

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Overtaking manoeuvre

If you want to overtake the vehicle in front and only if your speed is over 43 mph (70 km/h), activating the direction indicators temporarily reduces the following distance and triggers acceleration to facilitate overtaking.

## Stopping the vehicle and setting off

If the vehicle in front slows down, the system adapts its speed to bring the vehicle to a complete stop if necessary (e.g. in heavy traffic). The vehicle stops a few metres from the vehicle in front.

When the vehicle in front sets off again:

- if the stop lasts for less than thirty seconds, the vehicle will start again without any action required from the driver.

**Note:** the driver should always be ready for sudden incidents while driving and remains responsible for controlling the vehicle: if the system detects a pedestrian in the area around the vehicle, the automatic restart will be inhibited until the next stop;

- if the stopping time exceeds approximately thirty seconds, for the vehicle to set off again it is necessary to either:

- 
- press the accelerator pedal;
- press button **5** once (RES).

The message "Press RES or accelerate to restart Cruise Control" appears on the instrument panel to confirm.

If the stop exceeds around three minutes, the electronic parking brake is automatically applied and the Stop and Go adaptive cruise control is deactivated.

The warning light **9** goes out to confirm that the function is deactivated.

## Putting the function on standby

You can set the function to standby when:

- you press switch **4** (0);
- you apply the brake pedal while the vehicle is moving.

The function is deactivated by the system if:

- you set the gear control to **R** or **N**;
- you unbuckle the driver's seat belt;
- you open one of the opening elements;
- you press the engine start/stop button;
- the slope is too steep;
- certain driving aids and correction devices are triggered (active emergency braking, ABS, ESC, etc.)

**Note:** Depending on the vehicle, if the reception of the connected data is not optimal, the system automatically switches on standby the advance speed limit sign recognition and/or advance recognition of the road layout functions.

The two functions are automatically reactivated as soon as reception of the connected data becomes optimal again.

In all circumstances, the standby is confirmed when the warning lights appear in grey and the message "Adaptive Cruise Control disconnected" appears on the instrument panel.



Putting the Stop and Go adaptive cruise control in standby or switching it off does not cause a rapid reduction in speed: you must brake by applying the brake pedal if necessary.

## Exit from standby

### Based on the stored cruising speed

If a speed is stored, it can be recalled, once you are sure that the road conditions are suitable (traffic, road surface, weather conditions, etc.). Press button

## STOP AND GO ADAPTIVE CRUISE CONTROL

**5** (RES) to adjust the speed within the valid speed range.


When the stored speed is recalled, activation of the cruise control is confirmed by the illumination of the cruising speed in green.

**Note:** if the stored speed is higher than the current speed, the vehicle will accelerate to reach that speed.

### Based on the current speed

When the cruise control is set to standby, press switch **6** upwards (SET/+) or downwards (SET/-) to reactivate the cruise control function without taking into account the stored speed: it is the speed at which the vehicle is moving that is taken into account.

### "Take control of the vehicle" warnings



**In some situations (e.g. coming up on a much slower vehicle, vehicle in front changing lanes quickly, etc.) the system may not have time to react.**

Depending on the situation, the system sounds a beep associated with:

- the orange alert **H** if the situation requires the driver's attention;

or

- the red alert **J** accompanied by the "Brake" message if the situation requires the driver's immediate attention.

**In all situations, react accordingly and perform the appropriate manoeuvres.**

### Switching off the function



The adaptive cruise control Stop and Go function is interrupted:

- if you press the switch **3**.

The warning light **9** disappears from the instrument panel to confirm that the function has stopped.

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Temporary unavailability

### Radar



The radar is able to detect vehicles in front of your vehicle. The system cannot operate correctly if the radar detection area is obscured or if its signal is disrupted.

If the radar detection area is obstructed or the radar signal is disrupted, the message "Front radar no visibility" is displayed on the instrument panel and the adaptive cruise control Stop and Go is interrupted.

The green warning light **9** disappears to confirm that the function has been automatically deactivated.

Ensure that the radar area remains clean and is not obstructed by snow, mud, a badly fitted number plate or by any accessory fitted on the front of the vehicle (on the grille), or hidden by any accessory fitted on the front of the vehicle (on the grille or logo, etc.).

Conditions in certain geographical areas may hinder the function, for example:

- arid zones, tunnels, long bridges or lightly used roads without road lines, without signs or trees nearby;
- a military or airport zone.

You must leave such areas in order for the function to work.

In all cases, if the message is not erased after the engine is restarted, please contact an authorised dealer.

### Camera

The system cannot operate if the camera is obscured (by dirt, mud, snow, condensation, etc.).

If the camera visibility is reduced, the "Front camera no visibility" message will be displayed on the instrument panel and the performance of the adaptive cruise control Stop and Go will be reduced. Remain vigilant.

## Operating faults

If an operating fault is detected on the adaptive cruise control function Stop and Go, the "Check Adaptive Cruise Control" message appears on the instrument panel and the adaptive cruise control function Stop and Go is interrupted.

If an operating fault is detected on one or more components of the system, the Stop and Go adaptive cruise control function is deactivated.

Depending on the type of malfunction, the message is displayed on the instrument panel:

– "Check Front camera" accompanied, depending on the vehicle, by the



warning light;

– "Front radar to check" accompanied, depending on the vehicle, by the



warning light;

– "Check Camera/Radar" accompanied, depending on the vehicle, by the



warning light;

– "Check vehicle" accompanied by the




warning light.

Consult an approved dealer.

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Limitations of system operation

### Vehicle detection



The system detects only vehicles (cars, trucks, motorbikes) that are moving in the same direction as your vehicle.

A vehicle turning into the same lane (example **K**) will be taken into account by the system only once it enters the camera and radar detection areas.

**The system may trigger inappropriate or delayed braking.**



### The system cannot detect:

- vehicles arriving at intersections: e.g. slip road (example **L**);
- vehicles driving on the wrong side of the road or reversing towards you.



The Stop and Go adaptive cruise control must be used outside built-up areas, on wide roads with visible lines.

## Detection during cornering



When entering a corner or bend, the radar and/or camera may be temporarily unable to detect the vehicle in front (example **M**).


**The system may trigger an acceleration.**

When exiting a bend, the system's detection of the vehicle in front may be disrupted or delayed.

**The system may trigger inappropriate or delayed braking.**

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Detection of vehicles in adjacent lanes




The system may detect vehicles driving on an adjacent lane when:

- you drive into a bend (example **N**);
- you are driving on a road with narrow lanes;
- the speed of the vehicle on the adjacent lane is slower and if one of these vehicles is located too close to the lane of the other.

**The system may incorrectly trigger vehicle slowing or braking.**



**P**



**Q**

**Vehicles hidden due to variations in ground relief**


The system will not detect vehicles hidden due to variations in ground relief or those located outside of the camera and radar detection areas when driving uphill or downhill.

**Vehicles outside the camera and radar detection areas.**

**The system will react late or not at all** if the detected vehicles are outside the camera and radar detection areas, particularly in the following cases:

- vehicles transporting long objects which exceed the line;
- the actual length of tall vehicles (example **P**) is outside the radar detection area (construction machine, agricultural equipment towing vehicle, etc.);
- vehicles insufficiently centred in the lane;
- narrow vehicles which are very close (example **Q**).

# STOP AND GO ADAPTIVE CRUISE CONTROL





## Stationary and slow moving vehicles

When your speed is over approximately 31 mph (50 km/h), **the system does not detect:**

- stationary vehicles (example **R**);
- very slow moving vehicles.

When your speed is less than approximately 31 mph (50 km/h), **the system may not react or may react very late to:**

- stationary vehicles (example **R**);
- very slow moving vehicles;




- vehicles in front **19** that change lane, discovering a stationary vehicle **20** (example **S**);

- stationary vehicles **21**, when you change lane (example **T**).

 **Always be ready to respond in all circumstances.**

**The driver must always be in control of the vehicle.**

The Stop and Go adaptive cruise control does not trigger an emergency stop and its braking capability is limited.



**Non-detection of fixed obstacles and objects of a small size**  
**The system cannot detect:**


## STOP AND GO ADAPTIVE CRUISE CONTROL

- pedestrians, bikes, scooters, etc.;
- animals;
- fixed obstacles (toll barriers, walls, etc.) (example **U**).

These are not taken into account by the system. They do not trigger any alert or reaction by the system.

3

### Detection of vehicles moving into lane at high speed



If your vehicle is overtaken by another vehicle driving at high speed **22** (motorcycle, car, etc.) and the vehicle is temporarily positioned between your vehicle and the vehicle in front **23**, **the system may trigger undue acceleration, slowing or braking.**

# STOP AND GO ADAPTIVE CRUISE CONTROL

## Warnings



This function is an additional driving aid. It can under no circumstances replace the driver's responsibility to respect speed limits and safe distances or to be vigilant.

The driver must always be in control of the vehicle.

Apart from the speed limit signs and road map information from the maps (vehicles fitted with the "Road sign detection" function), other traffic information (traffic lights, pedestrian crossings, etc.) is not taken into account by the system. The driver must always adapt their speed to the surroundings and driving conditions, regardless of system indications. The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

**Use the Stop and Go adaptive cruise control function outside built-up areas, on wide roads with visible lines.**

### **System servicing/repairs**

- In the event of an impact, the radar and/or camera alignment may be changed and its operation may consequently be affected. Deactivate the system and consult an authorised dealer.
- Any work in the proximity of the radar and/or camera (replacements, repairs, windscreen modifications, paintwork etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

# STOP AND GO ADAPTIVE CRUISE CONTROL



## Deactivating the function

You must deactivate the function if:

- the vehicle is being towed (breakdowns);
- the vehicle is towing a trailer or a caravan;
- the vehicle is being driven in a tunnel or close to a metallic structure;
- the vehicle arrives at a toll point, a roadwork area or on a narrow lane;
- the vehicle is driven on a very winding road (mountain road, etc.);
- the vehicle is being driven up or down a very steep slope;
- the visibility is poor (glaring sun, fog, etc.);
- the vehicle is being driven on a slippery road surface (rain, snow, gravel, etc.);
- the weather conditions are poor (rain, snow, side winds, etc.);
- the radar area has been damaged (impacts, etc.);
- the camera area has been damaged (e.g. on the inside or outside of the windscreen);
- the windscreen is cracked or distorted.

**In the event of the system behaving abnormally, deactivate it and contact an authorised dealer.**

## STOP AND GO ADAPTIVE CRUISE CONTROL



### **In the event of system disturbance**

Some conditions can disturb or damage the system's operation, such as:

- the windscreen or bumper is obscured in the radar area (by dirt, ice, snow, condensation, number plate, etc.);
- a complex environment (tunnel, etc.);
- poor weather conditions (snow, heavy rain, hail, black ice, etc.);
- poor visibility (night, fog, etc.);
- being dazzled (glaring sun, lights of vehicles travelling in the opposite direction; etc.);
- narrow, winding or undulating road (tight bends, etc.);
- a vehicle with a significant difference in speed;
- use of mats not adapted to the vehicle. On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals.**

### **In this case, the system may brake or accelerate unintentionally.**


Many unforeseen situations may affect the system operation. Certain objects or vehicles that can appear in the camera or radar detection zone may be interpreted by the system incorrectly, possibly leading to inappropriate acceleration or braking.

**You should always be attentive to sudden events that might occur while you are driving. Always keep your vehicle under control by keeping your feet near the pedals, so that you are ready to act in any event.**

## PARKING AIDS

### Parking distance control

#### Operating principle



Ultrasonic sensors, indicated by arrows **1**, are fitted in the bumpers to detect obstacles near the vehicle.

The function alerts the driver via audible signals and a display representing the area where the obstacle was detected.

Depending on the equipment, the system detects obstacles behind, in front and to the sides of the vehicle.

The Park Assist system is only activated when the vehicle is driven at a speed below approximately 6 mph (10 km/h).

The function does not take into account towing or carrying systems that are not recognised by the system.



This function is an additional driving aid. Under no circumstances should it replace the driver's care or responsibility whilst reversing.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.




An impact to the underside of the vehicle while manoeuvring (e.g. striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g. deformation of an axle). To avoid any risk of accident, have your vehicle checked by an approved Dealer.

#### Location of the ultrasonic sensors **1**

Ensure that the area around the ultrasonic sensors indicated by the arrows **1** is not obscured (by dirt, mud, snow, a badly fitted/attached number plate, etc.), impacted, modified (including paintwork) or obstructed by any accessory fitted to the rear and, depending on the vehicle, to the front or sides of your vehicle.

# PARKING AIDS

## Operation




The display **2** shows the vehicle surroundings and emits beeps.

Depending on the equipment, it may be necessary to travel a few metres before the side detection is activated.

If all areas have a grey background, the whole area around the vehicle is being monitored:

- display **A**: analysis of vehicle surroundings in progress;
- display **B**: analysis of vehicle surroundings complete.

## Obstacle detection



Most objects located less near the front, rear and sides of the vehicle are detected.


The audible signal frequency will increase as the vehicle approaches on obstacle, until it becomes a solid beep at approximately 20 cm for an obstacle detected on the sides and approximately 30 cm for an obstacle detected to the front or rear.

The area where the obstacle has been detected is displayed (display **C**). Depending on the vehicle, the area is displayed in green, orange (or yellow depending on the vehicle) or red, depending on the proximity of the detected obstacle.

 In the event of a change in trajectory during a manoeuvre, the risk of collision with an obstacle may be signalled late.

3

## Special case of obstacles detected on the side



Depending on the direction of the wheels, the system determines the vehicle trajectory and notifies the driver if there is a risk or not of a collision with an obstacle **3** to the side of the vehicle.

If a side obstacle is detected:

## PARKING AIDS

- the beeps become faster and then sound continuously as the obstacle **3** has been detected is displayed (display **D**).
- if there is no risk of collision, no beep will sound when approaching the obstacle. Depending on the vehicle, the area where the obstacle **3** has been detected is shown interspersed.



In the event of a change in trajectory during a manoeuvre, the risk of collision with an obstacle may be signalled late.

### Activation/deactivation

#### Activation/deactivation from the multimedia screen **4**



From the "Vehicle" world on your multimedia screen **4**, press the "Parking assistance" menu.

Activate or deactivate areas covered by the ultrasonic detectors.

Please refer to the multimedia instructions for further information.

**Note:** depending on the vehicle, the rear detection zone cannot be deactivated.

### Parking distance control automatic deactivation

The system is deactivated:

- when the vehicle speed is above approximately 6 mph (10 km/h);
- depending on the vehicle, when the vehicle is stationary for more than approximately five seconds and an obstacle is detected (such as when in a traffic jam, etc.);
- when in **N** position;
- when an operating fault is detected.

**Note:** depending on the vehicle, if the vehicle is fitted with a towbar recognised by the system, only the rear Park Assist function is deactivated.

### Settings



For safety reasons, carry out any adjustments while the vehicle is stationary.



Each time the vehicle is started, the function resumes the activation status saved the last time the engine was stopped.

## PARKING AIDS

### Settings from the multimedia screen 4



With the vehicle stationary, from the "Vehicle" world on the your multimedia screen 4, press the "Parking assistance" menu.

Please refer to the multimedia instructions for further information.

### Deactivating the system sound

(depending on the vehicle)

Activate or deactivate the parking distance control sound.

**Note:** if you mute the sound, when approaching an obstacle you will be alerted only by the display.

### Parking distance control audio volume

Adjust the Park Assist volume using the volume bar.



Each time the vehicle is started, the function continues the mode saved the last time the engine was stopped.

### Special cases

You can manually deactivate sound alerts or, depending on the vehicle, the detection zone concerned in the event that:

- towing, carrying or trailer equipment that is unrecognised by the system is present in front of the ultrasonic sensors;
- the ultrasonic sensors are damaged.

**Note:** even if the sound is muted, the displays will continue to warn you.

### Operating faults

When the system detects a malfunction: either a beep sounds for about three seconds when the reverse gear is engaged, accompanied by the "Check Parking sensors" message on the instrument panel, or the system

does not produce a sound or display when the reverse gear is engaged.

Check that the ultrasonic sensors are clean.

If it the fault persists, consult an approved dealer.

# PARKING AIDS

## Advice



When the vehicle is travelling at a speed below approximately 6 mph (10 km/h), some noises (motorcycle, lorry, pneumatic drill, etc.) may trigger the Park Assist system audible warnings.



### **System servicing/repairs**

- In the event of an impact, the alignment of the sensors may be altered and their operation may consequently be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the sensors are located (repairs, replacements, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

### **System disturbance**

Some conditions can disrupt or damage the system operation, for example:

- poor weather conditions (rain, snow, hail, black ice, etc.);
- some types of noise (motorcycle, lorry, pneumatic drill, etc.);
- fitting an non-compatible towing ball or hook.

### **Risk of false alarms or absence of warnings**

If the system behaves abnormally contact an authorised dealer.

## PARKING AIDS



### **Limitation of the system operation**

- The area around the sensors must be kept clean and free of any modifications in order to ensure the proper operation of the system.
- Small objects moving close to the vehicle (motorcycles, bicycles, pedestrians, etc.) may not be recognised by the system.
- The system may not detect obstacles that are too close to the vehicle.
- The system may not provide a warning when the other vehicles or obstacles are travelling at a significantly different speed.
- During a change in trajectory during a manoeuvre, the system may report obstacles with a delay.
- When the vehicle is towing a trailer, the rear Park Assist system must be deactivated.

# PARKING AIDS

## Reversing camera

### Operation



When reverse gear is engaged, the camera **1** located at the rear of the vehicle transmits a view of the area behind the vehicle to the multimedia screen **2** accompanied by three guide lines **3**, **4** or **5** (fixed, moving and trailer guide lines).

This system uses several guidelines for its operation (mobile for trajectory and fixed for distance). When the red zone is reached, use the bumper image to stop accurately.



### Fixed guide lines **3**


The fixed guide line includes colour markers **A**, **B** and **C** indicating the distance behind the vehicle:

- **A** (red) at approximately 30 centimetres from the vehicle;
- **B** (yellow) at approximately 70 centimetres from the vehicle;
- **C** (green) at approximately 150 centimetres from the vehicle.

This gauge remains fixed and indicates the vehicle trajectory if the wheels are in line with the vehicle.

### Moving guide lines **4**

This is shown in blue on the multimedia screen **2**. It indicates the vehicle trajectory according to the position of the steering wheel.



### Trailer guide lines **5**

This is shown in blue on the multimedia screen **2**. This indicates the trajectory of the trailer towbar according to the steering wheel position. It allows the driver to position the towbar as close as possible to the trailer's towing head.

### « Trailer view »

If a trailer is connected, while in a forward gear press the "Camera" menu in the "Vehicle" world on your multimedia screen **2** to enable the camera **1** to transmit the view of the area behind during approximately 30 seconds.

# PARKING AIDS

## Settings



From the multimedia screen **2**, when reverse gear is engaged, press the "Settings" button to add or remove guide lines and to adjust the camera image settings (brightness, contrast, etc.).

Please refer to the multimedia instructions for further information.



Make sure that the camera is not obscured (by dirt, mud, snow, condensation etc.).

## "Zoom auto" function

If an obstacle is detected behind the vehicle, the "Auto zoom" switches the current display to a top rear view.

To activate/deactivate the "Auto zoom" function, refer to the multimedia instructions.



The screen shows a reverse mirror image.

The frames are a representation projected on a flat surface. This information is to not be taken into account when superimposed on a vertical object or an object on the ground.

Objects which appear on the edge of the screen may be deformed.

In very bright light (snow, vehicle in sunshine, etc.), the camera vision may be adversely affected.

If the luggage compartment is open or incorrectly closed, the "WARNING: Boot Open" message appears.

## Operating faults

When reverse gear is engaged, if the system detects an operating fault, a

black screen is displayed temporarily on the multimedia screen **2**.

This may be caused by a fault affecting the camera or screen (clearness, fixed image, delayed communication etc.).

If the temporary display of the black screen persists, please contact an approved dealer.



This function is an additional aid. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver.


The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.

## PARKING AIDS

Difference between the estimated distance and actual distance


Reversing towards a steep uphill slope

3



The fixed guidelines **6** show the distances as closer than they actually are. The objects shown on the screen are actually further away on the slope. For example, if the screen displays an object at **D**, the actual distance of the object is at **E**.

Reversing towards a steep downhill slope




The fixed guidelines **6** show the distances as further than they actually are.

Therefore, the objects shown on the screen are actually closer on the slope.

For example, if the screen displays an object at **G**, the actual distance of the object is at **F**.

Reversing towards a protruding object




Position **H** seems further than position **J** on the screen. However, position **H** is at the same distance as position **K**.

The trajectory indicated by the fixed and mobile guidelines do not take into account the height of the object. There is also a risk that the vehicle may collide with the object when reversing towards position **K**.

# PARKING AIDS

## Hands-free parking

### Introduction



As indicated by the arrows **1**, the ultrasonic detectors installed in the vehicle bumpers help to find accessible parking spaces and assist the parking manoeuvre.

Remove your hands from the steering wheel, you only control:

- the accelerator pedal;
- the brake pedal;
- the gear control.

At any time, you can regain control by using the steering wheel.



This function is an additional driving aid. Under no circumstances should it replace the driver's care or responsibility whilst reversing.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.



An impact to the underside of the vehicle while manoeuvring (e.g. striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g. deformation of an axle).

To avoid any risk of accident, have your vehicle checked by an approved Dealer.

## Switching on



**2**

With the vehicle stationary or driving at less than approximately 19 mph (30

## PARKING AIDS

km/h), there are several ways to access the function:

- via the multimedia screen **3**, from the "Vehicle" world **2**, press the "Driving aids" menu, then the "Parking" tab to access the Park Assist menu;
- via the "Hands-free parking" widget (if previously configured);
- via the "Favourites" button on the steering wheel (if previously configured).

Please refer to the multimedia instructions for further information.

### Special features



Ensure that the ultrasonic detectors indicated by the arrows **1** are not ob-

sured (by dirt, mud, snow, a badly fitted number plate, etc.).

### Choice of manoeuvre

The system can perform three types of manoeuvre:

- parking the vehicle in a parallel or perpendicular parking space;
- moving out of a parallel parking space.

From the multimedia screen **3**, select the manoeuvre to carry out.

**Note:** when starting the vehicle, or after having successfully completed parallel parking using the system, the default manoeuvre proposed by the system is assistance in exiting a parallel parking space.

In other cases, the default manoeuvre can be set from the multimedia screen **3**.

Please refer to the multimedia instructions for further information.



The system start up is accompanied by activation of the Park Assist and, on those vehicles equipped with one, the reversing camera to help the driver visualise the manoeuvre → **258**, → **264**.

### Operation



This function is an additional driving aid. Therefore, it can under no circumstances replace the driver's vigilance and responsibility during manoeuvres (the driver must always be ready to brake).



When manoeuvring, the steering wheel may turn quickly: do not put your hands inside and make sure that nothing is caught inside.

## PARKING AIDS

### Parking the vehicle in a parallel or perpendicular parking space

As long as the vehicle speed is less than 19 mph (30 km/h), the system looks for available parking spaces on both sides of the vehicle.

Once a space has been found, it is displayed on the multimedia screen **3**, indicated by the letter "P". Drive slowly until the "STOP" message appears accompanied by a beep. If several spaces are detected on either side of the vehicle, you must select the desired space by activating the direction indicator. If the spaces are on the same side of the vehicle, only the last space detected by the system will be taken into account.

The space turns green on the multimedia screen **3** and is marked by the letter "P".

- Stop the vehicle;
- select reverse gear.

The indicator light  is displayed on the instrument panel and a beep sounds.

- Let go of the steering wheel;
- follow the system instructions on the multimedia screen **3**.

Your speed should not exceed around 4 mph (7 km/h).

Once the indicator light  on the instrument panel goes off and a beep sounds, the manoeuvre has been completed.

### Moving out of a parallel parking space.

- Activate the "Hands-free parking" function;
- select the "Exit parallel parking space" mode;
- activate the direction indicator lights on the side on which you wish to exit the vehicle;

If all the conditions are met, a message will appear on the multimedia screen **3** to start the manoeuvre.

- press "OK" to start.

The  warning light appears on the instrument panel and a beep sounds.

- Let go of the steering wheel;
- carry out forward and backward manoeuvres following the instructions shown on the multimedia screen **3** and using the alerts provided by the Park Assist system.

Your speed should not exceed around 4 mph (7 km/h).

Once the vehicle is in a position to exit the parking space, the  warning light disappears from the instrument panel accompanied by a beep and a message appears on the multimedia screen **3** to confirm that the manoeuvre is complete.

### Suspending/resuming the manoeuvre

The manoeuvre is suspended in the following cases:

- an obstacle in the direction of movement prevents the manoeuvre from being completed;
- a passenger door or the luggage compartment door is opened.

The  warning light disappears from the instrument panel accompanied by a beep to inform you that the manoeuvre has been interrupted. The "Park manoeuvre suspended" message and the reason for interrupting the manoeuvre will be displayed on the multimedia screen **3**.

Make sure:

- you have let go of the steering wheel;
- and
- that all doors and the luggage compartment are closed;

## PARKING AIDS

and

- that no obstacles are in the way of the direction of movement;

and

- that the engine is started.

3

If the  warning light flashes, this indicates that the system is once again available to resume the manoeuvre.

To resume the manoeuvre, press the

"Parking assistance" menu. The  warning light appears on the instrument panel.

Follow the instructions shown on the multimedia screen **3**.

### Cancelling the manoeuvre

The manoeuvre is cancelled in the following cases:

- you take control of the wheel;
- the vehicle is stationary for too long;
- the parking brake is applied;
- the vehicle speed has exceeded approximately 4 mph (7 km/h);
- the vehicle wheels have skidded;
- the engine start/stop button is pressed;
- via the multimedia screen **3**;
- The instructions given on the multimedia screen are not respected;
- the driver's seat belt is unfastened;

- the driver's door is opened;
- you have performed more than ten forwards/backwards movements in one manoeuvre;
- the parking distance control sensors are dirty or obscured.

The  warning light disappears from the instrument panel accompanied by a beep to warn you that the manoeuvre has been aborted. The "Park manoeuvre cancelled" message and the reason for cancelling the manoeuvre will be displayed on the multimedia screen **3**.

### Function unavailable

When you select one of the system activation methods, if the operating conditions are not met, the "Hands-free parking unavailable" message is displayed on the instrument panel to inform you that the function is unavailable.

### Operating faults

When the function detects an operating fault, the following messages are displayed on the instrument panel:

- "Check Park Assist", accompanied

by the  warning light;

or

– « Check Parking sensors » ;

or

– « Check Parking assist ».

Clean the ultrasonic sensors. If there is still a problem, contact an approved dealer.

**Note:** if there is a fault with the function, the vehicle is not immobilised.

**Take control of the vehicle again immediately.**

# PARKING AIDS

## Warnings



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle. Make sure that the manoeuvre complies with the applicable traffic regulations in your location.

The driver should always be ready for sudden incidents while driving: always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, towing equipment, etc.) in the blind spot when manoeuvring.

### **System servicing/repairs**

- In the event of an impact, the operation of the sensors may be affected. Deactivate the function and consult an authorised dealer.
- Any work in the area where the sensors are located (repairs, replacements, exterior trim modifications, etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

### **In the event of system disturbance**

Certain conditions may disrupt or impair operation of the system, such as poor weather conditions (snow, hail, ice, etc.). In the event of the system behaving abnormally, deactivate it and contact an authorised dealer.

### **Risk of erroneous false alarms.**

### **Limitations of the system operation**


- The system cannot detect objects located in the sensor blind spots.
- Always look to check that the parking space suggested by the system is actually still available and free from obstacles before and during the entire manoeuvre.
- The system must not be used when towing a trailer or when there is a towing or load carrying system on the vehicle or on surrounding vehicles.

# PARKING AIDS

## Parking exit warning

### Introduction


3



Using information from the radars installed on each side of the rear bumper (zone **A**), the system warns the driver when another vehicle appears in the detection zone **B**.

The function is activated if:

- the reverse gear is engaged;
- and
- the vehicle is stationary or driving at a low speed.



The system's detection capability depends on the vehicle's surroundings (static objects etc.) and the condition of the bumper etc.



This function is an additional driving aid. This function is not under any circumstances intended to replace the due care and attention of the driver, who should at all times be in control of the vehicle.

### Special feature



Make sure that the radar zone **A** is not obscured (by stickers, mud, snow, etc.).

If a radar is obscured, the "Side radars no visibility" message will appear on the instrument panel. Clean the area where the sensors are located.

## PARKING AIDS

### Activation/deactivation from the multimedia screen 1



To activate or deactivate the function, refer to the multimedia instructions. Select "ON" or "OFF".


### Operation



The function warns you if a vehicle is in zone **B** and is approaching your vehicle.

When a vehicle is detected, the warning lights **2** light up on both door mirrors **3**.

**Note:** clean the door mirrors **3** regularly so that the warning lights **2** can be seen.



The warning lights **4** on the multimedia screen indicate the side on which the approaching vehicle has been detected.

**Note:** clean the camera regularly so that it is not obscured.

Warning lights **2** and **4** are accompanied by a beep when reverse gear is engaged and your vehicle is moving.

### Operating faults

If the vehicle is fitted with a towbar recognised by the system and a trailer has been connected, the parking exit warning is automatically deactivated and the following message is displayed on the instrument panel: "Driving assist unavailable".

## PARKING AIDS

If the system detects a fault, the "Check Side radars" message is displayed on the instrument panel. Consult an approved dealer.

3



Due to the presence of sensors behind the bumper, it is advisable to entrust any operation on the bumper (repair, replacement, paintwork, etc.) to a qualified professional.



### Limitation of the system operation

- The radar area should be kept clean and free of any modifications in order to ensure the proper operation of the system.
- Small objects (motorcycles, bicycles, pedestrians etc.) moving towards the vehicle may not be recognised by the system.

### Deactivating the function

You must deactivate the function if:

- the radar zone **A** has been damaged (rear bumper);
- the vehicle is fitted with a tow-bar that is not recognised by the system.



This function is an additional driving aid. This function is not under any circumstances intended

to replace the due care and attention of the driver, who should at all times be in control of the vehicle. The system should under no circumstances be taken to be an obstacle detector or an anti-collision system.

### System servicing/repairs

- In the event of an impact, the position of the radars may be changed, affecting the function. Deactivate the function and consult an authorised dealer.
- Any work in the area where the radars are located (repair, replacement, bodywork etc.) must be carried out by a qualified professional.

Only an authorised dealer is qualified to service the system.

# PARKING AIDS



## System disturbance

Some conditions can disrupt or damage the system operation, for example:

– a complex environment (underground car park, metallic structures, etc.);

– poor weather conditions (snow, heavy rain, hail, black ice etc.).


## Deactivating the function

You must deactivate the function if the vehicle is being towed (breakdown recovery) or if the vehicle is fitted with a towbar that is not recognised by the system.

In the event of the system behaving abnormally, deactivate it and contact an authorised dealer.


## Safe passenger exit

### Description



This function is an additional driving aid for the safety of the occupants of the vehicle.

The purpose of the "Safe passenger exit" function is to warn the driver and/or passengers of the potential danger if they open their doors when the vehicle is stationary.



Using information from the sensors installed on each side of the rear bumper (zone **C**), the function warns the driver:


– when another vehicle (or motorcycle, bicycle, pedestrian, etc.) is within the detection zone **A**;

and

– when there is a risk of collision with a vehicle (or motorcycle, bicycle, pedestrian, etc.) in the zone **B**.

## PARKING AIDS

### Special feature



Ensure that zone **C** around the radars on each side of the rear bumper is not obstructed (by dirt, mud, snow, etc.).

If a radar is obscured, the "Side radars no visibility" message will appear on the instrument panel. Clean the area where the sensors are located.

You must deactivate the function if:

- the radar zone **C** has been damaged (rear bumper);
- the vehicle is fitted with a towbar that is not recognised by the system.

### Operation



When a door is opened and a moving object is detected, the warning light **1** is displayed on the door mirror **2** and, depending on the vehicle, the ambient lights in the front door are illuminated.

**Note:** clean the door mirrors **2** regularly so that the warning light **1** can be seen.



When the detected object is very close, a beep will sound, along with the **3** "Lateral obstacle detected" warning message on the instrument panel.

**Note:** the system remains active for some time after the ignition has been switched off.

## PARKING AIDS

### Activating/deactivating the function from the multimedia screen 4



To activate or deactivate the function, refer to the multimedia instructions.



When the vehicle is unlocked, the function returns to the last saved status on the multimedia screen.

### Conditions for non-function

- The vehicle is moving and is not completely stationary;
- the vehicle is locked from the outside;

- there are moving objects (motorbikes, bicycles, pedestrians, vehicles, etc.) moving towards or near your vehicle at a low speed that is not considered a risk by the system;
- the range of the sensors located inside the rear bumper is hidden by objects, such as other particularly wide parked vehicles those parked very close to your vehicle.

If the vehicle is equipped with a towbar recognised by the system, the "Driving assist unavailable" message displayed on the instrument panel informs you that the function is not operational.

For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer.

### Operating faults

If the system detects a fault, the "Check Side radars" message is displayed on the instrument panel. Consult an approved Dealer.



This feature may not detect certain vehicles or moving objects in the vicinity of your vehicle.

This function is not in any way a substitute for the vigilance and responsibility of the driver and the occupants of the vehicle, who are always responsible for paying particular attention to the traffic situation and checking the area before leaving the vehicle.

### In the event of system disturbance

Certain conditions (complex environment, poor weather conditions, etc.) may disrupt or damage the operation of the system, with the risk of false alarms.

# EMERGENCY CALL

## Introduction

If the vehicle is equipped, the emergency call function can be used to call the emergency services (without charge) automatically or manually in the event of an accident or illness, reducing the time it takes for the emergency services to arrive.

**Note:** the emergency call function is operational:


- in countries covered by the telematics services and infrastructure associated and compatible with the system;
- depending on the network coverage in the geographical region where the vehicle is being driven.

If you use the emergency call function to report an accident which you have witnessed, this implies stopping where traffic conditions allow in order for the emergency services to locate your vehicle and therefore the location of the reported accident.

In all cases, comply with local legislation.



Use the emergency call only in the event of an emergency you are involved in, if you witness an accident or if you feel ill.



1. System operation warning light:
  - green: operational (network available);
  - off: non-operational (network unavailable);
  - red: operation fault;
  - flashing green: call in progress.
2. "SOS" button.
3. Microphone.

4. Speaker (depending on the vehicle).



A call always takes place as follows:


- the call is initiated with the emergency services;
- data related to the incident (manufacturer's plate, time of the call, last locations, vehicle direction, etc.) is sent;
- voice communication takes place with the emergency services;
- if necessary, emergency assistance is called.

There are two emergency call modes:

- automatic mode;
- Manual mode.

# EMERGENCY CALL

## Operation



### Automatic mode

If the automatic mode warning light **1** appears in green, this confirms that the automatic system is activated.

The emergency call starts automatically in the event of an accident that has required the activation of the protective equipment (seat belt pretensioners, airbag etc.).



In the event of an accident, if the location and traffic conditions permit, stay close to the vehicle in order to be able answer the call centre quickly if necessary.

### Manual mode

The emergency call can be initiated by:

– pressing and holding the button **2** for at least three seconds;

or

– pressing the button **2** five times within 10 seconds.

If the button was pressed by mistake, it is possible to cancel the call by pressing and holding the button **2** for around two seconds, before the call is connected to the call centre.

Once a call is established, only the call centre can end it.

### Operating faults

In some cases, the emergency call may not work (e.g. low battery, etc.).

When the system detects an operating fault, the warning light **1** appears in

red for over 30 minutes. Consult an approved dealer as soon as possible.



The system operates with a dedicated battery. The battery service life is approximately four years (the warning light **1** appears in red to warn you).

Consult an approved dealer.

## EMERGENCY CALL



Without the emergency call feature, the system is not trackable and will not be under constant surveillance. Data is automatically and constantly erased, and the system stores only the last three positions of the vehicle.

According to legislation relevant to the country, data is only sent in the event of an emergency call.

Data sent to the call centre is treated according to the personal data protection laws applicable in the country where you are located. The system stores activity history data for only 13 hours.

The vehicle owner has the right of access to their data. They can request that the data be corrected, deleted or locked.



To guarantee your safety and the proper operation of the system, any operation carried out on the battery (removal, disconnection, etc.) must be carried out by a qualified specialist.

### **Risk of serious burns or electric shocks.**

You must respect the replacement intervals (without exceeding them) as stated in the maintenance document.

The battery is a specific type.

Please ensure it is replaced with the same type.

Call an approved dealer.

## DRIVE MODE

Depending on the vehicle, the DRIVE MODE system enables you to choose from several driving modes that affect the driving, ambient lighting, comfort and driving position:

- all the modes are preconfigured and can be customised (ambient lighting, etc.);
- the "Perso" mode is customisable.

The driving modes influence:

- steering force;
- the Electronic Stability Program;
- engine responsiveness.

They also influence:

- passenger compartment comfort;
- the lighting in the passenger compartment and on the instrument panel;
- the presentation of the instrument panel and the multimedia screen.



Engine settings are specific to each of the driving modes and cannot be customised except for the "Perso" mode.

### Accessing the menu



You can access DRIVE MODE, depending on the vehicle:

- from the multimedia screen **1**;
- using the steering wheel control **2**.

Please refer to the multimedia instructions for further information.



If the Normal or Save modes are selected before the ignition is switched off, the last mode selected will be retained.

When the Sport mode is selected before the ignition is switched off, the Normal mode will be automatically activated upon restarting.

4

### DRIVE MODE modes

#### "Perso" mode

This mode allows the complete configuration of the driving elements, including engine responsiveness.

#### "Save" mode

"Save" mode focuses on energy saving. The engine and heating level can be managed to reduce consumption → 171.

#### "Sport" mode

This mode authorises increased engine responsiveness. The steering is firmer.

## DRIVE MODE

### "Normal" mode

Using standard vehicle settings, this mode gives you the best compromise between comfort and dynamism.



You can reset the mode by mode settings.

4




# AIR VENTS, HEATING AND AIR CONDITIONING

Air vents: air outlets

Air outlets

4



## AIR VENTS, HEATING AND AIR CONDITIONING

1. Driver's position air vents.
2. Windscreen demisting vent.
3. Side window demister outlet.
4. Passenger air vents.
5. Footwell heater outlets for front passengers.
6. Centre air vents.
7. Control panel

# AIR VENTS, HEATING AND AIR CONDITIONING

## Driver's position air vent 1



### Direction

To direct the air flow, turn the air vent **1** using the tab **8**.

**To close:** move the tab **8** away from the steering wheel and beyond the point of resistance.

**To open:** move the tab **8** towards the steering wheel.

## Passenger air vent 4



### Direction

To direct the air flow, turn the air vent **4** using the tab **9**.

**To close:** move the tab **9** towards the outside of the front panel, beyond the point of resistance.

**To open:** move the tab **9** towards the inside of the front panel.

## Centre air vents 6



### Direction

To direct the air flow, turn the air vents **6** using the tabs **10**.

**To close:** move the tab **10** towards the inside of the front panel.

**To open:** move the tab **10** towards the outside of the front panel, beyond the point of resistance.



Do not attach any objects to the air vents (e.g. telephone mounting).

**Risk of damage.**

# AIR VENTS, HEATING AND AIR CONDITIONING

## Air flow



To control the air flow from the air vents **1**, **4** and **6** press or raise the control **11** to the level desired.

To remove bad odours from your vehicle, only use the systems designed for this purpose. Consult an approved Dealer.




Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

**There is a risk of damage or of fire.**

## Automatic climate control

### The controls



1. Driver's heating temperature indicator.
2. Ventilation speed indicator.
3. Air-conditioning activation control.
4. Driver's heated seat activation control.
5. Passenger's heated seat activation control.
6. Heated steering wheel activation control.
7. Passenger compartment air distribution indicator.
8. System off control.

**9.** Passenger compartment air distribution adjustment.

**10.** Activation control for the "A/C MAX" function.

**11.** Air recirculation.

**12.** Air-conditioning activation control in AUTO mode.

**13.** De-icing/demisting of the rear screen and, depending on the vehicle, the rear view mirrors.

**14.** "Clear View" function.

**15.** Adjusting the ventilation speed and stopping the system.

**16.** Adjusting the driver/passenger side air temperature.

## Activating/deactivating the system

### Activating the system

When the vehicle is started, the system returns to the last programme used.

The system is also functional when the vehicle is stationary with the engine on.

Press the control **13** to activate the system or set the control **16** to the desired ventilation speed.

# AIR VENTS, HEATING AND AIR CONDITIONING

## Stopping the system


Press the control **9** to deactivate the system.

## Switching the air conditioning on or off

In automatic mode, the system manages activation of the air conditioning. You will still be able to activate or deactivate the system by pressing the control **5**.

## Automatic mode

The automatic climate control system guarantees comfort in the passenger compartment and good visibility (except in the event of extreme conditions), while optimising fuel consumption.



**12** then press upwards again to activate FAST mode.

When the air conditioning starts in automatic mode, the system returns to the last programme used.



Any action on a button other than the AUTO button disables automatic mode.

## Adjusting the distribution of air in the passenger compartment


The system controls the ventilation speed, air distribution, air recirculation, and starting and stopping the air conditioning and air temperature.

This mode consists of a choice of three programmes:

**AUTO:** optimises the selected comfort level according to exterior conditions. Press button **12**.

**SOFT:** enables the desired temperature level to be obtained more smoothly and silently. Press button **12** then press downwards to activate SOFT mode.

**FAST:** increases the air flow in the passenger compartment. This mode is recommended in particular to optimise comfort in the rear seats. Press button



Press on **9** once or repeatedly to adjust the air distribution. The selected air distribution setting **7** is displayed

## AIR VENTS, HEATING AND AIR CONDITIONING

on the multimedia screen. The positions are in the following order:



All the air is then directed to the windscreen and front side window demisting vents.



The air flow is distributed between front side window demisting vents, the windscreen demisting vents and the footwells.



The air flow is mainly directed to the dashboard air vents.



The air flow is directed towards the dashboard vents and towards the footwells.



The air flow is directed mainly towards the footwells.

### Adjusting the air temperature

Press the control **17** to adjust the air temperature.

### Adjusting the ventilation fan speed

In automatic mode, the system uses the most suitable amount of air to reach and maintain the desired comfort level.

You will still be able to adjust the ventilation speed by pressing the control **16** to increase or reduce the ventilation speed.

### "Clear View" function

Press the button **15**: the built-in indicator light comes on.


This function quickly de-mists the windscreen, rear screen, front side windows and door mirrors (depending on the vehicle). It automatically activates the air conditioning and rear screen de-icing functions.

**To exit this function**, press button **13** or **15**.



Some buttons have an operating light indicating their operative state.

### Rear screen de-icing and demist- ing



Press the button **13**: the built-in indicator light comes on. This function enables rapid demisting or de-icing of the rear screen and de-icing of the rear view mirrors (on equipped vehicles).

**To exit this function**, press the button **13** again. Demisting automatically stops.


### "A/C MAX" function

The "A/C MAX" function enables the user to experience the maximum power of their air conditioning system without any inconvenience or compromise in terms of the acoustics or the feeling

## AIR VENTS, HEATING AND AIR CONDITIONING

of the air being too cold on the hands and face.

66169



4

This function involves automatic modifications:

- temperature programmed to fully cold;
- distribution of air to the occupants;
- air flow at its maximum power;
- activation of the air conditioning;
- air recirculation.

Press the button **10** to activate the function. Deactivate Save mode to make the most of it.

### Air recirculation (isolation of the passenger compartment)

This function is managed automatically, but you can also activate it manual-

ly. In this case the operation is confirmed by an indicator light built into the button **12**.



Demisting/de-icing will still take priority over the air recirculation.

### Manual use

Press the button **12**: the built-in indicator light comes on.

Prolonged use of this position may lead to odours, caused by non-renewal of air, and the formation of condensation on the windows.

We therefore advise you to return to automatic mode as soon as air recirculation is no longer needed, by pressing the button **12**.

### Air purifier

Please refer to the multimedia instructions for further information.

### "Favourites" function



67218

Depending on the vehicle, by pressing the steering wheel control **18** you can activate the following functions according to the stored user settings that you have previously defined:

- heated steering wheel;
- heated seats;
- air purification.

For more information on programming this function, please refer to the multimedia instructions.

## AIR VENTS, HEATING AND AIR CONDITIONING

### Save mode



From the DRIVE MODE menu which can be accessed from the multimedia screen **19** or by pressing the switch **20**, you can activate Save mode which affects the heating level and reduces the vehicle's fuel consumption.

A Save indicator light is shown underneath temperature display on the multimedia screen **19** to inform you that Save mode is activated.

### Air conditioning: programming

#### Air conditioning programming



With the vehicle stationary and the engine on, from the "Vehicle" world **3** on the multimedia screen **1**, press the "Electric" menu **2** then the "Charging and Air conditioning" tab to access the settings.



You can save several comfort programmes by activating the following settings:

- temperature adjustment;
- programming the time by which the vehicle must be ready;
- selecting days when the programme must be repeated.

You can activate/deactivate the saved programmes.

**Note:** you can programme the air conditioning using the MyAlpine application on a smartphone.

Please refer to the multimedia instructions for further information.

# AIR VENTS, HEATING AND AIR CONDITIONING



## Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

In hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS INJURY.**

## Activating "Programming"

The function launches before the time programmed so that the vehicle reaches a comfortable temperature by the time they arrive, if:

- the bonnet is closed;
- the traction battery charge level is over 7.5%;
- the engine is stopped;
- the driver is not in the vehicle.

Warning light  comes on the instrument panel.

## Immediate activation of the air-conditioning

It is possible to carry out immediate starting of the air conditioning, if:

- the bonnet is closed;
- the traction battery charge level is over 7.5%;
- the engine is stopped;
- the driver is not in the vehicle.

The operation of the immediate activation of the air-conditioning is different from programming:

- it must be launched from your smartphone;
- the heated steering wheel and seats function, if your vehicle is equipped, is activated automatically;
- the function stops after approximately 10 minutes.

Please refer to the multimedia instructions for further information.

## Stopping the programmed air conditioning

The air conditioning stops automatically around ten minutes after the set end time.

However, the function can be deactivated if:

- the engine is running;
- the traction battery charging level is lower than 7%;

- the bonnet is open;
- you press one of the switches on the control panel;
- the driver is in the passenger compartment for approximately 20 seconds.

**Note:** these conditions are also applicable for the immediate deactivation of the air conditioning.

If the vehicle is parked for a long time without opening a door with at least one active pre-conditioning schedule, then the function will be deactivated from the third pre-conditioning launch included. The function will be available when one of the doors of the vehicle is opened.

## Air conditioning: information and advice on use

### Information and advice on use

### Advice on use

In some situations (air conditioning off, air recirculation activated, ventilation speed at zero or low etc.), you may notice that condensation starts to form on the windows and windscreen.

If there is condensation, use the **"Clear View"** function to remove it, then use the air conditioning in automatic mode to stop it forming again.

# AIR VENTS, HEATING AND AIR CONDITIONING



Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

**There is a risk of damage or of fire.**

## Consumption

It is normal to notice an increase in energy usage when the air conditioning is operating.

### Advice for reducing consumption and helping to preserve the environment

Drive with the air vents open and the windows closed. If the vehicle has been parked in the sun, open the doors for a few moments to let the hot air escape before starting the engine.

## Maintenance

Refer to the maintenance document for your vehicle for the inspection frequency.



Use the air conditioning system regularly, even in cold weather, running it at least once a month for approximately 5 minutes.

## Operating faults

As a general rule, contact your approved dealer in the event of an operating fault.

### – Reduction in de-icing, demisting or air conditioning performance.

This may be caused by the cabin filter cartridge becoming clogged.

### – No cold air is being produced.

Check that the controls are set correctly and that the fuses are sound. Otherwise, switch off the system.



The vehicle's air conditioning system is also used to cool the traction battery. A prolonged drop in air conditioning efficiency may lead to premature deterioration of the traction battery.

## Presence of water under the vehicle

After prolonged use of the air conditioning system, it is normal for water to be present under the vehicle. This is caused by condensation.



**Do not open the refrigerant circuit.** The fluid may damage eyes or skin.

## Refrigerant fluid



The refrigerant fluid circuit (of which some components are hermetically

# AIR VENTS, HEATING AND AIR CONDITIONING

sealed) may contain fluorinated greenhouse gases.

Depending on the vehicle, you will find the following information on label **A** affixed inside the engine compartment.

The presence and location of the information on label **A** may vary depending on the vehicle.

4



**Type of refrigerant fluid**



**(XXX) Type of oil in the air conditioning circuit**



**Inflammable product**



**Consult the vehicle user manual**



**Maintenance**

x.xxx kg	<b>(1)</b> Quantity of refrigerant fluid present in the vehicle.
GWP xxxxx	<b>(2)</b> Global Warming Potential (CO <sub>2</sub> equivalent).
CO <sub>2</sub> eq x.xxxt	<b>(3)</b> Quantity in weight and in CO <sub>2</sub> equivalent.

## Additional information

Depending on label and depending on the type of refrigerant:

### Refrigerant fluid R-1234yf

- **(1)** 0.450 kg/1.050 kg
- **(2)** GWP 4
- **(3)** 0.002t/0.004t



**Do not open the refrigerant circuit.** The fluid may damage eyes or skin.




Before carrying out any action in the engine compartment, you must switch off the ignition

→ 153.

# MULTIMEDIA EQUIPMENT

## Introduction



The presence and location of this equipment depends on the vehicle version.

1. Multimedia screen.
2. USB-C multimedia ports on the centre console.
3. Steering column control.
4. Voice command.



Please refer to the multimedia instructions for further information.

## "USB-C" multimedia ports

The USB-C multimedia ports **2** can be used to charge accessories with a maximum power of 15 Watts (5 Volts) per port.

**Note:** the USB-C multimedia ports **2** can also be used to transfer data.



Connect accessories with a maximum power of 15 Watts only.  
**Fire hazard.**

## Microphone 5



(For the telephone and voice assistant)



## Using the telephone

We remind you of the need to conform to the legislation in force concerning the use of such equipment.

## Induction charging area 6



Depending on the vehicle, the **3** symbol indicates that area **2** can be used to charge your phone without using a charging cable.

For more information on the wireless charger, please refer to the multimedia instructions.

## MULTIMEDIA EQUIPMENT

 Depending on the country and the subscription, the induction charging zone is also the placement zone for smartphones equipped with a digital key → **59**.

 Please refer to the multimedia instructions for further information.

 It is essential not to leave any objects (start-up card, USB drive, SD card, credit card, jewellery, keys, coins, etc.) **2** in the induction charging zone when charging your phone. Remove any magnetic cards or credit cards from the phone case before positioning your telephone in the induction charging area **2**.

 Objects left in the induction charging area **2** may overheat. You are advised to place them in the areas provided for this purpose (storage compartment, sun visor compartment etc.).

# PASSENGER COMPARTMENT EQUIPMENT

## Electric windows

### Introduction

These systems operate with the ignition on or off, until one of the front doors is opened (limited to about 3 minutes).



#### Driver's responsibility

Never leave your vehicle with the card or key inside, with a child, adult

who is not self-sufficient or a pet in the vehicle, even for a short while.

They may pose a risk to themselves or to others by starting the engine or activating equipment (such as the gear lever or electric windows).

If any part of the body becomes trapped, reverse the direction of the window immediately by pressing the relevant switch.

**Risk of serious injury.**

### One-touch electric windows



Briefly press or pull a window switch as far as it will go: the window will be fully raised or lowered. Pressing the switch again stops the window moving.

**Note:** the rear windows do not open fully.

From the driver's seat, use switch:

1. for the driver's side;
2. for the front passenger's side;
3. and 5 for the rear passengers.



From the passenger seats, press the switch 6.



#### Passenger safety

The driver can deactivate operation of the rear passenger electric windows by pressing switch 4. A confirmation message is displayed on the instrument panel.

## PASSENGER COMPARTMENT EQUIPMENT



Avoid resting any objects against a half-open window: **there is a risk that the electric window could be damaged.**

4

**Note:** if the window detects resistance when almost fully closed (e.g. a tree branch), it stops and then lowers again by a few centimetres.

### Impossible to operate the one-touch electric window

The one-touch electric window is equipped with heat protection: if you press the switch for the window more than 16 consecutive times it goes into protection mode (locking the window).

You can:

- use the electric window switch briefly and with intervals of approximately 30 seconds;
- with the engine running, the window will be unlocked after approximately 20 minutes of inaction on the electric window switch.

### Remote control window opening/closing

When unlocking the doors from the outside, if you **press and hold the**

**card unlocking button**, all the windows equipped with a one-touch electric window will open automatically.

When locking the doors from the outside, if you **press and hold the card locking button**, all the windows equipped with a one-touch electric window will close automatically.

It is recommended that the user only operates the system when the vehicle can be seen clearly and no one is inside.



When closing the windows, ensure that no part of the body (arm, hand, etc.) is protruding from the vehicle.

**Risk of serious injury.**

### Operating faults

In case of a fault when closing a window, the system reverts to normal mode: pull the switch concerned up as often as necessary to fully close the window (the window will close gradually), hold the switch (still on the closure side) for one second then lower and raise the window fully to reinitialise the system.


If necessary, contact an approved dealer.

## Interior lighting

### Map reading lights

### Front map reading lights

(depending on the vehicle)



Touch lights **1** or **2** to activate:

- permanent lighting;
- lighting switches off immediately.

### Note:

– It is not necessary to press the lights to activate or deactivate the lighting. You only need to make contact;

## PASSENGER COMPARTMENT EQUIPMENT

– you can deactivate/activate the illumination of the reading lights when the doors are opened using the multimedia screen → 128.

### Rear map reading lights

(depending on the vehicle)



Touch lights **3** or **4** to activate:

- permanent lighting;
- lighting switches off immediately.

#### Note:

- It is not necessary to press the lights to activate or deactivate the lighting. You only need to make contact;
- you can deactivate/activate the illumination of the reading lights when the

doors are opened using the multimedia screen → 128.

 When the doors are unlocked and opened, the courtesy and footwell lights come on temporarily.

### Luggage compartment light



The light **5** comes on when the luggage compartment is opened.

### Sun visor, Vanity mirrors



#### Sun visor

Lower the sun visor **6** over the windscreen or unclip it and flip it over to the side window.

#### Courtesy mirrors

Lift the cover **7**.

#### Lighting under sun visor

(depending on equipment)

The lighting **8** switches on automatically when the sun visor is opened.

# PASSENGER COMPARTMENT EQUIPMENT

## Accessories socket

### Accessories socket 1



It is provided for connecting accessories.

It can be used for the compressor of your tyre inflation kit, for example → 321.



Connect accessories with a maximum power of 120 watts (12 V) only.  
**Fire hazard.**

# PASSENGER COMPARTMENT STORAGE, FITTINGS

## Front storage compartments

### Storage compartments of the front doors 1



Nothing should be placed on the floor (area in front of the driver) as these objects may slide under the pedals during sudden braking manoeuvres, thus obstructing their use.

### Centre console storage compartment or induction charging zone 2



Depending on the vehicle, the 3 symbol indicates that area 2 can be used to charge your phone without using a charging cable.

For more information on the wireless charger, please refer to the multimedia instructions.



Depending on the country and the subscription, the induction charging zone is also the placement zone for smartphones equipped with a digital key → 59.



It is essential not to leave any objects (start-up card, USB drive, SD card, credit card, jewellery, keys, coins, etc.) 2 in the induction charging zone when charging your phone. Remove any magnetic cards or credit cards from the phone case before positioning your telephone in the induction charging area 2.



Objects left in the induction charging area 2 may overheat. You are advised to place them in the areas provided for this purpose (storage compartment, sun visor compartment etc.).



Please refer to the multimedia instructions for further information.

## PASSENGER COMPARTMENT STORAGE, FITTINGS

### Centre armrest storage compartment 5



Pull the cover **4** of the central armrest upwards.



Ensure that no hard, heavy or pointed objects are placed in the "open" storage compartments in such a way that they may fall onto passengers during sharp turning, sudden braking or in the event of an accident.



When turning corners, accelerating or braking, ensure that the receptacle being held by the cup holder is not dislodged. **There is a risk of burning if hot liquid escapes.**

### Sun blind storage compartment 6



Can be used to hold motorway toll tickets, maps, etc.

### Glovebox



To open it, pull the handle **7**.

It can hold a box of tissues, a bottle of water, etc.

# PASSENGER COMPARTMENT STORAGE, FITTINGS

## Rear storage compartments

### Storage pocket 8



(depending on the vehicle)

## TRANSPORTING OBJECTS

### Transporting objects in the luggage compartment

Always position the objects transported so that the largest surface is against:



– The back of the rear bench seat, for normal loading (example **A**).



– the front seatbacks with the rear seatbacks folded down, as is the case for maximum loads (example **B**).

Ensure that the objects being transported are evenly distributed throughout the loading area.

If you have to place objects on the folded seat back, it is vital that you remove the headrests before folding the seat back so that it can be folded as flat as possible against the seat.



**When refitting the seat-back**, make sure it is correctly locked in place.

**If seat covers are fitted**, make sure these do not prevent the seatback latch from locking in.

Make sure that the seat belts are positioned correctly.

Reposition the headrests. The headrest is a safety component; check that it is fitted and in the correct position.



Always position the heaviest items directly on the floor. If the vehicle is equipped, use the lashing points **1** located on the luggage compartment floor. The luggage should be loaded in such a way that no items will be thrown forward and strike the occupants if the driver has to brake suddenly. Fasten the rear seat belts, even if the seats are not occupied.



# TRANSPORTING OBJECTS

Towbar

# TRANSPORTING OBJECTS


## Towbar

**i** **Permissible nose weight, maximum permissible towing weight while braked and unbraked: → 352.**  
**Choice and fitting of towing equipment**

Towbar (cross member and hitch) not originally fitted to the vehicle: the entire towbar and mountings must not exceed 25 kg in weight. Any towing device must not obstruct any lighting component or the number plate when not in use. In all cases, you must comply with the regulations of the particular country you are in.


For fitting and conditions of use, refer to the equipment's fitting instructions.

Please keep these instructions with the rest of the vehicle documentation.



Maximum size **A**: 799 mm.

In order not to damage your vehicle, it is strictly forbidden to use the towing point and other means to tow another vehicle.



# ACCESSING THE ENGINE, LEVELS

## Bonnet

### Unlocking the bonnet catch



To open, pull the handle **1** located on the left-hand side of the dashboard.



Do not do any work under the bonnet when the vehicle is charging or when the ignition is switched on.



Do not press down on the bonnet as there is a **risk that the bonnet may accidentally close.**



To unlock, push the lever **2** to the left while raising the bonnet.



In the event of even a slight impact involving the radiator grille or bonnet, have the bonnet lock checked by an approved Dealer as soon as possible.



The vehicle drive system in an electric vehicle uses a direct voltage of approximately 400 volts.

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle. Any intervention or modification on the vehicle's 400 V electrical system (components, cables, connectors, traction battery) is strictly prohibited.

**The risk of serious burns or electric shocks can lead to death.**

The engine cooling fan may also


start at any moment. The  label in the engine compartment reminds you of this.

**Risk of injury.**

# ACCESSING THE ENGINE, LEVELS


## Opening/closing the bonnet

### Opening the bonnet



After raising the bonnet and disengaging the strut **4** from its mounting **3**, for your safety you **must** position the strut in its placement **5**.

### Closing the bonnet



Before closing the bonnet, make sure that nothing has been left in the engine compartment.

To close the bonnet, re-engage the strut **4** in its mounting **3**. Hold the middle of the bonnet and guide it down to 30 cm above the closed position, then release it. It will latch automatically under its own weight.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.  
**Risk of injury.**



Ensure that the bonnet is properly locked.  
Ensure that nothing is preventing locking (grit, cloths, etc.).



After any procedure in the engine compartment, make sure that you do not forget anything (cloth, tools, etc.).  
Otherwise, this may lead to engine damage or cause a fire.

# ACCESSING THE ENGINE, LEVELS

## Coolant level

## Coolant level



Depending on the vehicle, the location of the coolant reservoirs may vary:

- reservoir **1** is used to cool the engine circuit and the battery;
- reservoir **2** is used to cool the passenger compartment circuit.

The level should be read with the engine switched off and on level ground. For each reservoir, the level **when cold** must be between the "MINI" and "MAXI" marks on the coolant reservoirs **1** and **2**.

Top this level up **when cold** before the "MINI" mark is reached.

**Note:** for a new vehicle in the running in phase: the fluid level may be higher than the "MAXI" mark on the reservoir, then drop between the level "MINI" and "MAXI". This does not present a risk.



If there is an abnormal or repeated drop in the fluid level, consult an approved dealer.



No operations should be carried out on the cooling circuit when the engine is hot.

**Risk of burns.**



The vehicle drive system in an electric vehicle uses a direct voltage of approximately 400 volts.

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle.

Any intervention or modification on the vehicle's 400 V electrical system (components, cables, connectors, traction battery) is strictly prohibited.

**The risk of serious burns or electric shocks can lead to death.**

The engine cooling fan may also

start at any moment. The  label in the engine compartment reminds you of this.

**Risk of injury.**

## Frequency of checking coolant level

**Check the coolant levels regularly** (very severe damage is likely to be caused to the engine and battery if there is insufficient coolant).

## ACCESSING THE ENGINE, LEVELS

If the level needs to be topped up, only use products approved by our Technical Department which ensure:

- antifreeze protection;
- anti-corrosion protection of the cooling system.

### Replacement intervals

Refer to the maintenance document for your vehicle.




Do not do any work under the bonnet when the vehicle is charging or when the ignition is switched on.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.  
**Risk of injury.**

### Levels, filters

#### Brake fluid level



The level should be read with the engine switched off and on level ground. This should be checked frequently, and immediately if you notice even the slightest loss in braking efficiency.

#### Replacement intervals

Refer to the maintenance document for your vehicle.



If there is an abnormal or repeated drop in the fluid level, consult an approved dealer.

#### Topping up

After any operation on the hydraulic circuit, a specialist must replace the fluid. Only use fluids approved by our Technical Department (and taken from a sealed container).

#### Level 1

It is normal for the level to drop as the brake shoes become worn, but it must never drop lower than the warning line "MINI".

If you wish to check the disc wear yourself, you should obtain the document explaining the checking procedure from our Network or from the manufacturer's website.

# ACCESSING THE ENGINE, LEVELS

## Windscreen washer reservoir



### Topping up

Open the cap **2**, fill until you can see the fluid, then refit the cap.

### Fluid

Only use windscreen washer fluid containing antifreeze.

We advise you to consult an approved dealer or a qualified professional.

**Note:** do not use hard water (risk of damage to the priming pump, limescale building up on the pump and the jets).

# BATTERY

## Secondary 12 V battery

### Introduction



The secondary battery is a 12 V battery: it supplies the energy required to operate vehicle equipment (lights, windscreen wipers, windows, audio system, etc.) and certain safety systems such as braking assistance.

**You should not open it or add any fluid.**



Do not do any work under the bonnet when the vehicle is charging or when the ignition is switched on.

### Maintenance/replacement

The secondary 12 V battery **1** charging status may diminish, especially if you use your vehicle:

- when the outside temperature drops;
- after extended use of energy-consuming devices with the engine switched off.



For your own safety and to ensure the proper operation of the vehicle's electrical equipment (lights, windscreen wipers, ABS etc.), any intervention on the secondary "12 V" battery (removal, disconnection, etc.) must **ALWAYS** be performed by a specialist professional.

**Risk of serious burns or electric shocks.**

You **must** respect the replacement intervals (without exceeding them) as stated in the maintenance document.

The battery is a specific type. Please ensure it is replaced with the same type.

Call an approved dealer.

# BATTERY



The vehicle drive system in an electric vehicle uses a direct voltage of approximately 400 volts.

This system can get hot during and after switching off the ignition. Respect warning messages given on the labels in the vehicle.

Any intervention or modification on the vehicle's 400 V electrical system (components, cables, connectors, traction battery) is strictly prohibited.

**The risk of serious burns or electric shocks can lead to death.**

The engine cooling fan may also

start at any moment. The  label in the engine compartment reminds you of this.

**Risk of injury.**

## Label A



Observe the indications on the battery.

2. Naked flames and smoking are forbidden.
3. Eye protection required.
4. Keep away from children.
5. Explosive materials.
6. Refer to the manual.
7. Corrosive substances.

## Breakdown recovery



Do not disconnect the secondary 12 V battery.  
**Risk of serious burns or electric shocks.**



To avoid damaging your vehicle, do not recharge the secondary 12 V battery using:

- an external battery charger;
- a battery from another vehicle.

Call an approved Dealer.



Do not use your electric vehicle to restart the 12 volt battery in another vehicle. The 12 volt electric power of an electric vehicle is not enough to perform such an operation.  
**Risk of damage to the vehicle.**

# CLEANING

## Bodywork maintenance

### Bodywork maintenance

A well-maintained vehicle will last longer. It is therefore recommended to maintain the exterior of the vehicle regularly.

Your vehicle has been treated with very effective anti-corrosion products. It is nevertheless subject to various outside influences.

#### Corrosive agents in the atmosphere

- atmospheric pollution (in built-up and industrial areas);
- saline atmospheres (near the sea, particularly in hot weather);
- seasonal and damp climatic conditions, (e.g.: road salt in winter, water from road cleaners, etc.).

#### Minor impacts

##### Abrasive action

Dust and sand in the air, mud, road grit thrown up by other vehicles, etc.

You should take a number of minor precautions in order to safeguard your vehicle against such risks.

### You should do the following

Wash your car frequently, **with the engine off**, with cleaning products recommended by our Technical Depart-

ment (never use abrasive products). Rinse thoroughly beforehand using a jet washer:

- spots of tree resin and industrial pollution;
- mud in the wheel arches and underneath the body which forms damp patches;
- **bird droppings, which cause a chemical reaction with the paint that rapidly discolours paintwork and may even cause the paint to peel off.**

Wash the vehicle **immediately** to remove these marks as it is impossible to remove them by polishing;

- salt, particularly in the wheel arches and underneath the body after driving in areas where the roads have been gritted.

Withdraw the vegetable falls (resin, film etc.) from the vehicle regularly.

Observe the vehicle stopping distances when driving on gravelled surfaces to prevent paint damage.

Repair, or have repaired quickly, areas where the paint has been damaged, to prevent corrosion spreading.

Remember to visit the body shop periodically in order to maintain your anti-corrosion warranty. Refer to the maintenance document.

Observe local regulations about washing vehicles (e.g. do not wash your vehicle on a public highway).

When washing the vehicle with a high-pressure cleaning device, please take the following precautions:

- make sure that your vehicle's paintwork, the area or the component that you want to clean is compatible with this type of washing;
- the pressure delivered by the device must be less than 100 bar;
- when washing, position the spray nozzle at least 15 cm from the vehicle and check that the water flow rate is less than 3.30 gal (15 l)/min;
- do not persist in washing the same area, impacted points or the seals (risk of damage to the paint, seals becoming detached, etc.).

If mechanical components, hinges, etc. have been cleaned, they must be protected again by spraying with products approved by our Technical Department.



We have selected special products to care for your vehicle and you can obtain these from the manufacturer's accessory outlets.

# CLEANING

## Do not do the following

Wash the vehicle in bright sunlight or freezing temperatures.

Do not scrape off mud or dirt without pre-wetting.

Allow dirt to accumulate on the exterior.

Allow rust to form following minor impacts.

Using solvents not approved by our Technical Department to remove stains may damage the paintwork.

Do not drive in snow or muddy conditions without washing the vehicle, particularly under the wheel arches and body.



Degrease or clean using high-pressure cleaning equipment or by spraying products not approved by our Technical Department:

- mechanical components (e.g. engine compartment);
- wheels (e.g. braking system components such as brake callipers);
- the underbody;
- the parts with hinges (e.g. inside the doors);
- the painted plastic external fittings (e.g. bumpers).

Doing this could give rise to corrosion or operational faults.

## Vehicles with a matte paint finish

This type of paint requires certain precautions.

## You should do the following

Wash the vehicle by hand using plenty of water, using a soft cloth or a gentle sponge.

## Do not do the following

Use wax-based products (polishing).

Rub too hard.

Wash the vehicle in a roller-type car wash.

Attach stickers to the paintwork (risk of leaving marks).



Wash the vehicle using a high-pressure cleaning device.

## Using a roller type car wash

Return the wiper stalk to the Park position ➔ 147.

Check the mounting of external accessories, additional lights and rear view mirrors, and ensure that the wiper

blades are secured with adhesive tape.

Remove the radio aerial mast if your vehicle is fitted with this equipment.

Remember to remove the tape and re-fit the antenna after washing.



### Washing the vehicle

Never wash the engine compartment, the charging connection or the traction battery with a high-pressure jet.

**This risks damaging the electric circuit.**

Never wash the vehicle while it is charging.

**Risk of electric shock and a risk to life.**

## Cleaning the headlights, sensors and cameras

Use a soft cloth or cotton wool.

If this is not sufficient, moisten the cloth with soapy water, always rinsing with a soft cloth or cotton wool.

Finally, carefully dry off with a soft dry cloth.

## CLEANING

**Do not use cleaning products containing alcohol or utensils (e.g. a scraper).**

**Cleaning stickers, decorative films, etc.**

**You should do the following**

Use a soft cloth or cotton wool.

Moisten it slightly with soapy water then always wipe clean with a soft cloth or cotton wool.

Finally, carefully dry off with a soft dry cloth.

**Do not do the following**

Use alcohol-based cleaning products.

Use utensils (e.g. a scraper).

Rub too hard.



Wash the vehicle using a high-pressure cleaning device.

**Interior trim maintenance**

**Introduction**

A well-maintained vehicle will last longer. It is therefore recommended to

maintain the interior of the vehicle regularly.

A stain should always be dealt with swiftly.

Whatever the type of stain, use **cold (or tepid) soapy water prepared with natural soap.**

**Detergents (washing-up liquid, powdered products, alcohol-based products) should not be used.**

Use a soft cloth.

Rinse and wipe up excess water.

**Multimedia screen**

Maintenance of the screen may depend on the type of multimedia equipment. Please refer to the multimedia instructions for further information.

**Glass instrument panel**

(e.g. instrument panel, clock, exterior temperature display, etc.).

Use a soft cloth or cotton wool.

If this does not clean them properly, use a soft cloth (or cotton wool) slightly moistened with soapy water and then wipe clean using another soft damp cloth or cotton wool.

Finally, dry off **carefully** with a soft dry cloth.

**Do not use products containing alcohol and/or spray fluids on the area.**

**Seat belts**

These must be kept clean.

Use products selected by our Technical Department (approved outlets) or warm, soapy water and a sponge and wipe with a dry cloth.

**Detergents or dyes must not be used under any circumstances.**

**Textiles (seats, door trim, etc)**

Vacuum-clean the textiles **regularly.**

**Liquid stain**

Use soapy water.

Dab lightly (never rub) with a soft cloth, rinse and remove the excess.

**Solid or pasty stain**

Carefully remove the excess solid or pasty material **immediately** using a spatula (working from the edges to the centre to avoid spreading the stain).

In the case of a liquid stain, clean as indicated.

## CLEANING

### Special instructions for sweets or chewing gum

Place an ice cube on the stain to solidify it then proceed as for a solid stain.



For further recommendations on maintaining the interior and/or in the event of unsatisfactory results, please consult an approved dealer.

### Removal/replacing removable equipment originally fitted in the vehicle

If you need to remove equipment in order to clean the passenger compartment (for example, mats), always ensure that they are correctly refitted and are the right way around (the driver's mat should be fitted on the driver's side, etc.) and fit them with the components supplied with the equipment (for example, the driver mat should always be fixed using the pre-fitted mounting components).

With the vehicle stationary, always ensure that nothing will impede driving (anything obstructing the pedals, heel wedged by the mat etc.).

### Do not do the following

Position objects such as deodorants, scents etc. near air vents as this could damage your dashboard trim.



Use high-pressure cleaning equipment or sprays inside the passenger compartment:

without careful use, this equipment could impair the correct functioning of the electrical or electronic components in the vehicle, or have other detrimental effects.

# TYRES

## Tyres

### Maintaining the tyres

The tyres are the only contact between the vehicle and the road, so it is essential to keep them in good condition.

You must make sure that your tyres comply with the local regulations set out in the Highway Code.



The tyres must be in good condition and the tread form must have sufficient depth; tyres approved by our Technical Department have wear warning strips **1** which are **indicators moulded into the tread at several points**.

When the tyre tread has been worn to the level of the wear indicators, they

become visible **2**: it is then necessary to replace your tyres because the tread rubber is 1.6 mm deep at most, resulting in poor road-holding on wet roads.

An overloaded vehicle, long journeys by motorway, particularly in very hot weather, or continual driving on poorly surfaced minor roads will lead to more rapid tyre wear and affect safety.



Incidents which occur when driving, such as striking the kerb, may damage the tyres and wheel rims, and could also lead to misalignment of the front or rear axle geometry. In this case, have the condition of these checked by an approved dealer.

### Tyre pressures

Adhere to the tyre pressures. The tyre pressures should be checked at least once a month and additionally before any long journey (refer to the label affixed to the edge of the driver's door) → 320.



**Incorrect tyre pressures** lead to abnormal tyre wear and unusually hot running. These are factors which may seriously affect safety and lead to:

- poor road holding;
- the risk of blow-outs or of throwing a tread.

The pressure depends on the load and the speed of use. Adjust the pressure according to the conditions of use (refer to the label affixed to the edge of the driver's door).

Pressures should be checked when the tyres are cold: ignore higher pressures which may be reached in hot weather or after the vehicle is driven at high speed.

If tyre pressures cannot be checked when the tyres are **cold**, the **pressure values indicated must be increased by 0.2 to 0.3 bar (or 3 PSI)**.

**Never deflate a hot tyre.**

# TYRES



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and may lead to pressure loss. Always use valve caps identical to the originals and screw them down fully.



## Vehicle equipped with a tyre pressure monitoring system

In the event of under-inflation (punctures, etc.), the  warning light appears on the instrument panel or ➔ 175.



It is not permissible to exchange the front wheels (tyres and/or rims) with the rear wheels.

## Fitting new tyres

To fit new tyres, consult an approved dealer.



For your safety and to comply with the law. When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

**They must either have a load capacity and speed rating at least equal to those of the original tyres, or conform to those recommended by an approved dealer.**

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

**Risk of loss of control of the vehicle.**

## Use in winter

### Chains

**For safety reasons, fitting snow chains to the rear axle is strictly forbidden.**

**Chains cannot be fitted** to tyres which are larger than those originally fitted to the vehicle.

## One-way tyres

An one-way tyre must only be fitted in one direction. You must observe this direction.

If an one-way tyre must be fitted in the opposite to its direction of rotation following a puncture, drive with caution, particularly on a wet road, because the tyre specifications will not be adapted.

## "Snow" or "Winter" tyres

We would recommend that these be fitted to all **four wheels** to ensure that your vehicle retains maximum adhesion.

**Caution:** these tyres sometimes have a specific direction of rotation and a maximum speed index which may be lower than the maximum speed for your vehicle.

## Studded tyres

This type of equipment may only be used for a limited period and as laid down by local legislation. It is necessary to observe the speed specified by current legislation.

These tyres must, at a minimum, be fitted to the two front wheels.

# TYRES

**Note:** the use of snow tyres, winter tyres or studded tyres significantly reduces the vehicle range.

 In all cases, we would recommend that you contact an approved Dealer who will be able to advise you on the choice of equipment which is most suitable for your vehicle.




Chains may only be fitted to tyres of the same size as those originally fitted to **your vehicle**.

Chains may be fitted, provided that they are specific chains. We would advise you to consult an approved dealer.

## Tyre pressure


### Label A



Open the door to read it.

Tyre pressures should be checked when the tyres are cold.

If tyre pressures cannot be checked when the tyres are **cold, the pressure values indicated must be increased by 0.2 to 0.3 bar (or 3 PSI). Never deflate a hot tyre.**



**B.** : dimension of the tyres fitted to the vehicle.

**C.** : tyre pressures for the front wheels.

**D.** : tyre pressures for the rear wheels.

The optimal tyre pressure to ensure a good balance between comfort and vehicle behaviour is 2.3 bar. In order to maximise your range, you can increase the tyre pressure to the "ECO" pressure as indicated on the pressure label.

## TYRES

 **Vehicle equipped with a tyre pressure monitoring system**

In the event of under-inflation

(punctures, etc.), the  warning light appears on the instrument panel → 175.

 **Tyre safety and chain fitting:** for information on servicing conditions and, depending on the vehicle version, the use of chains → 318.



**Vehicle used fully laden (Maximum Permissible All-up Weight) and towing a trailer**

The maximum speed must be limited to **62 mph (100 km/h)** and the tyre pressure increased by **0.2 bar** → 352.  
**Risk of tyre blowouts.**

 **Tyre safety and chain fitting:** for information on servicing conditions and, depending on the vehicle version, the use of chains → 318.



For your safety and to comply with the law. When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

**They must either have a load capacity and speed rating at least equal to those of the original tyres, or conform to those recommended by an approved dealer.**

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

**Risk of loss of control of the vehicle.**

## Tyre inflation kit

### Introduction



## TYRES



The kit repairs tyres when the tread **A** has been damaged by objects smaller than 6 mm.

It cannot repair all types of puncture, such as cuts larger than 6 mm, cuts in the tyre sidewall **B**, etc.

Ensure also that the wheel rim is in good condition.

Do not pull out the foreign body causing the puncture if it is still in the tyre.



Do not attempt to use the inflation kit if the tyre has been damaged as a result of driving with a

puncture.

You should therefore carefully check the condition of the tyre sidewalls before any operation. Driving with underinflated, flat or punctured tyres can be dangerous and may make the tyre impossible to repair.

**This repair is temporary.**

A tyre which has been punctured should always be inspected (and repaired, where possible) by a specialist as soon as possible. When taking a tyre which has been repaired using this kit to be replaced, you must inform the specialist.

When driving, vibration may be felt due to the presence of the repair product injected into the tyre.



The kit is only approved for inflating the tyres of the vehicle originally equipped with the kit.

It must never be used to inflate the tyres of another vehicle, or any other inflatable object (rubber ring, rubber boat, etc.).

Avoid spillage on skin when handling the repair product bottle. If droplets do leak out, rinse them off with plenty of water.

Keep the repair kit away from children.


Do not dispose of the empty bottle in the countryside. Return it to your approved dealer or to a recycling organisation.

The bottle has a limited service life which is indicated on its label.

Check the expiry date.

Contact an approved dealer to replace the inflation tube and repair product bottle.

## TYRES



In the event of a puncture, use the kit located underneath the luggage compartment carpet.



### Vehicle equipped with a tyre pressure monitoring system

In the event of under-inflation

(punctures, etc.), the  warning light appears on the instrument panel → 175.

**With the engine running and the parking brake applied:**

- disconnect any accessories that are connected to the vehicle's accessories sockets;
- on vehicles fitted with a towing device, disconnect the towbar socket if needed;
- **see the information on the inflation kit compressor** located in the vehicle luggage compartment and follow the instructions for use;
- inflate the tyre to the recommended pressure → 318;
- after a maximum of **15** minutes, stop inflating and read the pressure (on the pressure gauge **2**);

**Note: while the container is emptying (approximately 30 seconds), the pressure gauge 2 will briefly indicate a pressure up to 6 bar, then the pressure drops.**

- Adjust the pressure: to increase it, continue inflating using the kit. To reduce it, press the button **1**.

**If the recommended pressure of 1.8 bar cannot be achieved after 15 minutes, repair is impossible. Do not drive the vehicle, consult an approved dealer.**




Before using the kit, park the vehicle at a sufficient distance from traffic, switch on the hazard warning lights, apply the parking brake, ask all passengers to leave the vehicle and keep them away from traffic.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

# TYRES

47426



6

Once the tyre is correctly inflated, remove the kit: slowly unscrew the inflation adapter from the container **3** to prevent any product spatter, then store the container in plastic packaging to prevent the product from leaking.

- Affix the driving recommendation label (located under the container) to the dashboard where the driver can see it.
- Put the kit away.
- At the end of this initial inflation operation, air will still escape from the tyre. You must drive a short distance in order to seal the hole.
- Start the vehicle immediately and drive at a speed between 12 to 37 mph (20 to 60 km/h) in order to distribute the product evenly in the tyre. After dri-

ving a distance of 2 miles (3 km), stop and check the pressure.  
– If the pressure is higher than 1.3 bar but lower than the recommended pressure (see the label affixed to the edge of the driver's door), re-adjust it. Otherwise, contact an approved dealer: the tyre cannot be repaired.

## Precautions when using the kit

The kit should not be operated for more than 15 consecutive minutes.

The container must be replaced after the first use even if liquid remains inside.



Nothing should be placed around the driver's feet as during sudden braking such objects may slide under the pedals and obstruct their use.



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and may lead to pressure loss. Always use valve caps identical to the originals and screw them down fully.



Following repair with the kit, do not travel further than 124 miles (200 km). In addition, reduce your speed and under no circumstances exceed 50 mph (80 km/h). The sticker, which you must affix in a prominent position on the dashboard, reminds you of this. Depending on the country or local legislation, a tyre repaired with the inflation kit will need to be replaced.

# TYRES


## Tools

### Location of the tool kit



The tool kit is located under the luggage compartment carpet.

After use, ensure the tools are correctly stored.



### Tyre inflation kit compressor 1

→ 321

### Hubcap tool 2

This tool is used to remove the wheel trims.



You do not need to use a tool to fit or remove the central trim.

### Towing eye 3

→ 326

### Adapter for V2L charging 4

→ 45

### Container of anti-puncture product 5

→ 321




Do not leave the tools unsecured inside the vehicle **as they may be projected during braking**. After use, check that all the tools are correctly clipped into the tool kit, then position it correctly in its housing to reduce the **risk of injury**.

# BREAKDOWN RECOVERY

## Towing: breakdown

## Towing: breakdown



The speed specified by current legislation for towing must always be observed.

Before towing the vehicle or recovering it on a platform, depending on the case, ensure that the gear control is in the **N** position and/or that the parking brake is released.

Observe the following instructions:

- with the card in the passenger compartment, press the engine start button while pressing the brake pedal;
- set the gear control to the **N** → **160** position;

- press the engine start button to stop it;
- press the engine start button for more than two seconds without pressing the brake pedal. The accessories functions are powered: you can use the vehicle lighting functions (hazard warning lights, brake lights, etc.). At night the vehicle must have its lights on. The "Permanent IGN activated" message is displayed on the instrument panel;
- if the driver's seat belt is fastened, unfasten it;
- open the driver's door;
- release the parking brake while pressing the brake pedal → **164**. The "Parking brake loose" message is displayed on the instrument panel;
- close the driver's door and do not lock the vehicle ("Permanent IGN activated" mode must remain activated);
- once the towing is complete, press the engine start button for more than two seconds without pressing the brake pedal (risk of battery discharging). The "Permanent IGN activated" message disappears from the instrument panel.

## Choice of towing

It is strictly forbidden to tow the vehicle with the front wheels on the ground.



Do not leave the tools unsecured inside the vehicle as they may be projected during braking.

## Access to the towing point

**Use only the front towing point 2** (never use the driveshafts or any other part of the vehicle). This towing point may only be used for pulling. It must never be used for lifting the vehicle directly or indirectly.


**Note:** be sure to protect the towing point area, for example using a cloth, when using a flat-blade screwdriver or similar tool.

**Screw in the towing eye 3 by hand as far as possible.**

You must only use the towing eye **3**.

# BREAKDOWN RECOVERY

## Front towing point 2



Press the upper section of the flap **1** to tilt it.



Ensure that the towing ring is bolted correctly.  
**Risk of losing the towed object.**



When the engine is stopped, steering and braking assistance are no longer provided.



- Use a rigid tow bar. If a rope or cable is used (where the law allows this), the vehicle being towed must be able to brake.
- a vehicle must not be towed if it is not fit to be driven.
- avoid accelerating or braking suddenly when towing, as this may result in damage being caused to the vehicle.
- In any case, it is advisable not to exceed **16 mph (25 km/h)**.



In order not to damage your vehicle, it is strictly forbidden to use the towing point and other means to tow another vehicle.

## HEADLIGHTS, LIGHTS: REPLACING BULBS

### Exterior lighting: replacing bulbs

#### Front headlights

LED daytime running lights/side lights/dipped headlights/main beam headlights **1**



Consult an approved Dealer.


LED daytime running lights/side lights **2**

Consult an approved Dealer.

LED direction indicator lights **3**

Consult an approved Dealer.

#### Rear and indicator lights



LED high-level brake light **1**

Consult an approved Dealer.


LED direction indicator lights/side lights/rear fog lights brake lights **2**

Consult an approved Dealer.

LED reversing lights **3**

Consult an approved Dealer.

#### LED number plate lights **4**



Consult an approved Dealer.

# HEADLIGHTS, LIGHTS: REPLACING BULBS


## Indicator lights 5



Consult an approved Dealer.

## Interior lighting: changing bulbs

### Reading lights 1 and 2



Consult an approved dealer.

### Reading lights 3 and 4



Consult an approved Dealer.

## HEADLIGHTS, LIGHTS: REPLACING BULBS

Courtesy mirror lights **5**



Consult an approved dealer.

Luggage compartment light **6**



Consult an approved dealer.

## WIPER BLADES: REPLACEMENT


### Replacing the windscreen wiper blades 2



To replace the wipers, first put them in the service position **B**.

#### With the ignition on and the engine stopped:

- move the stalk **1** twice in succession to position **A** (single sweep): the wiper blades will stop in the service position **B** away from the bonnet;
- raise the wiper arm, lower the tab **4** then remove the blade downwards.




#### Refitting

To refit the wiper blade **2**, insert it into its housing in the arm **3**, then clip it until you hear a click. Make sure that the blade is correctly locked in position.

To return the blades to the lowered position, make sure that the blades are folded down onto the windscreen then set the stalk **1** to position **A** (single sweep): the windscreen wiper blades will fold into the bonnet when the ignition is switched on.

56511



6

**i** Check the condition of the wiper blades. You are responsible for their service life:

- clean the blades and the windscreen regularly with soapy water;
- do not use them when the windscreen is dry;
- free them from the windscreen when they have not been used for a long time.

# WIPER BLADES: REPLACEMENT

## Rear screen wiper blade 5



The stalk in the off position (deactivated):

- lift the wiper arm **6**;
- rotate the rear screen wiper blade **5** (movement **C**) until it unclips;
- release the rear screen wiper blade **5** by pulling it.

### Refitting

To refit the wiper blade, proceed in the reverse order to removal. Make sure that the blade is correctly locked in position.



Check the condition of the wiper blades. You are responsible for their service life:

- clean the blades and the windscreen regularly with soapy water;
- do not use them when the windscreen is dry;
- free them from the windscreen when they have not been used for a long time.



- In frosty weather, make sure that the wiper blades are not stuck by ice (to avoid the risk of the motor overheating).
- Check the condition of the wiper blades.

Replace the wiper blades as soon as they begin to lose efficiency (approximately once a year). Whilst changing the blade, take care not to drop the arm onto the window after it has been removed as this may break the window.



Before changing the rear wiper blade, make sure the stalk is in the stop position (deactivated).

**Risk of injury.**

# FUSES

## Fuse box

If any electrical component does not work, check the condition of the fuses.

## Fuse box A



Unclip the flap **1**.

## Fuse box B


(depending on the vehicle)



The fuses can be accessed behind the glovebox in the passenger compartment **B**. Open the glovebox using the opening button.

You will then have direct access to the fuse box **2**.

## Clamp 3



Remove the fuse using the clamp **3** located on the fuse panel.

To remove the fuse from the tweezers, slide the fuse to the side.

It is not advisable to use the free fuse locations.

## FUSES



Check the fuse in question and, **if necessary, replace it (replacement fuse must have the same rating as the original).**

If a fuse is fitted with too high a rating, it may cause the electrical circuit to overheat (risk of fire) in the event of an item of equipment using an excessive amount of current.



To comply with local legislation or as a precautionary measure:

Obtain an emergency kit containing a set of spare bulbs and fuses from an approved Dealer.




# FUSES

## Allocation of fuses

(the presence of certain fuse depends on the vehicle equipment level)

Vehicles not equipped with a fuse allocation label



66170

## FUSES

Number	Allocation
<b>1</b>	Rear wiper/rear fog light
<b>2</b>	Direction indicators
<b>3</b>	Brake lights
<b>4</b>	Right-hand rear window control motor
<b>5</b>	Driver's side window control motor
<b>6</b>	Left-hand rear window control motor
<b>7</b>	Passenger side window control motor
<b>8</b>	Rear-view mirror ECU - multiplexed door matrix control
<b>9</b>	Towbar socket communication module
<b>10</b>	Accessories socket
<b>11</b>	Instrument panel

# INSTALLATION AND USE OF ACCESSORIES

## Important recommendations



### Electrical and electronic accessories

Before installing this type of accessory (particularly for transmitters/receivers: frequency bandwidth, power level, position of the aerial, etc.), make sure it is compatible with your vehicle. Contact an approved dealer.

Before connecting an accessory to a socket, please ensure that it does not exceed the maximum power authorised for the socket → 295 → 300. **Fire hazard.**

No work may be carried out on the vehicle's electrical and/or electronic circuits, except by a qualified professional. In fact, an incorrect connection and/or the installation of electrical/electronic accessories not approved by the manufacturer could lead to:

- damage to the electrical and/or electronic equipment;
- damage to the components connected to it;
- the collection and use of vehicle data;
- an invasion of privacy (modification, deletion or unwarranted access to personal data);
- cancellation of the authorisation for entry into service.

### **Risk of serious accidents. Risk of invasion of privacy.**

If you have electrical equipment fitted in future, make sure that you are notified of the rating and position of the corresponding fuse.

### **Using the diagnostic socket**

The use of electronic accessories on the diagnostic socket may cause serious disturbance to the vehicle's electronic systems and/or cause invasion of privacy (modification, deletion or unwarranted access to personal data). For your safety we recommend that you use only electronic accessories approved by the manufacturer, consult an approved dealer. **Risk of serious accidents. Risk of invasion of privacy.**

### **Fitting aftermarket accessories**

If you wish to install accessories on the vehicle: consult an approved dealer. Also, to ensure the correct operation of your vehicle, and to avoid any risk to your safety, we recommend that you use only accessories specifically designed for your vehicle, which are the only accessories for which the manufacturer will provide a warranty.

If you are using an anti-theft device, only attach it to the brake pedal.

### **Driver obstruction**

## INSTALLATION AND USE OF ACCESSORIES

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another. **There is a risk of wedging the pedals.**

# OPERATING FAULTS

## Operating faults

The following advice will enable you to carry out quick, temporary repairs. For safety reasons you should always contact an approved dealer as soon as possible.

FAULTS	POSSIBLE CAUSES	ACTION REQUIRED
Impossible to charge the traction battery.	The outdoor temperature is lower than -26°C.	Recharge your vehicle in a more suitable environment. If necessary → 326.
The charging flap warning light flashes red.	No electrical current in the wall socket or poor connection of the cable in the domestic socket.	Check your installation (circuit breaker, programmer, etc.). Check the connections (charging socket, etc.) → 20.
	The cord is defective.	Please see an authorised dealer to replace it.
Impossible to charge the traction battery. The charging flap warning light flashes blue.	The charging cord is not correctly locked to the vehicle.	Reconnect the charging cable to the vehicle → 20 correctly.

6

FAULTS	POSSIBLE CAUSES	ACTION REQUIRED
The card does not lock or unlock the doors.	Card battery is flat.	Replace the battery or have it replaced. You will still be able to lock, unlock, and start your vehicle → 51 and → 153.
	Use of appliances operating on the same frequency as the remote control (mobile phone, etc.).	Stop using the devices or use the built-in key → 51.
	Vehicle located in a high electromagnetic radiation zone. Secondary 12 volt battery discharged.	Use the key that is built into the card → 62.

## OPERATING FAULTS

FAULTS	POSSIBLE CAUSES	ACTION REQUIRED
	Desynchronisation of the card.	Unlock the driver's door by inserting the card's built-in key into the door lock → 62, then place the card on the placement area → 153 and press the "START" button to synchronise the card.
The "Place the card near the START button" message appears on the instrument panel.	The card battery is flat or the card is out of synch.	Check the card battery status or place the card in the dedicated placement area → 51.
FAULTS	POSSIBLE CAUSES	ACTION REQUIRED
Steering becomes heavy.	Assistance overheating.	Drive carefully at reduced speed, be aware of the level of force in the steering wheel needed to turn the wheels.
	Fault with the electric assistance motor. Fault in the assistance system.	Consult an approved Dealer.
Electrical equipment	POSSIBLE CAUSES	ACTION REQUIRED
Vibrations.	Tyres not inflated to the correct pressure, incorrectly balanced or damaged.	Check the tyre pressures. If this is not the problem, have them checked by an approved Dealer.
The wipers do not work.	Wiper blades stuck.	Free the blades before using the wipers.
	Broken windscreen wiper fuse.	Consult an approved Dealer.
	Blown rear screen wiper fuse (intermittent, permanently stopped).	Replace the fuse or have it replaced → 333.
	Motor fault.	Consult an approved Dealer.
The wiper does not stop.	Faulty electrical controls.	Consult an approved Dealer.

## OPERATING FAULTS

Electrical equipment	POSSIBLE CAUSES	ACTION REQUIRED
Direction indicators flashing more quickly.	Faulty bulb.	Consult an approved Dealer.
The indicators are not working.	On one side: Faulty bulb.	Consult an approved Dealer.
	On both sides: <ul style="list-style-type: none"> <li>– blown fuse;</li> <li>– Faulty electrical circuit or control.</li> </ul>	Replace the fuse or have it replaced <b>➔ 333.</b>  Replace: contact an approved dealer.

## OPERATING FAULTS

Electrical equipment	POSSIBLE CAUSES	ACTION REQUIRED
The headlights are not working.	One only: – Faulty bulb;	Consult an approved Dealer.
	– disconnected wire or incorrectly-positioned connector;	Consult an approved Dealer.
	– fuse damaged.	Replace the fuse or have it replaced → 333.
Both:	Two fuses damaged.	Replace the fuses → 333 or have them replaced.
The headlights do not switch off.	Faulty electrical controls.	Consult an approved Dealer.
Traces of condensation in the headlights or rear lights.	Traces of condensation may be a natural phenomenon caused by variations in temperature and humidity. In this case, the traces will disappear slowly once the lights are switched on.	

## OPERATING FAULTS




Stopped	POSSIBLE CAUSES	ACTION REQUIRED
<p>The air conditioning and ventilation fan switch on after the ignition is switched off or when the vehicle is being charged.</p>	<p>This is not necessarily a fault, the air conditioning compressor and the ventilation fan switch on to regulate the temperature of the system when the exterior temperature is low.</p>	<p>Consult an approved Dealer.</p>
	<p>The air conditioning compressor and the ventilation fan switch on for more than 30 minutes when the ignition is switched off.</p>	
<p>The programmable air conditioning fails to work.</p>	<p>One of the usage conditions is not complied with (the traction battery is not charged, etc).</p>	<p>➔ 291</p>
<p>The passenger compartment air conditioning and the heating functions are switched off with no action by the user, even if the battery is sufficiently charged.</p>	<p>This is not necessarily a fault, the system switches off by default to preserve battery autonomy or optimise recharging.</p>	<p>To enter the extended life on board mode, press the Start button without pressing the brake pedal. The air conditioning nevertheless stops after a few minutes. You can always reactivate the system by pressing the air conditioning controls ➔ 287.</p>
	<p>Electrical fault.</p>	<p>Consult an approved Dealer.</p>

6

# INFORMATION ABOUT THE VEHICLE

## Vehicle identification plates

## Vehicle identification plates



The information shown on the vehicle identification plate should be

quoted on all correspondence or orders.

The presence and location of the information depends on the vehicle.

### Manufacturer's plate A

1. Manufacturer name.
2. EC design number or approval number.
3. Identification number.


**B. Depending on the vehicle, this information is also provided on the marking.**

4. MMAC (Maximum permissible all-up weight).
5. MTR (Gross Train Weight: vehicle fully loaded, with trailer).
6. MMTA (Maximum Permissible Weight) front axle.
7. MMTA rear axle.
8. Area reserved for related or additional entries.
9. Not used.
10. Paint reference (colour code).

## INFORMATION ABOUT THE VEHICLE

Technical Information for the emergency services

Technical Information for the emergency services



The QR Code on label **A** allows emergency workers to use a tablet or smartphone to immediately access technical information that is useful for working on the vehicle in the event of an accident.

Ensure that the label **A** is always visible and present on the windscreen as well as the rear screen.


**Any modification or damage would prevent access to the information.**

## INFORMATION ABOUT THE VEHICLE

**Engine identification, engine specifications**


# INFORMATION ABOUT THE VEHICLE

## Engine identification



62527

## Engine specifications



7

**Please quote the information on the engine plate or label A in all correspondence or orders.**

(Location varies depending on engine)

1. Engine type.
2. Engine suffix.
3. Engine serial number.

## INFORMATION ABOUT THE VEHICLE

### Information on lifting

66305



Your vehicle is equipped with four dedicated lifting points **1** located underneath the vehicle.



**For your safety**, we recommend that you consult an approved dealer when changing wheels.

**Risk of damage to the vehicle and particularly to the electric traction battery in the event of incorrect positioning of the lifting equipment.**

The lifting points are compatible with the use of a jack with a flat plate and a diameter between **max. 80 mm** and **min. 140 mm**.

The jack used must comply with the standards and regulations in force for the country. The jack lifting capacity must be greater than the maximum permissible weight of the relevant vehicle ➔ **345**.

Lifting the vehicle using a jack is intended only for changing the wheels. This should be performed:

- with the parking brake applied,
- the vehicle unladen,
- on level, non-slip and solid ground.

Before lifting the vehicle, the plate of the jack must be correctly positioned on lifting **point 1**.



To prevent any risk of injury or damage to the vehicle, the jack must only be cranked until the wheel you are replacing is at most three centimetres off the ground.

**Risk of injury. Risk of damage to the vehicle.**



For safety reasons, the vehicle lifting points should be used only for wheel changes. Under no circumstances should they be used:


- to carry out a repair;
- to access the underside of the vehicle.

**Risk of injury. Risk of damage to the vehicle.**

# INFORMATION ABOUT THE VEHICLE

Dimensions (in metres)

Dimensions diagram



7

# INFORMATION ABOUT THE VEHICLE

## Dimensions table

	Length
<b>A</b>	0,789
<b>B</b>	2,534
<b>C</b>	0,674
<b>D</b>	3,997
<b>E</b>	1,575
<b>F</b>	1,512 unladen
<b>G</b>	1,570
<b>H</b>	1,823 2.020 with door mirrors folded out 1.830 with door mirrors folded in

# INFORMATION ABOUT THE VEHICLE

## Weights (in kg)

### Weight table

The weights indicated are for a basic vehicle without optional fittings: they vary according to your vehicle's equipment. Consult your approved Dealer.

<b>Maximum Permissible All-Up Weight (MMAC)</b> <b>Maximum Permissible Weight (MMTA)</b> <b>Gross Train Weight (MTR)</b>	Weights indicated on the manufacturer's plate → <b>345</b>
<b>Towing Weight Braked*</b>	found by calculating: MTR - MMAC
<b>Unbraked Towing Weight*</b>	500 kg
<b>Permissible nose weight*</b>	75 kg
<b>Maximum permissible load on roof</b>	Prohibited

#### \* Towing weight (towing a caravan, boat, etc.)

Towing is prohibited when the MTR - MMAC calculation is equal to zero, or when the MTR is equal to zero (or is not indicated) on the manufacturer's plate.

- It is important to respect local towing regulations in force, specifically those set out in the Highway Code. Contact an approved Dealer for any modifications to towing equipment.
- For vehicles fitted with a trailer, **the total train weight (vehicle + trailer) must never be exceeded**. However the following is tolerated:
  - rear MMTA exceeded by up to 15%;
  - MMAC exceeded by up to 10% or 100 kg (whichever limit is reached first).

In either case, the maximum speed of the vehicle and trailer must not exceed 62 mph (100 km/h) and the tyre pressures must be increased by 0.2 bar (3 PSI).

## REPLACEMENT PARTS AND REPAIRS

Original parts are based on very stringent specifications and are subjected to specific tests. Therefore, they are of at least the same level of quality as the parts fitted originally.

If you always fit genuine replacement parts to your vehicle, you will ensure that it performs well. Furthermore, repairs carried out in the approved dealer network with original parts are guaranteed according to the conditions stated on the back of the repair order.

# SERVICE SHEETS

VIN: .....

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			

\* See specific page

7

# SERVICE SHEETS

VIN: .....

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			

\* See specific page

# SERVICE SHEETS

VIN: .....

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			

\* See specific page

7

# SERVICE SHEETS

**VIN:** .....

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b> Service <input type="checkbox"/> ..... <input type="checkbox"/>		<b>Stamp</b>	
<b>Anticorrosion check:</b> OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			

\* See specific page

# SERVICE SHEETS

VIN: .....

Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			

\* See specific page

7

# SERVICE SHEETS

**VIN:** .....



Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			
Date:	Miles (km):	Invoice number:	Comments/miscellaneous
<b>Type of operation:</b>		<b>Stamp</b>	
Service <input type="checkbox"/>			
..... <input type="checkbox"/>			
<b>Anticorrosion check:</b>			
OK <input type="checkbox"/> Not OK* <input type="checkbox"/>			

\* See specific page

# ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.

**VIN:** .....



Date of repair:		<b>Stamp</b>
Corrosion repair operation to be carried out:		
Date of repair:		<b>Stamp</b>
Repair to be carried out:		

7

# ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.



**VIN:** .....

Date of repair:		<b>Stamp</b>
Corrosion repair operation to be carried out:		
Date of repair:		<b>Stamp</b>
Repair to be carried out:		

# ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.

**VIN:** .....



Date of repair:		<b>Stamp</b>
Corrosion repair operation to be carried out:		
Date of repair:		<b>Stamp</b>
Repair to be carried out:		

7

# ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.



**VIN:** .....

Date of repair:		<b>Stamp</b>
Corrosion repair operation to be carried out:		
Date of repair:		<b>Stamp</b>
Repair to be carried out:		

# ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.

**VIN:** .....



Date of repair:		<b>Stamp</b>
Corrosion repair operation to be carried out:		
Date of repair:		<b>Stamp</b>
Repair to be carried out:		

7

# ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.



**VIN:** .....

Date of repair:		<b>Stamp</b>
Corrosion repair operation to be carried out:		
Date of repair:		<b>Stamp</b>
Repair to be carried out:		

# ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.

**VIN:** .....

Date of repair:		<b>Stamp</b>
Corrosion repair operation to be carried out:		
Date of repair:		<b>Stamp</b>
Repair to be carried out:		

7

# ALPHABETICAL INDEX

## Symbols

"Hands-free" card: battery, [57](#)

"Hands-free" card: use, [53](#)

## A

Accessing the vehicle, [53](#), [62](#)

Accessories socket, [300](#)

Access to the engine compartment, [307](#)

Active driver assist, [221](#)

Active emergency braking, [208](#)

Active emergency braking in reverse gear, [235](#)

Additional restraint devices: side protection, [85](#)

Airbag, [85](#)

Airbag : activating the front passenger airbag, [109](#)

Airbag: airbag, [85](#)

Airbag : deactivating the front passenger airbag, [109](#)

Airbags : child safety, [109](#)

Air conditioning, [291](#)

Air conditioning: information and advice for use, [292](#)

Air Vents, [283](#)

Audible alarm: door or luggage compartment door open, [62](#)

Audible alarm: lights-on reminder, [62](#)

Audible and visual signals, [146](#)

Automatic locking when driving, [66](#)

## B

Battery, [312](#)

Blind spot warning, [199](#)

Bodywork (maintenance), [314](#)

Bonnet, [307](#)

## C

Card, [62](#)

Card: emergency key, [51](#)

Card: engine not starting in hands-free mode, [51](#)

Card: hands-free, [51](#), [53](#)

Card: locking/unlocking the opening elements, [51](#)

Card RENAULT: use, [53](#)

Central door locking, [66](#)

Charging cable, [44](#)

Charging programming, [44](#)

Children, [62](#), [89](#)

Child restraint, [89](#)

Child restraint devices, [89](#)

Child restraint system, [89](#)

Child safety, [89](#), [89](#)

Child seats, [89](#), [95](#)

Clock, [130](#), [130](#)

Closing/Opening the doors, [53](#)

Closing/Opening the luggage compartment, [53](#)

Closing/Opening the sunroof, [53](#)

Closing the doors, [62](#), [66](#)

Configuration menu, [128](#)

Control instruments, [125](#)

Coolant level, [309](#)

Customising the vehicle settings, [128](#)

# ALPHABETICAL INDEX

## D

Detection of road signs, [217](#)  
Digital key, [59](#)  
Display, [125](#), [125](#)  
Doors, [62](#), [62](#), [66](#)  
Doors/Luggage compartment door, [53](#), [62](#), [66](#)  
Driver vigilance warning, [215](#)  
Driving advice, [171](#)  
Driving position, [113](#)  
Driving position: settings, [75](#)

## E

ECO driving, [171](#)  
Electrical adjustment of the dipped beam headlights, [143](#)  
Electric windows, [297](#)  
Electronic parking brake, [164](#)  
Emergency: emergency call, [278](#)  
Emergency lane departure prevention, [192](#)  
Engine identification, [347](#)  
Engine specifications, [347](#)  
Environment, [170](#)  
Exterior lighting and signals, [139](#)  
Exterior lights, [328](#)

## F

Fitting accessories, [338](#)  
Fitting a child seat, [95](#)  
Front headrests, [70](#)

Front seat adjustment, [70](#)  
Front seats, [70](#)  
Front seats: adjustment, [70](#), [75](#)  
Fuses, [333](#)

## G

Gear control, [160](#)

## H

Hands-free parking, [267](#)  
Headlight beam adjustment, [143](#)  
Headlight beam adjustments, [143](#)  
Headlights: adjustment, [143](#)  
Headrests, [73](#)  
Heating and air conditioning system, [283](#)  
Heating system, [283](#)

## I

Instrument panel, [125](#)  
Interior lighting, [298](#)  
Interior lighting: changing bulbs, [329](#)  
Interior trim: maintenance, [316](#)

## L

Lane departure prevention, [185](#)  
Levels, [307](#), [310](#)  
Levels: coolant, [309](#)  
Lighting signals, [143](#)

# ALPHABETICAL INDEX

Lights: adjustment, [143](#)  
Lights: replacing bulbs, [328](#)  
Locking/unlocking the doors, [64](#)  
Locking the doors, [53](#), [62](#), [66](#)  
Luggage compartment, [67](#)

## M

Maintenance: bodywork, [314](#)  
Maintenance: filters, [310](#)  
Maintenance: interior trim, [316](#)  
METHODS OF RESTRAINT IN ADDITION TO REAR SEAT BELTS,  
[85](#)  
Methods of restraint in addition to the front seat belts, [80](#)  
Multimedia equipment, [295](#)

## O

Opening/closing: opening elements, [62](#)  
Opening element/door controls, [53](#)  
Opening elements, [53](#), [62](#)  
Opening elements - locking / unlocking, [62](#)  
Opening the doors, [62](#), [66](#)  
Operating faults, [66](#), [340](#)  
Operating faults: card batteries, [51](#)

## P

Parking brake, [164](#)  
Parking distance control, [258](#)  
Passenger safety: front passenger airbag, [109](#)

Power consumption, [125](#), [125](#)

## R

Rear headrests, [73](#)  
Rear seats, [73](#)  
Rear view mirrors, [137](#)  
Replacement and repair parts, [353](#)  
Replacing windscreen wiper blades, [331](#)  
Restraint in addition to the seatbelts, [85](#)  
Reversing camera, [264](#)

## S

Safe distance alert, [204](#)  
Safe passenger exit, [275](#)  
Seat belts, [75](#), [85](#)  
See-me-home lighting, [143](#)  
Settings, [128](#)  
Settings: configuration menu, [128](#)  
Side protection devices, [85](#), [85](#)  
Speed limiter, [238](#)  
Starting the engine, [153](#)  
Steering wheel: adjustment, [135](#)  
Stopping the engine, [153](#)  
Storage compartment/ fittings: passenger compartment, [301](#)

## T

Temperature: exterior, [130](#)  
Tools, [325](#)

# ALPHABETICAL INDEX

Towbar, [305](#)  
Towing: breakdown, [326](#)  
Transporting children, [89](#)  
Trip computer, [118](#)  
Troubleshooting: towing the vehicle, [326](#)  
Tyre inflation kit, [321](#)  
Tyre pressure, [320](#)  
Tyre pressure monitoring system, [175](#)  
Tyres, [318](#), [318](#)

## U

Unlocking the doors, [66](#)

## V

Vehicle customisation settings, [128](#)  
Vehicle dimensions, [350](#)  
Vehicle identification plates, [345](#)  
Vehicle settings personalisation menu, [128](#)  
Vehicle weights, [352](#)

## W

Warning: parking exit, [272](#)  
Warning buzzer, [62](#)  
Warning lights on the instrument panel, [125](#)  
Washer/wiper, [147](#), [150](#)  
Windscreen washer, [147](#), [150](#)  
Wiper, [147](#), [147](#), [150](#)  
Wiper blades: replacement, [331](#)





SOCIÉTÉ DES AUTOMOBILES ALPINE, SA par actions simplifiée à associé unique  
AVENUE DE BREAUDE, 76200 DIEPPE - SIRET 662 750 074 / SITE INTERNET : [alpinecars.com](http://alpinecars.com)

NU 1491-1 – 77 11 416 082 - 06/2024 - Edition anglaise



7711416082

